



# BUNK BED

**IMPORTANT – READ CAREFULLY – RETAIN FOR FUTURE REFERENCE**

## Tools Needed

Two persons required  
Cross head screwdriver



Regrettably self assembly items cannot be returned once assembly is part or fully completed unless the items are found to be faulty. Should you need to return the unassembled product, please repack in its original packaging.

## Important

- We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instruction. Carefully check that you have all the parts before beginning assembly.
- Keep fittings out of children's reach and keep children well away from the construction area.
- We suggest you retain these instructions for future reference.
- A minimum of 2 persons is required to assemble this product.
- We recommend that the packaging is used to protect the surfaces during assembly.

## Product Information

- This product is made New-Zealand Pine wood with a painted finish.
- Natural features ensure that each piece is individual to you. Every effort is made to ensure colour continuity between pieces, however this is a natural product, slight colour variations and natural markings may occur.
- Made in Vietnam.
- This item complies with BS EN: 747 : 2007













## Care Instructions

- **Do not over tighten all the screw.**
- Do not rub or scrub the surface when cleaning.  
Ensure the product is protected with mats and coasters when items are placed on its surface, to prevent scratching or damage. Do not put hot dishes directly onto wooden surfaces.
- Avoid keeping the furniture in direct sunlight or close to any heat source as this can cause cracking, discolouration or warping.
- Never drag the pieces across the floor as this could cause damage to the joints.
- Periodically check all fixings and tighten if necessary.  
Wood will mellow and change colour over time, we recommend that ornaments are moved regularly to prevent uneven mellowing.

**“USE OF A POWER TOOL TO ASSEMBLE THE PRODUCT WILL INVALIDATE ANY CLAIM AND COULD MAKE THIS PRODUCT UNSAFE.”**

# Components parts and fittings contained in the box

## Fittings:


<p>(H1) 22 pcs</p>  <p>FLAT HEAD ALLEN SCREW: Ø8 x 100</p>	<p>(H2) 22 pcs</p>  <p>BARREL NUT: Ø8 x 15</p>	<p>(H3) 9 pcs</p>  <p>FLAT HEAD ALLEN SCREW: Ø6 x 30</p>
<p>(H4) 60 pcs</p>  <p>SCREW: Ø4 x 30</p>	<p>(H5) 4 pcs</p>  <p>WOODEN DOWEL: Ø12 x 80</p>	<p>(H6) 6 pcs</p>  <p>FLAT HEAD ALLEN SCREW: Ø6 x 40</p>
<p>(H7) 6 pcs</p>  <p>FLAT HEAD ALLEN SCREW: Ø6 x 50</p>	<p>(H8) 12 pcs</p>  <p>FLAT HEAD ALLEN SCREW: Ø6 x 80</p>	<p>(H9) 1 pc</p>  <p>ALLEN KEY: 4mm</p>
<p>(H10) 1 pc</p>  <p>ALLEN KEY: 5mm</p>	<p>(H11) 52 pcs</p>  <p>WOODEN DOWEL: Ø10 x 40</p>	<p>(H12) 8 pcs</p>  <p>SCREW: Ø4 x 25</p>

Please sort out all parts before you begin to assemble the item. This to make sure you always use the correct part  
Do not over tighten all the screw.

# WARNING !


Keep small components out of the reach of children  
Parts:

P1 1 pc




Upper H/B (left 18 holes)

P2 1 pc




Upper F/B (right 12 holes)

P3 2 pcs




Lower HB/FB

P4 1 pc




Bottom back side rail (no hole)

P5 1 pc




Bottom front side rail (2 holes)

P6 1 pc



Top front side rail (3 holes)

P7 1 pc



Top back side rail (2 holes)

P8 2 pcs




Lower top rail (2 holes)

P9 2 pcs




Upper top rail

P10 2 pcs



Back guard rail (2 holes)

P11 2 pcs



Front guard rail (1 hole)

P12 26 pcs




Slats

P13 4 pcs




End slats

P14 1 pc



Ladder post (left)

P15 1 pc



Ladder post (right)

P16 3 pcs



Step of ladder

P17 3 pcs



Support guard rail

P18 43 pcs



Wooden button


# STEP ONE

Attach wooden dowels in Bottom back side rails (P4) and (P5) as picture.

Attach lower HB/FB (P3) with Bottomback side rails (no hole) (P4) and Bottom back side rail (2 holes) (P5).

Tighten with Flat head allen screw (H1) and Barrel nut (H2) by allen-key (H10).

Use 8 pcs wooden buttons (P18) to attach in holes.




# STEP TWO

Attach lower top rails (P8) with lower HB/FB.

Use wooden dowels (H11) and Flat head allen (H8) to link them together as picture.

Use allen key (H9) to tighten them.

Put 4 wooden dowels (H5) into holes to link top bed




# STEP THREE

Attach Upper H/B (P1) and Upper F/B (P2) as picture.

Attach Upper top rail (P9) with Upper HB/FB.

Use wooden dowels (H11) and Flat head allen (H8) to link them together as picture.

Use allen key (H9) to tighten them.



# STEP FOUR

Attach wooden dowels as picture.

Attach Top front side rail (P6) and Top back side rail (P7) and use Flat head allen screws (H1)


Do not tighten these until instruction to case assembly..

Attach Back guard-rails (P10) and use Flat head allen screws (H1)..

Do not tighten these until instruction to case assembly..

Use allen key (H10) to fully tighten rails when all in position

Use 12 pcs wooden buttons (P18) to attach in holes.




# STEP FIVE

Attach wooden dowels as picture (H11).

Attach ladder post (P14) and (P15) with steps of ladder (P16).

Use Flat head allen screws (H7) to link them together tightening with allen key (H9).

Use 6 pcs wooden butons (P18) to attach in holes.




# STEP SIX

Attach ladder with the bed as picture

Use Flat head allen screws (H6) to tighten them.

Tighten screw(H13) by screwdriver as picture.

Use 8 pcs wooden butons (P18) to attach in holes.




# STEP SEVEN

Attaching front guardrails (P11) using Flat head allen screws (H1) and (H6).

Attach Support guard-rails (P17) using Flat head allen screws (H3).

Tighten all screws.


Use 11 pcs wooden buttons (P18) to attach in holes.



# STEP EIGHT


Fix 4 pcs of end slats (P13) and 26 slats (P12) as picture

Use screws (H4) and use screwdriver to tighten all slats.



# Assembly Instructions

## BUNK BED




### **INSTRUCTIONAL LITERATURE WARNING**

**PLEASE READ CAREFULLY BEFORE USE**

**TO HEPL PREVENT INJURIES PLEASE FOLLOW INSTRUCTION CAREFULLY.**

- 1. NEVER ALLOW A CHILD UNDER 6 YEARS ON UPPER BED.**
- 2. USE ONLY MATTRESS, WHICH IS 900mm- 925mm and 1895mm-1905mm.**
- 3. ENSURE THICKNESS OF MATTRESS DOES NOT EXCEED 190mm.**
- 4. PROHIBIT MORE THAN ONE PERSON ON UPPER BUNK.**
- 5. USE LADDER FOR ENTERING AND LEAVING UPPER BUNK.**
- 6. DO NOT USE IF ANY STRUCTURAL PART IS BROKEN.**
- 7. ENSURE NOT TO HANG OR ATTACH ITEMS THAT COULD LEAD TO STRANGULATION ( ROPES, HARDNESS, BELTS, ETC.. )**
- 8. WARNING: CHILDREN CAN BECOME TRAPPED BETWEEN THE BED AND THE WALL. TO AVOID RISK OF SERIOUS INJURY THE DISTANCE BETWEEN TOP BARRIER AND THE WALL SHALL NOT EXCEED 75mm OR BE MORE THAN 230mm)**



#### **Remark:**

**Use 4 pcs wooden button to cover the pre-drilled holes on lower top rails holes if customer decide to convert this bunk bed to 2 single beds**