






ASSEMBLY INSTRUCTIONS






Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 2 people to assembly.
Make sure no parts are missing or damaged before assembly.


Not actual size




① X1




② X1




③ X1




④ X1




⑤ X1




⑥ X4




⑦ X2




⑧ X2




⑨ X2



⑩ X1




⑪ X1




⑫ X1


Not actual size




⑬X1




⑭X1




⑮X1




⑯X1




⑰X1




⑱X2




⑲X2




⑳X6




㉑X6



㉒X6




㉓X6




㉔X6


Not actual size




25 X1




26 X1




27 X1




28 X1




29 X1




30 X2









<div><div>A</div><div>X104+3</div></div> <div></div> <div><div>ø6.5*35</div></div>	<div><div>B</div><div>X104+3</div></div> <div></div> <div><div>ø15*9.5</div></div>	<div><div>C</div><div>X16+1</div></div> <div></div> <div><div>ø8*30</div></div>	<div><div>D</div><div>X18+1</div></div> <div></div> <div><div>ø6*30</div></div>
<div><div>E</div><div>X84+3</div></div> <div></div> <div><div>ø3.5*14</div></div>	<div><div>F</div><div>X14+1</div></div> <div></div> <div><div>ø3*12</div></div>	<div><div>G</div><div>X39+2</div></div> <div></div> <div><div>ø4*35</div></div>	<div><div>H</div><div>X24+2</div></div> <div></div> <div><div>ø3*14</div></div>
<div><div>I</div><div>X2</div></div> <div></div> <div><div>ø4*14</div></div>	<div><div>J</div><div>X6</div></div> <div></div> <div><div>12*45</div></div>	<div><div>K</div><div>X7</div></div> <div></div> <div><div>106*16*8</div></div>	<div><div>L</div><div>X14</div></div> <div></div> <div><div>ø4*18</div></div>
<div><div>M</div><div>X1</div></div> <div></div> <div><div>109*99*38.5</div></div>	<div><div>N</div><div>X7</div></div> <div><div>CL</div><div><div>L=350</div></div></div>	<div><div>N</div><div>X7</div></div> <div><div>CR</div><div><div>L=350</div></div></div>	<div><div>N</div><div>X7</div></div> <div><div>DL</div><div><div>L=350</div></div></div>
<div><div>N</div><div>X7</div></div> <div><div>DR</div><div><div>L=350</div></div></div>	<div><div>O</div><div>X1</div></div> <div></div> <div></div>	<div><div>P</div><div>X1</div></div> <div></div> <div><div>72*30*5</div></div>	<div><div>Q</div><div>X10+2</div></div> <div></div> <div></div>





Cam Lock Fastening System


Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 1




(E)	X18
	
Ø3.5*14	




(N)	X3
	
CL L=350	

(N)	X3
	
CR L=350	





STEP 2


(A)	X18
	
Ø6.5*35	




A line drawing of a screwdriver. The handle is on the left, and the shaft extends to the right. A circular callout is positioned at the tip of the shaft, with two lines connecting it to the tip, providing a magnified view of the screwdriver's point.


E	X12
	
Ø3.5*14	



N	X1
	
CL	
L=350	

(N)	X3
	
L=350	





STEP 4


A	X15
	
Ø6.5*35	





FLIP OVER





STEP 5




(E)	X12
	
Ø3.5*14	




(N)	X3
	
CL L=350	

(N)	X1
	
CR L=350	





STEP 6


(A)	X15
	
Ø6.5*35	



FLIP OVER





STEP 7



A	X2
Ø6.5*35	




B	X2
Ø15*9.5	

C	X4
Ø8*30	




X 2




Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 8

(B)	X18
	
Ø15*9.5	






Insert the cam bolt into the hole first, then insert the cam lock and lock it.




Proper orientation of CAM LOCK

STEP 9

(B)	X18
	
Ø15*9.5	





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK


STEP 10

(B)	X12
	
Ø15*9.5	

(C)	X4
	
Ø8*30	





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK




STEP 11




(A)	X9
	
Ø6.5*35	

(B)	X4
	
Ø15*9.5	

(D)	X2
	
Ø6*30	




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



STEP 12

B


X5





Ø15*9.5

D


X4




Ø6*30



FLIP OVER




Insert the cam bolt into the hole first, then insert the cam lock and lock it.



Proper orientation of CAM LOCK



STEP 13




(A)	X9
Ø6.5*35	

(B)	X4
Ø15*9.5	

(D)	X2
Ø6*30	




Insert the cam bolt into the hole first, then insert the cam lock and lock it.





Proper orientation of CAM LOCK

STEP 14




(B)	X5
Ø15*9.5	


(D)	X4
Ø6*30	





Insert the cam bolt into the hole first, then insert the cam lock and lock it.




STEP15




ⓐ	X6
	
1245	


ⓕ	X12
	
Ø3*12	


THIS STEP REQUIRES 2 PEOPLE










STEP 16


A	X8
	
Ø6.5*35	

D	X6
	
Ø6*30	

G	X11
	
Ø4*35	




STEP 17




(B)	X8
Ø15*9.5	

(C)	X8
Ø8*30	


THIS STEP REQUIRES 2 PEOPLE





Insert the cam bolt into the hole first, then insert the cam lock and lock it.





STEP 18






Ⓜ	X24
	
Ø3*14	


Ⓜ	X1
	
109*99*38.5	


Ⓜ	X2
	
Ø4*14	


Ⓜ	X1 set
	





STEP 19



A	X24
	
Ø6.5*35	

B	X24
	
Ø15*9.5	






G	X24
	
Ø4*35	

K	X6
	
10616*8	

L	X12
	
Ø4*18	



FLIP OVER




Proper orientation of CAM LOCK

Insert the cam bolt into the hole first, then insert the cam lock and lock it.

Step 3

X6

STEP 20





(A)	X4
Ø6.5*35	

(B)	X4
Ø15*9.5	



(G)	X4
Ø4*35	

(K)	X1
10616*8	

(L)	X2
Ø4*18	






Step 1



Step 2


Step 3





Proper orientation of CAM LOCK


Insert the cam bolt into the hole first, then insert the cam lock and lock it.


STEP 21



(E)	X36
	
Ø3.5*14	


(N)	X6
	
DR L=350	


(N)	X6
	
DL L=350	





X6


STEP 22




(E)	X6
	
Ø3.5*14	


(N)	X1
	
DR L=350	


(N)	X1
	
DL L=350	




STEP 23




F	X2
	
Ø3*12	

O	X1
	

Q	X10
	

Tear off a layer of 3M polyethylene foam.




STEP 24


Pass the bulb wire through the pre punched plate, then gently press the bulb and make it adhere to the plate, and then connect the adjacent bulbs successively through the wire head slot on the opposite side (corresponding to the line of the same color).

When connecting the interface, please note that the colors of the wires at both ends correspond one by one.



same color correspond



STEP 25



STEP 26




⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove !


Install the tipping restraint hard ware




1.make mark on the wall




2.drill two Ø6 holes on the wall



3.put two anchors in the holes



4.fix the device on the wall by the long screws



5.Push the cabinet close to the wall so that the two bases are close to each other, and then put on nylon tie to tighten it.

