

Installation & Assembly



Assembly Instructions

Before beginning the assembly process, please read and save these instructions for reference. Following these guidelines will ensure a smooth and successful assembly of your product.

1. Part Identification:

Carefully separate and identify all the parts included in your package. Confirm that you have all the components listed in the instruction manual. This step will help you avoid any missing or misplaced parts during assembly.

2. Work Surface:

To prevent any scratches or damage to the product, assemble it on a soft mat or a similar protective surface. This will provide a cushioned area for the components and protect the surfaces from unwanted marks.

3. Step-by-Step Assembly:

Follow the assembly instructions provided, proceeding one step at a time. Take care to understand each step properly before proceeding to the next one. This sequential approach ensures that the assembly is done correctly and minimizes the chance of errors.


4. Proper Screw Seating:

When attaching screws and nuts, it is essential not to fully tighten them until all screws are correctly seated. By partially tightening each screw and nut initially, you can ensure that they are aligned properly and fit securely before final tightening.


5. Avoid Over-Tightening:

While each screw and nut should be tightened correctly, it is crucial not to over-tighten them. Over-tightening can cause damage to the product or compromise its structural integrity. Use the appropriate amount of force to secure the components without excessive tightening.










Parts list



x2



Hardware list

Ax16 	Bx28  ø3x12	Cx16 	Dx16 	Ex13  ø4x35
Fx17  ø4x14	Gx1  G1+G2	Hx2 	Ix2 	


Code	Description	qty
A	Wood dowel	16+2
B	ø3x12 self-tapping screw	28+2
C	Cam bolt	16+2
D	Cam lock	16+2
E	ø4x35 self-tapping screw	13+2

Code	Description	qty
F	ø4x14 self-tapping screw	17+2
G	Angle iron	1
H	Drawer pull	2
I	Drawer slider	2


Step 1



Press the plastic part in the indicated direction to separate drawer runner I1 and I2 before assembling.

Attention:
Please grip the I1 part while sliding
the I2 part.



Step 2




(B)		X 12
(I)		X 4

← FRONT


Attention:

1. Please locate the holes from the back of part I1.

I1 Back:





I1 Front:




2. Then please install part B from the front of part I1.





Step 3




Step 4





Step 5






Step 6





Step 7



Step 8



Step 9





(F)




X 16

Step 10



(C)



X 4

(F)







X 1

(G)




X 1


Step 11




Step 12





Step 13




Step 16




x2



- (B)  X 4
- (H)  X 2

Step 17





x2



- (B)  X 12
- (I)  X 4

Step 18




Attention:


1. Align the slide runners on the drawer with the unit and push it carefully inside until it stops.

- ★ If the drawer does not go in smoothly please take it out and repeat the step.

Step 19



To assemble the anti-rewind, remove the top drawer



(E)



X 1

(G)



X 1

Step 20

