

Assembly Instructions: Hanging Daybed

Tools Needed:

- Power Screwdriver

Parts List:

- 2 - Headboards
- 1 - Backrest
- 2 - Front Posts
- 2 - Back Posts
- 1 - Front Rail
- 7 - Mattress Boards

Hardware List:


- 4 - 4" Eyebolts
- 8 - 3½" Bolts
- 12 - 2¾" Bolts
- 8 - Dowel Nuts
- 34 - 1¾" Screws
- 1 - Allen Wrench
- 1 - Square Drive Bit
- 4 - Chains or Ropes





Step 1: Attach 1 front post and 1 back post to each headboard. Keep the notches in the posts on the same side. (The front posts have 2 bolt holes and the back posts have 4 bolt holes.) Fasten with 4 - 3½" bolts per headboard and tighten with the Allen wrench. Now attach the ends of the headboard caps to the top of the posts with 4 - 1¾" screws in the predrilled holes (see photos 1 & 2).



Step 2: Insert two dowel nuts in the holes in each end of the bottom backrest board and on the inside of the front rail. Push them in all the way and turn so the threaded holes align with the holes in the ends of the rails. (See photos 3, 4 & 5).




Step 3: Attach the backrest to the back posts. Place the bottom rail in the notches in the inside of the posts. Insert four 2 $\frac{3}{4}$ " bolts through the top and bottom holes in the posts. Turn the top bolts into the threaded inserts in the backrest and the bottom bolts into the dowel nuts in the bottom rail. A straight screwdriver can be used to properly align the dowel nuts (see photo 6).



Step 4: Place the front rail in the notches in the front posts. Turn two 2 $\frac{3}{4}$ " bolts into the dowel nuts in each end (see photo 7).

Step 5: Place the mattress boards in the frame and space them evenly. Fasten with 1 $\frac{3}{4}$ " screws, 4 screws per board (see photos 8 & 9).



Step 6: Find the 4 holes in the front and back posts close to the top. Insert the 4" eyebolts & turn into the inserts. (See photo 10). If you are attaching chain, hook the chain into the eyebolts before fully tightening them. If you are attaching ropes, pull an end of the rope through the eyebolts and make a knot in the end of the rope below the eyebolts. Hook the ends of chain or the rings on the end of the rope onto hooks at the ceiling. If you have ropes you will need to adjust them until the daybed is at the desired height. The ropes are all adjustable. To lower the daybed, push the bottom loops on the end of the rope further up the rope, then hold the top loops with one hand and pull the end of the rope up through the loops. To raise the daybed, pull the rope through the loops in the opposite direction. If the daybed is crooked, adjust the ropes until it hangs properly.