


Installation Instruction




Notice Regarding Surface Finish

This product is manufactured using MDF (Medium-Density Fiberboard) with a marble-pattern decorative surface. Due to variations in the manufacturing and printing process, the marble grain pattern may differ slightly between individual panels. Therefore, the appearance of the product you receive may not be identical to the images shown. Such variations are normal and do not affect product quality or functionality.

Assembling

What you need


- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips head screwdriver



Weight Limitation



100 | **35**
lbs table top lbs per



What' included


Code	Description	Qty
A	Wrench	1
B	Phillips screwdriver	1
C	Wooden Dowel M8X30MM	6
D	Screw M4X40MM	12
E	Screw M3.5X14MM	20
F	Left Liftre	1
G	Right Liftre	1
H	Screw M6X25MM	4
I	Screw M6X12MM	16
J	Screw M6X30MM	16
K	Screw M6X25MM	2

The Hardware


Ⓐ




Ⓑ



Ⓒ




Ⓓ




Ⓔ



Ⓕ



Ⓖ



Ⓗ



Ⓘ



Ⓝ



Ⓚ




IMPORTANT:

- 1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
- 2. Do not over tighten screws and bolts to avoid stripping



Included Accessories

Code	Description	Qty
1	Panel	1
2	Base plate	1
3	Left side panel	1
4	Right side panel	1
5	Neutral plate	2
6	Edge panel	4
7	Upper metal frame	1
8	Lower frame	1
9	Supporting rod	4
10	Supporting leg	4
11	Connection pipe	1
12	Reinforced pipe	1


The Accessoriss






Step 1





The long sides of the 3rd board, the 4th board and the 5th board have PVC edge bands on the upper side.






Step 2



Step 3




Step 4





Attention: The curvature of accessory 9 is aligned with that of accessory 7.

Attention: Please screw all the accessories I into the holes, and then tighten them with accessory A. (Including the accessories I in Step 5)



Step 5

A	x 1
	

I	x 8
	





Attention: The curvature of accessory 9 is aligned with that of accessory 8.





Attention: Please screw all the accessories I into the holes, and then tighten them with accessory A.






Step 6

A	x 1
	




H	x 4
	




Step 7



Step 8




Step 8




B	x 1

E	x 12



Step 10


Attach Board 6 neatly to the Velcro of iron 7 and 8







Attention: Please fully stretch Board 6 and then stick it tightly along the Velcro to avoid gaps that affect the appearance. If there are obvious gaps, tear them off and stick them again.

To achieve a more attractive appearance, please position the 6th curtain interface at the 9th pipe position.

Step 11

A	x 1
	

J	x 8
	





Hexagonal screw
lock 80%





Please lock the 10th
pipe on the diagonal
in a straight line.

Step 12


A	x 1
	

J	x 8
	




Hexagonal screw
lock 100%



Step 13



Step 14



Step 15



Two people work together to move the table.
Make sure you lift it off the ground.
Don't push and pull.