


# **UESR'S MANUAL**

---

**WJHM203MS**

# Before You Start



1. Read each step carefully and follow the correct order.
2. Separate and count all parts and hardware.
3. Leave enough space for the assembly process.
4. Prepare the following tools: Flat Head Screwdriver, Cross Head Screwdriver and Hammer.
5. Note: If you use an electric drill or electric screwdriver to tighten the screws, please be careful to slow down and stop when tightening the screws. Otherwise, the screws may fall off. (Using an electric screwdriver can increase assembly speed).

# Useful Tips


## Assembly Personnel Required: 1-2 People

- Unpack the item in the area where you plan to store it to avoid excessive lifting.
- Identify, sort, and count the parts before attempting assembly.
- Use a hammer to gently tap in the compression pins.
- The sliders are marked with R (right) and L (left) for proper placement.
- Make sure to always point the tip of the top of the cam lock toward the outer edge.
- If there is a back panel in the package, install it to ensure your unit is complete and sturdy.
- Tighten all the screws provided for the back panel, which can enhance the stability of the product. If it is difficult to tighten, you can use a hammer to secure it and then tighten it.
- Do not use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




# Board Identification

Not actual size




1

**BOTTOM BOARD**  
1400\*390mm  
Qty: 1




2

**LEFT SHELF BOARD**  
675\*350mm  
Qty: 1




3

**RIGHT SHELF BOARD**  
675\*350mm  
Qty: 1




4

**LEFT BOARD**  
670\*389mm  
Qty: 1




5

**MIDDLE BOARD**  
670\*372mm  
Qty: 1




6

**RIGHT BOARD**  
670\*389mm  
Qty: 1




7

**LEFT BACK BOARD**  
677\*115mm  
Qty: 1



8

**RIGHT BACK BOARD**  
677\*115mm  
Qty: 1




9

**BACK BOARD**  
687\*289mm  
Qty: 4


# Board Identification

Not actual size




**10**

TOP BOARD  
1400\*390mm  
Qty: 1




**11**

LEFT DOOR  
665\*339.5mm  
Qty: 2




**12**

RIGHT DOOR  
665\*339.5mm  
Qty: 2



**14**

FRONT LEG SUPPORT  
1205\*60mm  
Qty: 1




**15**

BACK LEG SUPPORT  
1205\*60mm  
Qty: 1




**16**

SIDE SUPPORT  
257.5\*60mm  
Qty: 2



**17**

LEG  
130\*82mm  
Qty: 4




**18**


MID-LEG  
127\*127mm  
Qty: 2

# Board Identification


Not actual size




# Part List




LARGE DOOR HINGE




MIDDLE DOOR HINGE




LEG SUPPORT




HANDLE




CAM BOLT  
spare:2



CAM LOCK  
spare:2




SCREW




DOWEL  
spare:1





BOLT  
spare:1






SCREW



SCREW  
spare:3




SCREW




# Part List


## Cam Lock Fastening System


insert the cam bolt into the hole first, then insert the cam lock and lock it.






# Step 1



	M6*40mm
(D)	X8










	Ø15mm
(E)	X8

	M4
	X1








8









# Step 2













# Step 3








# Step 4









# Step 5






# Step 6



# Step 7





# Step 8





### To adjust the vertical height.

Loosen the four screws "A" on both hinges. Two of them are usually in slotted holes which allows you to adjust up or down by a few mm. Then tighten back up.



### To adjust depth.

Loosen screw "B" and adjust door, if the door can not be adjusted, please loosen screw "C", then try again. Tighten screw "B" and "C".



### To adjust side ways.

Turning the screw "C" on BOTH hinges on each door.