


# ASSEMBLY INSTRUCTIONS



***Thank you for purchasing our product!***

*Please refer and use this assembly instruction to assemble the product.*

*Contact our customer service department in case there are any missing or damage parts or hardware. Please also tell us your "Order ID", We will solve for you as soon as possible.*

## **ASSEMBLY PREPARATION:**

1. Remove all packaging materials, staples and packing straps from the carton.
2. Refer to Parts List and Hardware List and ensure they are correct before assembly. Contact customer service for missing parts.
3. Place all wooden parts on a clean, flat and soft surface (e.g. carpet or rug) to prevent parts from getting scratched.

## **SAFETY PRECAUTION:**

1. Keep all hardware parts out of reach of children.
2. Dispose plastic packaging material immediately to avoid any risk of suffocation to children and animals..

## **TIPS FOR ASSEMBLY:**


1. Allow ample room for assembly and in close proximity to where product will be placed.
2. Assemble the product on a surface that does not scratch or damage the exterior gloss and finish of the furniture.
3. Identify all of the parts, hardware and quantities required for each step.
4. During assembly, do not over-tighten any fittings as this may cause damage.
5. DO NOT USE POWER TOOLS TO ASSEMBLE THIS PRODUCT.
6. Always place the product on a flat, level surface.
7. Do not sit or stand on the partially assembled product; only use the product for which it is intended.

## **CARE AND MAINTENANCE:**

- Use a slightly damp cloth to clean the product. Do not use bleach or abrasive cleaning material.
- Check all the fittings periodically and re-tighten as necessary. Do not use the product if any of the parts is damaged or broken.
- Never allow any kind of liquid to remain on your furniture. Absorption can cause wood to warp or delaminate.
- Do not place hot items (e.g. hot drinks) directly onto the wood surface.















# Part List


Please check if all the pieces listed bellow are received



# Hardware List

Please check if all the pieces listed bellow are received


A		Ø8x30mm	Wooden dowel	10	pcs	H		Plastic wedge	4	pcs
B		Ø6x35mm	Cam bolt	10	pcs	I		Ø3x17mm Screw	4	pcs
C		Ø15x12mm	Cam lock	10	pcs	J		Ø4x30mm Screw	4	pcs
D		Ø6x50mm	Screw	4	pcs	CR			1	pcs
E			Handle	1	pcs	CL			1	pcs
F		Ø3.5x12mm	Screw	14	pcs	DL			1	pcs
G		4mm	Allen Key	1	pcs	DR			1	pcs



Philips head screwdriver required for assembly  
(not included)

*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

## Step 1



I. Using screw (F) secure slide rail CL to Panel (3) with screwdriver .

II. Using screw (F) secure slide rail CR to panel(4) with screwdriver .


F X6



Ø3.5x12mm




Wheel  
Facing Down




## Step 2

I. Secure cam bolt (B) into panel (3,4) with screwdriver as per diagram.

B X2





Ø6x35mm




### Step 3

I. Insert wooden dowel (A) into panel (5) as per diagram.


II. Attach (3,4) to panel (5), insert cam-lock (C) into the holes on Panel (5), then turn clockwise to lock onto cam-bolt.


A	X2	C	X2
			
Ø8x30mm		Ø15x12mm	



### Step 4

I. Secure cam bolt (B) into panel (1) with screwdriver as per diagram.



B	X4
	
Ø6x35mm	





## Step 5

I. Insert wooden dowel (A) into panel (1) as per diagram.


II. Attach (3,4) to panel (1), insert cam-lock (C) into the holes on Panel (3,4), then turn clockwise to lock onto cam-bolt.

A	X4	C	X4
			
Ø8x30mm		Ø15x12mm	



## Step 6




I. Place panel (6) as per diagram.




## Step 7

I. Insert wooden dowel (A) into panel (3,4) as per diagram.


II. Attach (2) to panel (3,4,6), using screw (D) attach panel (2) to panel (3,4) with allen key (G) as per diagram.



A	X4	D	X4	G	X1
					
Ø8x30mm		Ø6x50mm		4mm	





## Step 8

I. Using screw (I) attach plastic wedge (H) to panel (6) with screwdriver as per diagram.




H	X4	I	X4
			
		Ø3x17mm	






## Step 9

I. Secure cam bolt (B) into panel (7) with screwdriver as per diagram.

II. Using screw (F) secure handle (E) to panel (7) with screwdriver as per diagram.




B	X4
	
Ø6x35mm	
E	X1
	
F	X2
	
Ø3.5x12mm	

## Step 10



I. Using screw (F) secure slide rail DL (G) to panel (8) with screwdriver (M) ⚙️ghten.

II. Using screw (H) secure slide rail DR (G) to panel (9) with screwdriver (M) ⚙️ghten.


F	X6
	
Ø3.5x12mm	




Wheel Up



Wheel at the back





Wheel at the back








## Step 11

I. Attach panel(8,9)to panel(10),using screw (J) secure panel(8,9) to panel (10) with screwdriver as per diagram. II.Place panel(11) as per diagram.




## Step 12

I. Attach panel(7)to panel(8,9,10),insert cam-lock (C) into the designated holes,then turn clockwise to lock onto cam-bolt.




## Step 13

I.Place drawer as per diagram.



## Step 14



**Final Assembly**