





Outdoor Large Dog Cage





Model:P2508-LG



Scan the QR code to learn more about our product.



SPECIFICATIONS






CONTENTS

Specifications.....	1
Contact us.....	2
Important.....	3
Exploded views.....	4
Parts List.....	5
Screw Set.....	7
Instruction.....	8

CONTACT US

If you have any questions or concerns regarding our product, please don't hesitate to contact our customer service team at [service@outsofas.com]. We are committed to providing excellent service and ensuring your satisfaction.



Scan The Qr Code And Click The  Chat Button To Contact us.

Web:www.outsofas.com

E-mail:service@outsofas.com



IMPORTANT

Note: Please prepare below tools before installation.

The following tools are not included and needed for assembly:




Pistol Drill



Tape Measure


Package included Tools



Ratcheting wrench x1



Gloves x1 pair



Open-end wrench x2

Warning

We recommend two adults to complete the installation. Two adults installed together will make the installation process easier and safer.

The gloves must be carried to prevent hand cuts during installation.

Take care when using power tools near water the use of a residual current device (RCD) is advised.


Please use the electric driver carefully during screwing to prevent the screw from slipping and hurting your hand. (We recommend that beginners use a manual screwdriver for installation.)

Be careful not to fall when installing the roof. Please steady the ladder and make sure the product placed on a flat ground.

PLEASE KEEP THIS INSTRUCTION FOR FUTURE REFERENCE.










EXPLODED VIEWS
















PARTS LIST BOX A

<p>(B) × 6</p> 	<p>(C) × 1</p> 	<p>(E) × 4</p> 
Dog Cage Side Part 3	Small Door Side Part	Dog Cage Side Part 4
<p>(J) × 12</p> 	<p>(U) × 12</p> 	<p>(H1) × 2</p> 
Top Inclined Tube	Triangular Cross Brace	Vertical Long Link Rod
<p>(H2) × 4</p> 		
Vertical Short Link Rod		















PARTS LIST BOX B

<p>Ⓒ × 1</p> 	<p>Ⓐ1 × 1</p> 	<p>Ⓐ2 × 7</p> 
<p>Door Side Part</p>	<p>Dog Cage Side Part 1</p>	<p>Dog Cage Side Part 2</p>
<p>Ⓕ1 × 4</p> 	<p>Ⓕ2 × 1</p> 	<p>Ⓖ × 6</p> 
<p>Top Connecting Rod 1</p>	<p>Top Connecting Rod 2</p>	<p>Top Support Rod</p>
<p>Ⓕ1 × 8</p> 	<p>Ⓕ2 × 2</p> 	<p>Ⓖ × 1</p> 
<p>Diagonal Brace 1</p>	<p>Diagonal Brace 2</p>	<p>Top Cloth Cover</p>
<p>Ⓖ × 12</p> 	<p>ⒶⒶ × 1</p> 	
<p>Link Elbow</p>	<p>Screw Set</p>	



PARTS LIST (Screw Set)

<p>Ⓢ × 6</p>  <p>Bolt M6×15</p>	<p>Ⓚ × 184</p>  <p>Bolt M6×35</p>	<p>Ⓡ × 184</p>  <p>Washer Nut</p>	<p>Ⓣ × 43</p>  <p>Pull Cord</p>
<p>Ⓟ × 82</p>  <p>Adjustable Screws</p>	<p>Ⓛ × 12</p>  <p>Ground nails</p>	<p>Ⓞ × 1</p>  <p>Ratcheting Spanner</p>	<p>Ⓦ × 1</p>  <p>Spanner</p>
<p>Ⓥ × 2</p>  <p>Wrench</p>	<p>Ⓧ × 16</p>  <p>Hole Cover</p>	<p>Ⓨ × 1</p>  <p>Gloves</p>	<p>Ⓩ × 72</p>  <p>Plastic Cover</p>



WARNING: Failure to locate parts in accordance with these diagrams, or failure to use special parts provided with this equipment, may result in property damage or personal injury.




Step 1

Arrange the front mesh of the dog crate in the order of the corresponding labels in the picture below.


Note: The small door in (C) is below. Please note that the kennel door (D) has two threaded holes in the upper side cross tube and the holes need to be facing up.



A2 × 3





C × 1



D × 1

Step 2

Use two snap fasteners (P) front and back to align the holes in the two panel side rods, use a bolt (Q) to pass through and (R) to tighten on the other side.




Bolt M6x35

Q × 16



R × 16





P × 16




Step 3

Arrange the side nets of the dog crate in the order of the corresponding labels in the diagram below; this process needs to be done twice, with the left and right side panels of the crate placed in the same order.

Note: There are two through holes on the top side of both the side panels (B) and (E), so pay attention to the hole placement when installing.





(B) x 6



(E) x 4

Step 4

Use two snap fasteners (P) front and back to align the holes in the two panel side rods, use a bolt (Q) to pass through and (R) to tighten on the other side.




Bolt M6x35

(Q) x 32



(R) x 32







(P) x 32





Step 5

Use two snap fasteners (P) front and back to align the holes in the two panel side rods, use a bolt (Q) to pass through and (R) to tighten on the other side.
Note: There are two threaded holes in the top side cross tube of the panel (A1), the holes need to be facing up.



Step 6

Plug the holes, into the tubes on the grounded side of the panel, being careful not to plug the holes backwards, into all the holes on the lower side of the side tabs (Z).





Z x 40



Step 7

Combine the side piece installed in step 1 with the side piece installed in step 3, and tighten the bolts (Q) and (R) using the bolts (Q) and (R) after aligning the (E) side holes parallel to the upper side holes in (C) using the snap fasteners (P). The lower side is installed following the same procedure.




Bolt M6x35

Q × 4





R × 4



P × 4

Step 8

Combine the side piece installed in step 1 with the side piece installed in step 3, and tighten the bolts (Q) and (R) using the bolts (Q) and (R) after aligning the (E) side holes parallel to the upper side holes in (A2) using the snap fasteners (P). The lower side is installed following the same procedure.




Bolt M6x35


Q × 4



R × 4





P × 4




Step 9

Install the three pieces installed in step 5 on the inside of (E) according to the same procedure, note that the one connected to (E) is (A2), and then take another piece (A2) and install it on the inside of the other side (E) according to the same procedure.

Note: (A1) should be in the center of the back side, and the two threaded holes in the upper cross tube should face up.




A2 × 1



Q × 8



R × 8




P × 8

Bolt M6×35

Step 10



The following picture shows the distribution of each part on the top of the dog cage, please check it many times during installation to prevent installation errors.





Step 11

Insert bends (M) into the upper side holes of both side panels, as shown below, in the upper side holes of (E) and (B), with 10 tubes on the upper side, and insert (M) into the upper side holes of the six tubes, 1, 3, 5, 6, 8, and 10, and align them with the holes.





(M) × 12

Step 12

After inserting the elbow (M) in line with the vacant position, tighten it with a bolt (Q) and a nut (R).

Note: Bolts should be threaded into the installation from the outside in.



Bolt M6×35

(Q) × 12





(R) × 12





Step 13


Insert one end of (J) into (M) to align the holes.
Note: Plug in the parts first, do not bolt on.



Step 14



Consistent with the previous step, install all the rest (J) onto (M).





Step 15



Install the pipe jacking (N) to both sides (J), insert the pipe jacking into the two sides (M) pipes, and align the empty positions.



(N) × 1

Step 16

Repeat the previous step to install all the remaining five (N).




(N) × 5










Step 17

According to step 10, the (K1) (K2) (H1) (H2) that needs to be installed is placed in order, and there are five kinds of screw installation methods in the following figure, which are marked with the corresponding label to enlarge the drawing, and are used with (Q) and (R) together.

Note: The bolts at both ends of the roof are installed from the outside to the inside, and the nuts are on the inside of the dog cage.





 (F1) × 4	 (F2) × 1	 (Q) × 48 Bolt M6×35
 (K1) × 8	 (K2) × 2	 (R) × 48





Step 18


Install (H1) under the front and rear push rods, use (H1) to insert it into the vertical direction of (N), align the holes, and screw in (Q) and (R).



Step 19



(H1) The lower lug hole is aligned with the upper side hole of the lower panel, and screwed in with a bolt (S).
Note: Please do not tighten the bolts.






Step 20

(H2) is set in the middle four (N) vertical lower rods in the manner consistent with step 18 and is fixed with bolts (Q) and (R).
Note: Please do not tighten the bolts.



(H2) × 4



(Q) × 4





(R) × 4

Bolt M6×35


Step 21

As shown in the figure below, (U) is installed between (H1), (H2) and (J), and after aligning the holes, the bolt (Q) and nut (R) are used.

Note: Tighten all dog cage top bolts at this time.



(U) × 12



(Q) × 24





(R) × 24

Bolt M6×35





Step 22 Install (A2) in the remaining position of the side panel.



(A2) × 1

Step 23 Using the metal sheet (P) and bolts (Q), (R), install the (A2) that you just placed with the other two pieces.




Bolt M6×35

(Q) × 8



(R) × 8





(P) × 8



Step 24

After installing the frame, observe the excess holes at the top, the rest of the holes are free of plastic plugs, and install (Z) and (X) to the excess holes.



(Z) × 28





(X) × 16

Step 25

Unfold the cloth cover and fasten it to the top of the dog cage, tightening it.

Note: Do not pull the canopy too hard.





(G) × 1




Step 26


Once the tarp is taut, use (T) to mount the cloth top on top of the dog cage.



Step 27

The ground nails are installed on the transverse pipe under the side panel, and three ground nails are installed on one side, respectively in the first, third and fifth pieces.





Scan the QR code to learn more about our product.