




Product Installation Instructions







Ax1




Bx2




Cx1




Dx1




Ex1




Fx2




Gx1




Hx1




Ix2




Jx1




Kx3



Lx1

















Mx2










1


Accessories list

①		Two In One Screw (6x28mm)	38pcs +3pcs
②		Two In One Nut (10x12mm)	38pcs +3pcs
③		Wood Chipping (6x30mm)	28pcs +3pcs
④		Non-slip pads	4pcs
⑤		Door Magnet & Screw (3.5x12mm)	4pcs +1pcs 2pcs
⑥		Wire Clamp	2pcs +1pcs
⑦		Fixing clip & screw (3x16mm)	10pcs +6pcs
⑧		Foot nail	6pcs +4pcs
⑨		Handle & screw (4x16mm)	4pcs +2pcs 2pcs
⑩		Iron sheet & Screw (3x10mm)	8pcs +2pcs 4pcs
⑪		Cabinet Door Hinge & Screw (3.5x12mm)	16pcs +2pcs 4pcs
		AC/DC Adapter (12V=3.0A)	1pcs
⑫	<div> <div>Anti Fall Hardware</div> <div>  </div> </div> <div> <div>1pcs</div>  <div>Double-head screwdriver, use as required</div> <div>2</div> </div>		

Product structure decomposition




①		22pcs	③		12pcs	⑤	 2pcs	 4pcs
②		22pcs	④		4pcs			




Use parts ① and ②



Step1




Step2



Step3






Use a screwdriver to lock in the direction of the "+" sign



Disassemble along the direction of "-" sign

Step 1




5

Step 2

2



x2



Step 3


5



x1





x2




6

Step 4



Step 5




Step 6

2



x4




Step 7



3




x4




Step 8




Step 9



Step 10




4



x4

Tear off release paper and stick the black foot pad on the board

Step 11




3




x4

10




Step 12





Fx2










Step 13




Step 14




1		16pcs	3		16pcs	7		10pcs
2		16pcs	6		2pcs	8		6pcs





Step 15





Step 16




Step 17




Step 18





Step 19


②  x4



Step 20

①  x4

③  x4




Step 21




2






x4




Step 22




Step 23




Step 24



Kx3




Step 25






2 x4

Step 26







20


Step 27




Step 28
















Step 29









Use a hammer to drive the nail into the gap of the wooden board and fix the back board




9	 2pcs	 4pcs	11	 4pcs	 16pcs	12	 x2
10	 4pcs	 8pcs		 1pcs		 x2	 x2
						 x2	 x4




Step 30


9		
	x1	x2
10		
	x2	x4
11		
	x2	x4




Step 31




9		
	x1	x2
10		
	x2	x4
11		
	x2	x4




Step 32

11  x8




Step 33




If there is a large gap after the installation of the door, please twist the screw of the door hinge back halfway and move the door left and right.

Step 34









x1



Step 35

Install as required




User's Guide

Thank you for purchasing this product. To use this product, please plug it into a 12V DC power supply. Please use if the product works normally after connecting to power.

Introduction

The box is an intelligent controller with 2 touch buttons. It can turn ON/OFF the light, change light colors, and adjust the light luminance.

Product Show



ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.

Operation



This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off. B. Long touch -> adjust the luminance



This touch button is used to turn on/off the induction function.

- A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 4 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.
- B. Long touch to turn off the induction function.
- C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.