

# 6 Leg Full-Queen-King Bed Frame



**1.** Remove the two sides of the frame and lay them on their side. They are not side specific or end specific.

**2.** Swing the cross arms open as shown. Lay the frame open as shown.



**3.** Insert the rivets into the appropriate set of keyhole slots for the size bed you have. The set closest to the leg is the Full/Double setting, middle is Queen and the closest to the end is for King. Put the head of the rivet through the round hole and pull the rails in the opposite direction so the rivet slides into the narrow part of the keyhole. Do not be concerned if the frame does not stay fully locked out at this point. They will lock in place with the center bar.

# 6 Leg Full-Queen-King Bed Frame

**4.** Take the centerbar out of the box that is 59" long. If you are using the



King or Full/Double size setting, the center bar will run head to toe.

Use the nuts and bolts provided to secure them as pictured using the hex key wrench and box wrench that are provided. The center bar goes under the angle cross arms as pictured.

For Queen, the center bar can be installed either head to toe, or side to side. If you have a split foundation, you should install it head to toe.

Using it head to toe increases bed storage and eliminates any chance of hitting your foot on it. If you install the bar side to side, you will have two extra nuts and bolts.

These go into the holes that line up on the cross bars at the head end and foot end. If you installed the center bar head to toe, you will not need these, as the center bar will lock the two rails together.



**5.** Now, put the glides/ feet on all 6 legs. You will have 4 black glides and 2 grey glides.

The black glides go on the corners and the grey glides go on the center bar. You will then need to find the 6 black saucer discs. Put these under each glide and push down so they snap onto the bottom of the glide. At this point, the frame should look like this depending on the center bar placement.



**6.** Install the black angle end caps on the ends of the side rails. If you are attaching to a headboard, you will only need them on the foot end. Either end can be the head or foot end

# 6 Leg Full-Queen-King Bed Frame

**7.** If you are using a headboard, find the headboard mounting brackets. They can be used as either left or right. Pick a set of the round holes that look like the right height for the headboard mounting holes. Loosely attach the brackets to the frame and see if you have selected the proper holes. Once you have selected the proper holes, tighten the brackets. The brackets can be turned in or out, or one can be turned in and one out. Whatever configuration you need to securely attach the headboard. If you have any difficulty, please email us and we will respond quickly. You can then mount the headboard using the hardware provided.



**8.** If you do not have a headboard, you should have black end caps on all 4 corners. When you put the foundation or box spring on the frame, center it over the frame. This should leave you with a 5" overhang on the head and foot end on a Queen or King and 2 1/2" overhang on Full.