


Assembly Instructions




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




- VI. A Phillips head screwdriver is required for the assembly of this product.












- VII. Power tools should not be used to assemble this product.








Parts List




Hardware List

A		Ø8,0 x 30mm	Wood Dowel	78x
B		Ø4,0 x 40mm	Screw	24x
C		Ø4,0 x 30mm	Screw	70x
D		Ø14 x 14mm	Cam Lock	6x
E		Ø3,0 x 12mm	Screw	12x
F		96 x 40mm	Puller	6x
G		Ø8,0 x 40mm	Wood Dowel	6x
H		Ø10 x 10mm	Nail	40x
I		Ø5,5 x 28mm	Screw	6x

J			Ribbon	1x
K			Washer	2x
L		Ø3,5 x 14mm	Screw	1x
M				1x




Philips head screwdriver required for assembly
(not included)




The hardware quantities listed above are required for proper assembly
Some extra hardware may also have been included


Step 1 Insert wood dowel A (x66) into parts (1),(4),(5),(6),(7),(9),(12),(13), (15),(16).




Step 2 Insert Cam Lock I (x6) into parts (2),(3).




Step 3 Insert screw B (x8) C (12) into parts (2),(3),(9),(6),(8).




Step 4 Insert screw C (x3) into parts (9).




Step 5 Insert screw B (x2) C (x3) into parts (4),(1).




Step 6 Insert screw B (x3) Cam lock D (x3) into parts (2),(1).




Step 7 Insert screw B (x4), C (x2) into parts (5),(7).







Step 8 Insert screw B (x3), C (X2) Cam lock D (x3) into parts (3).



Step 9 Insert screw B (x4) into parts (6).




J		1x
K		2x
L	 Ø3,5 x 14mm	1x




**Attach part (J) with Screw (L) and Washer (K)
inside of superior panel unit.**


Step 10 Let the Ribbon (J) to outside and Insert Nail H (x40) into parts (17).



Step 11 Insert screw C (x16) into parts (12),(13),(14).



Step 12 Insert screw C (x32) into parts (15),(16),(14).




Step 13

WARNING



Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.





With drilling machine make one hole in the wall, Insert part (M) in the hole.

Secure part (K) with Screw (D) and Washer (L), in the wall.



CHECK FOR HIDDEN PIPES AND CABLES BEFORE DRILLING

Step 15 Use screw E (x12) to attach Puller F (x6) to the drawers.



Final Assembly