



ASSEMBLY INSTRUCTION



VIP Service68@outlook.com

Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware, If Parts are missing defective or having wrong parts in package, or Board Surface is broken, scratched or lack of some screw holes. You can contact us and we will get back to you within 24 hours. Or, you can reach us via after-sales email.
- ✓ Give yourself enough room for the assembly process
- ✓ Caution: If using a power drill or power screwdriver for screwing, please pay attention to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: 2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Do not make the screws too loose or too tight.
- The accessory bag contains some small accessories, which should be kept away from children.
- The remaining parts are spare parts.
- Do NOT use harsh chemicals or abrasive cleaners on this item. And Never push, pull, or drag your furniture.
- Young children can be seriously injured by tipping furniture. You must install the tipping restraint hardware with the unit (K#Accessories) to prevent the unit from tipping, causing any accidents or damage. the tipping restraints are intended only as a deterrent, they are not a substitute for proper adult supervision.



Product Installation Video


Please scan this QR code with your cell phone YouTube to watch the installation video instantly.













Contact Us

When missing parts? Or feeling stuck? you can contact us by scanning the QR code below or via after-sales email (VIPService68@outlook.com), we will reply you in time.








1 x1  m	2 x1  m	3 x1  m
4 x1  786x287x12mm	2 x 5  666x262x12mm	1 x 6  107x262x12mm
7 x4  m	8 x1  m	9 x1  m
10 x1  786x120x36mm		



12

16

Hardware


A x38 +1(spare)  Ø6x32mm	B x38 +1(spare)  	C x42 +2(spare)  Ø6x30mm	D x12 +1(spare)  Ø4x16mm	E x2  	F x12 +1(spare)  M5x40mm
G x2  	H x2  Ø8x38mm	I x2  M4x45mm	J x2  Ø3.5x12mm	K x1  	L x1  M3
M x6  Ø20mm					

How the knock down assembly system works




How to Install Wood Dowel





Insert the wood dowel [C] at least half way by tapping lightly with a rubber mallet, IF NECESSARY.




CAM LOCK SYSTEM OPERATION




1. Screw the cam bolt [A] into the threaded insert on the panel.
2. Connect both panels together making sure cam bolt [A] goes into the pre-drilled large hole on the end of panel for cam lock [B].
3. Insert the cam lock [B] into the pre-drilled large hole on the panel. Make sure the cross slot of cam lock [B] faces out (The arrow should point towards Screw No. A).
4. Rotate the cam lock [B] clockwise with a self-supplied phillips screwdriver to lock the cam bolt [A] in place (Rotate 100-180 degrees until tight).



STEP1




Tighten the screw into the holes as guided by the dotted lines.



A	x38
	
Ø6x32mm	


STEP2

Note that when installing Plate No. 7, it must be mounted symmetrically left and right; do not install it in the same direction.




STEP3

These holes are all outside.




STEP4




C	x2
	
Ø6x30mm	
F	x6
	
M5x40mm	

STEP5




B	x2
	
C	x2
	
Ø6x30mm	

STEP6




B	x6
	

STEP7




C	x8
	
Ø6x30mm	

STEP8




F	x3
	
M5x40mm	
B	x6
	

STEP9




J	x2
	
Ø3.5x12mm	
G	x2
	
C	x8
	
Ø6x30mm	


STEP10




B	x6
	
F	x3
	
M5x40mm	

STEP11




D	x12
	
Ø4x16mm	
E	x2
	

STEP12





C	x10
	
Ø6x30mm	


STEP13



B	x10
	

STEP14



M	x6
	
Ø20mm	
I	x2
	
M4x45mm	
H	x2
	
Ø8x38mm	

Care Instructions



Your furniture, if treated with respect and love, will last you a long time. Each piece requires light maintenance to maximize its longevity.

Few quick tips before using this product

1. Top panel weight capacity: 100 lbs
2. Check and tighten the camlock and screw periodically as it may loose over the time.

How to take care of it?

1. Avoid direct sunlight or use curtains or blinds to limit the sun exposure to the product.
2. Clean the product regularly with a dry, soft cloth.
3. Avoid using abrasive or liquid cleanser.
4. Avoid placing hot objects onto the table top surface.
5. Spillage may damage the surface. Clean immediately with a dry cloth.
6. We recommend using placemats or coasters underneath glasses, cups, bowls or plates to prevent scratches to the table surface.

Frequently Asked Questions



For any enquiries or issues regarding your purchase, chat with us at VIPService68@outlook.com

1. What should I do if my order is incomplete?

Our products ship flat-packed in separate boxes. When your order leaves via FedEx, you'll get an email with tracking details. Keep in mind that FedEx may deliver your boxes separately, so wait until you have them all before you start assembling. If you need help tracking your delivery, please visit aftersaleservice.net or email vipservice68@outlook.com.

2. What should I do if my shipment is damaged or items are defective?

We're really sorry if you received a damaged or defective item. Please email us at vipservice68@outlook.com or chat with us at aftersaleservice.net. Send a description and some photos or videos of the damage, and we'll sort it out as quickly as possible.

3. Can I order replacement parts?

Yes! Just get in touch with our customer service at vipservice68@outlook.com or via chat at aftersaleservice.net. Tell us your order ID, and we'll help you with the parts you need.1

4. What warranty do you offer?

Our warranty covers damage that isn't caused by user error. If your product is damaged for these reasons, keep it and send us some photos at vipservice68@outlook.com. We'll review the damage within 24 hours and work for you to find a solution.

5. Why does the new furniture have an odor?

A slight smell is normal with new furniture due to the materials and packaging. It should fade away after a few days of airing out.

6. Why is there a slight color difference in my furniture?

The color may appear different under varying lighting conditions and display settings. In dim lighting, the wood grain may look darker. This is completely normal and just part of the natural characteristics of the material.

7. My furniture seems smaller than expected. What should I do?

Our product dimensions are accurate. Pictures often focus closely on the item, which can make it appear larger than it really is. When placed in a bigger room, the furniture might seem smaller. Room layout and screen settings can also affect your perception of size. If you have any concerns or need more details, please contact our customer service at aftersaleservice.net or email vipservice68@outlook.com. We're here to help!

8. What should I do if I want to return the product?

We offer a 30-day return policy from when you receive your order. To start a return, please contact us through Amazon, email vipservice68@outlook.com, or visit aftersaleservice.net. Just let us know why you're returning the item, and we'll help you out.

WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.



*This is a permanent label.
Do not remove!*