

# CONTENTS

Safety and care advice	1
Components – panels	2
Components – fittings	3
Assembly	4
Copyright	10

# $\triangle$ SAFETY AND CARE ADVICE $\triangle$

#### PLEASE READ THESE INSTRUCTIONS CAREFULLY AND KEEP FOR FUTURE REFERENCE

- Warning: This unit weighs approximately10kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers *for inserting screws*, as this could damage the unit. Only use hand screwdrivers.
- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings.
- Dispose of all packaging carefully and responsibly.


# **CARE AND MAINTENANCE**

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

•This product should not be discarded with household waste. Take to your local authority waste disposal center.

**Note** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference. Please check you have all the panels listed below:



1	Top Panel, 1000x398x15	x1	4	Back Panel, 955x320x15	x1
2	Left Side Panel, 366x320x15	x1	5	Front Panel, 955x320x15	x1
3	Right Side Panel, 366x320x15	x1	6	Bottom Panel, 1000x400x15	x1

# **COMPONENTS** — **FITTINGS**

Please check you have all the fittings listed below:



Metal Dowel (M6x34) x 14



Lock (M15x12) x 14



Hinge x 3




Screw (M3.5x14) x 44




Gas Lift x 2





Block x 4




)












Customer Attention:


To align doors & control gaps in between doors. Product doors may need adjusting during & after assembly or once wardrobe contains clothing. This can be done by adjusting appropriate screws. See illustrations below.






Vertical Door Adjustment:

Loose both screws on all hinges and lift the door to desired height. This allows an even space at the top and bottom between door and wardrobe frame.






Lateral Door Adjustment:

If door is hinge bound (rubbing on frame as you clode or open door), loose screw shown and move the door in appropriate direction.





Horizontal Door Adjustment: Rotate Screw clockwise or counterclockwise. This will produce an even gap between doors and frame.



Congratulations! Now you have finished assembling the product. There may be some dust or hand marks on your item, we recommend using a standard wood polish to clean this product.