




10'x14'Metal Patio Gazebo

ASSEMBLY MANUAL



MODEL#: LGMF1668

Missing part? Damaged? Contact us via email at

service@domioutdoorliving.com

www.domioutdoorliving.com

Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

Warning & Attention




-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;



-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



IMPORTANT: A gaze may entail to purchase a municipal permit or be subject to specific building codes. It is the consumer's responsibility to inform themselves of any restrictions.




1



If the deck is hard wood and the depth of it is over 3 inch, you can use **5/16 in. x4 in. Structural Wood Screw** to mount the gazebo.







2




If the ground is concreted and the depth of it is over 3 inch, you can use 1/4 inch expansion bolts to mount the gazebo






































3



Or you can make a concrete footing for gazebo, **15×15×15 inches** is recommended. use expansion bolts to mount the pergola like ② shows.


IMPORTANT:
Anchor is not recommended





 <p>Pole 2080 A (x4)</p>		 <p>Bracket K2 (x8)</p>	
 <p>Beam 2015 B (x2)</p>		 <p>Corner Roof Tube Connector 565 L (x4)</p>	
 <p>Beam 2015 B1 (x2)</p>		 <p>Corner Roof Tube 1775 L1 (x4)</p>	
 <p>Beam 1390 B2 (x2)</p>		 <p>Roof Bar 1566 M (x4)</p>	
 <p>Beam 1390 B3 (x2)</p>		 <p>Finishing Bar 573 N (x2)</p>	
 <p>Track 1883 C (x2)</p>		 <p>Finishing Bar 1823 N1 (x2)</p>	
 <p>Track 1883 C1 (x2)</p>		 <p>Finishing Bar 853 O1 (x2)</p>	
 <p>Track 1258 C2 (x2)</p>		 <p>Finishing Bar 2103 O2 (x2)</p>	
 <p>Track 1258 C3 (x2)</p>		 <p>Mesh P (x1)</p>	
 <p>Outside Roof Cover 1515 D (x1)</p>		 <p>Plastic Bar Pa (x2)</p>	
 <p>Inside Roof Cover 1439 D1 (x1)</p>		 <p>Plastic Bar Pb (x2)</p>	
 <p>Union Bar 600 E (x4)</p>	 <p>Corner Cover F (x4)</p>	 <p>Finishing End Q (x8)</p>	 <p>Hooks R1 (x3)</p>
 <p>Joint Cover G (x4)</p>	 <p>Silicone Sealant H (x1)</p>	 <p>Black Rubber S (x116)</p>	
 <p>Corner Solidifying Bar 578 J1 (x4)</p>		 <p>Solidfying Bar 849 U1 (x4)</p>	
 <p>Corner Solidifying Bar 578 J2 (x4)</p>		 <p>Solidfying Bar 1474 U2 (x4)</p>	
 <p>Base K (x4)</p>	 <p>Base Cover K1 (x4)</p>	 <p>Bracket U3 (x4)</p>	 <p>Bracket U4 (x4)</p>

Mosquito Netting		Mosquito Netting		Strap		Solid Sidewall			
Solid Sidewall		Plastic Bracket		Plastic Bracket		Plastic Bracket			





POST ASSEMBLY:






(1) Put on Base Cover
#K1 first;


(2) Attach Base #K to
Pole #A with 3 Bolts
#1.






(1) Slide the Plastic Hooks #4 to the double-rail track #C (each slot should slide 8 plastic hooks).



(2) Repeat the above procedures for the another track C.



(1) Slide the Plastic Hooks #4 to the double-rail track #C1 (each slot should slide 8 plastic hooks).


(2) Repeat the above procedures for the another track C1.






(1) Slide the Plastic Hooks #4 to the double-rail track #C2 (each slot should slide 6 plastic hooks).



(2) Repeat the above procedures for the another track C2.




(1) Slide the Plastic Hooks #4 to the double-rail track #C3 (each slot should slide 6 plastic hooks).

(2) Repeat the above procedures for the another track C3.






BEAM ASSEMBLY



- (1) Insert Part #E into Part #B1, and secure with 4 Bolts #1.
- (2) Insert the other side of Part #E into Part #B and secure with 4 Bolts #1.



Repeat the above procedures to assemble the other Part #B1 and #B.






TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H) and Joint Cover #G to affix the gap.(see P13)

1#
x16

(1) Use 8 Bolts #1 to fix the track C & C1 to the beam B1 & B.
Repeat the above procedures for another beam B1 & B.




X2




- (1) Insert Part #E into Part #B3, and secure with 4 Bolts #1.
- (2) Insert the other side of Part #E into Part #B2 and secure with 4 Bolts #1.


Repeat the above procedures to assemble the other Part #B3 and B2.

TIPS: It's a normal situation that there's a gap between the 2 beams, please use silicone sealant (part #H) and Joint Cover #G to affix the gap.(see P13)




(1) Use 8 Bolts #1 to fix the track C2 & C3 to the beam B3 & B2.
Repeat the above procedures for another beam B3 & B2.






3#
x16

FRAME ASSEMBLY:




Please don't tighten
all bolts.




Outside View




2#
x16



Please don't tighten
all bolts.





Inside View



Inside View

CORNER SOLIDIFYING
BAR ASSEMBLY:



Outside View







F (x4)






9#
x16

CORNER COVER & JOINT COVER ASSEMBLY:





Use 5mm silicone sealant (part #H) and Joint Cover #G to affix the gap.






L (x4)




L1 (x4)




2#
x8

CORNER ROOF TUBE ASSEMBLY:





(1) Connect Part #L1 and Part #L with 2 Bolts #2.
Repeat the above procedures to assemble the
other 3 Corner Roof Bars.




D1 (x1)

CORNER ROOF TUBE AND INSIDE ROOF CONNECTOR ASSEMBLY:






Place 4 Corner Roof Tubes on the 4 corners of Inside Roof Cover #D1, secure with 8 Bolts #1 (from bottom to top).




Lift 4 corner roof Tubes and inside roof connector to the top of the frame.(You may need 2 people and 2 ladder).




1#
×4

Inside View





M (x4)





1#
x12

MIDDLE ROOF TUBE ASSEMBLY:

(1) Place Middle Roof Tube #M on Inside Roof Connector ,secure with Bolt #1 (from bottom to top).


(1) Connect Middle Roof Tube #M and the Assembled Beam with 2 Bolts #1.

Repeat the above procedures to assemble the other sides.




Inside View


Check the the frame as pictures below shows.




Frames in Parallelogram shape




Frames in rectangular shape



P (x1)






Pa (x2)




Pb (x2)

PLASTIC BAR ASSEMBLY :





D (x1)




P (x1)






R1 (x3)

OUTSIDE ROOF COVER AND MESH ASSEMBLY :

- (1) Place the Outside Roof Cover #D on the inside Roof Cover.
- (2) Align the holes, and use 3 Hooks #R1 to secure Mesh #P to the inside Roof Cover (From Bottom to Top).











1#
x4



11#
x4






Please do not pull plastic bar out when installing it with #N, N1 on the middle roof tube.






1#
x4





11#
x4



Plastic Bar
on the mesh




FINISHING END #Q ASSEMBLY:




■ Plastic Bar on the mesh








■ #N/N1







N1

Q







Section View





Attach Part #Z, #Z1 & #Z2 by lightly tapping with screwdriver.



SMALL ROOF PANEL AND FINISHING BAR ASSEMBLY:



If you can't install #V4, push the Outside Roof Cover up and try to insert them again.



U1 (x4)


U2 (x4)

U3 (x4)


U4 (x4)







1#
x24

SOLIDIFYING BAR ASSEMBLY:




Inside View












Attach Part #Z, #Z1 & #Z2 by lightly tapping with screwdriver.







Install the Middle Panels (#X4 ,X5 or #W3,W4) first, then the small panels on the edge.



The Black Rubber #S should be assembled when installing the roof panels; please see the next page.




The Black Rubber #S should be inserted between roof panels and solidifying bars or beams, then secure with bolts and nuts.




S x4




10#
x4




Solidifying Bar

Middle Roof Tube






Middle Roof Tube






S x32

7#
x32



Solidifying Bar










④

Beam





5#

5#






MOSQUITO NETTING AND SOLID SIDEWALL ASSEMBLY:





Please close your gazebo curtain when it is incoming over 30 mph wind, and tie with Strap #Yb.



Y1/Y2


Y1a/Y2a

Y1a/Y2a



Y1/Y2

Y1a/Y2a



Yb



Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So, if you have any questions about our product or assembly, please feel free to contact us. We are here for you.

Support:  

After-sales contact email:

service@domioutdoorliving.com

Business cooperation contact email:

marketing@domioutdoorliving.com

Please have your order ID available if you reach out for support.

If you have damaged parts or product, please send us photos for an immediate response.