


Installation Instruction



Assembling


Estimated time for assembly



45 : 00

What you need

- Use the packaging carton as a working surface to prevent product damage during assembly
- Phillips head screwdriver



Weight Limitation




100

lbs table top

| 35

lbs per




What' included


Code	Description	Qty
A	Cam Bolt M6X35MM	49
B	Cam Lock 15X9MM	49
C	Wooden Dowel M6X30MM	40
D	Screw M4X40MM	17
E	Screw M6X40MM	4
F	Left regulator	1
G	Right regulator	1
H	Screw M3.0X12MM	8
I	Foot nail	8
J	Big bend hinge	3
K	Cam Bolt M4X20MM	2
L	Metal shake handhandle	1
M	Wrench M4X55MM	1
N	Hole position sticker	49
O	Screw M3.5X12MM	38
CL	Left mother extended orbit	1
CR	Right mother extended orbit	1
DL	Left public extension track	1
DR	Right public extends track	1

The Hardwares

(A)




(B)



(C)




(D)




(E)



(F)



(G)



(H)



(I)



(J)



(K)




(L)



(M)




(N)




(O)




(CL)




(CR)



(DL)



(DR)




IMPORTANT:

1. Do not tighten bolts / screws completely until all bolts / screws are lined up and inserted into holes.
2. Do not over tighten screws and bolts to avoid stripping
3. Please use hand tools to assemble this product. Do not use power tools.


Included Accessories


Code	Description	Qty
1	Left panel	1
2	Right panel	1
3	Left Side Panel	1
4	Right Side Panel	1
5	Noodles with soy sauce	1
6	Drawer left panel	1
7	Drawer right side panel	1
8	The drawer bottom	1
9	After the drawer board	1
10	Reinforcing strip	1
11	Left bottom plate	1
12	Right bottom plate	1
13	Left trim	1
14	Right trim	1
15	Front trim	1
16	Laminate	1
17	Neutral plate	1
18	Back brace	1
19	Rail slide	2
20	Stand on both sides	2
21	Fore and aft standing	2


The Accessoriess




Step 1


A	x 8
	


C	x 4
	




Step 2


E	x 4
	


M	x 1
	





Step 3


H	x 4
	

CL	x 1
	

CR	x 1
	





CR





This is the small screw H








Step 4

A	x 7
	









C	x 2
	



Step 5



Step 6













Board No. 3 The long side of board No. 17 has a perforated end facing forward

Step 7








The long side of board 4 has a perforated end facing forward





Step 8










Board 18 has the long edge of the banding strip facing up













Step 9




Step 10



Step 11










Step 12




Step 13





Board 11 with the countersunk side facing up






Step 14





Step 15



Step 16









Step 17









Step 18




Board 20 21 has the long edge of the seal facing up












Step 19













Step 20



Step 21




Step 22







This is the small screw H

Step 23




Step 24


O	x 8	F	x 1	G	x 1
					




This is the big screw O


Step 25




O	x 12
	

Step 26




O	x 6
	








J	x 3
	

 This is the big screw O

Step 27



This is the big screw O



Two people work together to move the table.
Make sure you lift it off the ground.
Don't push and pull.