


# INSTRUCTION MANUAL



We offer a diverse range of products to meet the needs of customers.





## WARNING

Ensure that all parts  
and hardware are  
available before  
beginning assembly.

# TOOLS REQUIRED



ALLEN WRENCH  
(PROVIDED)



1 PERSON ASSEMBLY




UP TO 40 MIN. ASSEMBLY

## NOTICE

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and knobs before use.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.


## PARTS

**D** Side Board




4PCS

**E** Armless Back




2PCS

**F** Armless Seat




2PCS

**J** Tea Table Top




1PCS

**K** Tea Side Board






2PCS

**L** Tea Side Board





2PCS

## PARTS




## HARDWARE

Do not tighten the screws until you are fully installed, and then tighten them after all installations are complete.




# I PART LIST


- 1** As shown in the figure, attach part F chair seat to part E chair backrest, then combine the two D parts



**2**




**3**




# PRODUCT ASSEMBLY-CORNER CHAIR

Note: Dear customer, if you did not purchase the table, it will not be included in the package.


- 1 Connect the "K" and "L" with screws as shown, then put tabletop "J" and glass "M" on it.



2




3



# HELP CENTER


Question about your product? We're here to help. Visit us at:



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

## We Stand Behind the Quality of Their Furniture

If you have any issues with your item please let us know! We will always do our best to come up with a solution that you will be happy with.

Please get in touch with our customer service team before returning the product.

And pls do not throw the original box(es) if you have not finished assembling or confirmed no quality issues.

Length of return period:

Items can be returned within 30 days of purchase.

In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

1. Your item has a manufacturing defect in its materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after photos are sent.
2. Your item has been damaged in transit. For example, glass is broken or wicker is damaged. We will send you a prepaid shipping label after photos are sent.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after photos are sent of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

\*However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

1. You don't like the product(s) after receiving the box(es).
2. You no longer need the product(s) but you have received the box(es).
3. You buy the product(s) by mistake but you have received the box(es).
4. Order/Shipment cancellation failed and you have received the box(es).