



User Guide



BOUNCE HOUSE

Dimensions: 6.25' x 6'

Model: BH66OR

**Got a Problem building your Bounce house?
Call us at 1-877-927-8777 and we can help**



WARNING: Read these assembly instructions carefully before attempting to assemble or use this product. Keep this user guide in a safe place for future reference.

IMPORTANT INFORMATION

- **ADULT SUPERVISION REQUIRED AT ALL TIMES.**
- The Bounce house must not be used by people weighing more than 40Kgs (90lbs). Maximum user height - 120cm.
- Recommended age 3+ years.
- The Bounce house is for outdoor domestic use only.
- **WARNING!** Keep away from fire.
- This product must be inflated before use. Inflation time is approximately 25 to 28 seconds. Blower must be on for duration of use.

IMPORTANT PRECAUTIONS



Do not land on your head or neck.

Paralysis or death can result, even if you land in the middle of the jumping surface.

To reduce the chance of landing on your head or neck, do not do somersaults (flips).

Avoid bouncing when tired.



The Bounce house should not be used by more than one user at the same time.

Not recommended for use by children under 3 years.

Multiple jumpers increase the chances of loss of control, collision and falling off. This can result in serious injury to head, leg or neck.

IMPORTANT PRECAUTIONS

⚠️ WARNING:

To reduce the risk of serious injury or death, read the following important precautions before using the Bounce House.

1. Read this manual carefully before using the bounce house. The owner of the Bounce house is responsible for making all users aware of the information in this manual.
2. The Bounce house is intended for home use only. Do not use the Bounce house in a commercial, rental, or institutional setting.
3. The Bounce house must not be set up or used in gusty or severe winds. Wind or air movement must be calm to gentle.
4. The Bounce house is for outdoor use only. Place the Bounce house on a level, smooth, soft surface such as grass. Do not use the Bounce house on a hard surface. Position the Bounce house as close as possible to a power source; do not use an extension cord.
5. Make sure that there is adequate clearance above and around the Bounce house. There must be no wires, tree limbs, walls, structures, fences, or other possible hazards near the Bounce house.
6. The materials used in the Bounce house are not fire retardant and may burn if exposed to flames. Keep the Bounce house away from flames and high heat sources.
7. Do not use the Bounce house unless it and the blower are properly anchored to the ground with the provided stakes. Wear proper eye protection while driving in the stakes. Make sure that the tops of the stakes are at ground level so they will not create a tripping hazard. In addition, cover the tops of the stakes, if necessary, so users will not be injured by falling onto the stakes.
8. Inspect the Bounce house, the power cord, and all other components before each use. If damage is found, do not use the Bounce house until it has been properly repaired.
9. The Bounce house should not be used by children under 3 years old. Children must always be supervised by adults while using the Bounce house.
10. The Bounce house should not be used by person weighing more than 90 pounds (40 kgs).
11. Maximum user height - 120cm (3.94ft).
12. Before entering the Bounce house, remove shoes, eyeglasses, and sharp or breakable objects. In addition, remove jewelry or other objects that could get caught on the netting.
13. Climb head first into the Bounce house. Crawl feet first out of the Bounce house. Do not jump onto the Bounce house or off it. Do not use the Bounce house as a springboard to other objects.
14. Do not attempt or allow somersaults. Doing so can result in a broken head, neck, back, or leg. Landing on the head or neck can cause serious injury, paralysis, or death.
15. The Bounce house uses a mains powered fan to maintain pressure. Only to be used by competent adult.
16. Do not jump against or pull down on the sides or corners of the Bounce house from the inside or the outside. Do not stand on the Bounce house while you are outside of it.
17. Misuse and abuse of the Bounce house is dangerous and can cause serious injuries or death.
18. Do not turn off the blower while the Bounce house is in use. If the blower stops unexpectedly, make sure that all users exit the Bounce house immediately.
19. Keep children away from the blower, the air inlet, the air outlet, and the power cord at all times.
20. Always turn off the blower and put the Bounce house away when it is not in use.
21. Keep the Bounce house and the blower dry. Never put the Bounce house in a pool. Do not use the Bounce house if it is wet.

22. Place the Bounce house on a free-space boundary free from branches, sharp corners, fences, obstacles where a child could fall upon. Siting must always be on soft leveled ground.
23. The Bounce house must never be used in a partially-inflated state.
24. Before and during use, check for air loss and re-inflate before allowing play to continue.
25. All inflation / deflation and assembly should be carried out by a competent adult.
26. Adult supervision required.
27. The blower is not a toy. Use under the direct supervision of a competent adult.
28. Do not leave children unattended at any time.
29. This is not an aquatic toy. It is not to be used in water.
30. Helmets or other headgear should not be worn while playing in the Bounce House.
31. Loosen or baggy clothing, or clothing containing long cords should not be worn while playing in the Bounce House.
32. Keep pets off of the inflatable device.
33. Bounce away from others and sides, especially the openings.
34. Do not set up when windy.
35. Set up as near to power source as possible.
36. Keep hands away from net.
37. Do not jump on or off the Bounce house.
38. No flips or wrestling.
39. Surface washable only.
40. Do not leave blower outside overnight or in wet or damp conditions.
41. The blower should be securely affixed to the ground before use.
42. Users should be advised to check the product and all its anchorage points before and during use, and to re-inflate or re-secure a appropriate.
43. Place the inflatable device on level ground, not less than 1.8m (6 ft) in any direction from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
44. Bounce house shall be fully inflated and anchored before use.
45. Bounce house shall be inflated with blower provided or with other manufacturer specified replacement blower.
46. Separation of larger children from smaller children.
47. Prevention of users from climbing or hanging on the containing walls.
48. Restriction on the consumption of food, drink and gum.
49. Do not attach items to the inflatable device that are not specifically designed for use with the inflatable device, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they have the potential to cause a strangulation hazard.

KEEP THESE INSTRUCTIONS


OPERATIONAL SPACE REQUIREMENT

Place the inflatable device on level ground, not less than 1.8m (6 ft) in any direction from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.



Before using your Bounce house, check again that there is enough clearance around it. Maintain a clear space of 1.8 metres (6 feet) on all sides of the Bounce house.

Also check that the area is free from walls, structures, fences, tarmac and other hard surfaces and other play areas.




Ensure that there is 1.8 metres (6 feet) clearance above the Bounce house.

Also check that there are no overhanging objects in the area above the Bounce house.

PARTS LIST


Part **A**



Description:
Bounce House

Quantity: **1**


Part **B**



Description:
Blower

Quantity: **1**


Part **C**



Description:
Plug and cable

Quantity: **1**


Part **D**



Description:
Blower Stakes

Quantity: **2**


Part **E**




Description:
Anchor Stakes

Quantity: **4**

WHAT YOU WILL NEED



Description:
Hammer or rubber mallet



Description:
Eye protection


Important : Please check that you have all parts prior to assembly.

GROUNDING INSTRUCTIONS

DANGER:

Improper connection of the equipment- grounding conductor can result in an increased risk of electric shock. Check with a qualified electrician or service engineer. If you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product. If the plug will not fit the power outlet socket, have an appropriate power outlet installed by a qualified electrician.

This product is for use on a
110v~120v - 60Hz 280W



This product must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electrical current to reduce the risk of electric shock. This product is equipped with a power cord that is equipped with a grounding conductor and a grounding plug. Only use the plug in a correctly installed and grounded power outlet complying with local codes and ordinances.

SAFETY WARNINGS: ELECTRICAL BLOWER

DO NOT IMMERSE IN WATER OR USE NEAR OR IN CONTACT WITH WATER. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.

ADULT SET-UP AND SUPERVISION REQUIRED.

⚠ CAUTION: The blower is a high volume blower, and is capable of moving large volumes of air very quickly. Place the blower in an area where it will not draw in dirt or leaves. Keep the blower and power cord away from children, pets, bodies of water, pools, spas, and traffic.

INSTRUCTIONS FOR BLOWER INSTALLATION AND OPERATION

NOTE: Set up as close to the power source as possible. The product should be periodically examined for potentially unsafe conditions such as: damaged cord, plug, housing or parts, and in the event such damage is found, the product should be used until properly repaired. Never leave the blower outside in the rain or exposed to the elements when not in use. When in use, do not place the cord across traffic areas, water or damp areas. The blower should be placed on a stable surface and anchored per product instructions. The power cord of the blower is equipped with Ground Fault Current Interrupter (GFCI) plug.

1. Make sure that power switch of the blower is in the “OFF” position. Plug the blower into a properly grounded outlet.
2. If the GFCI has been tripped, press the “RESET” button to restore power to the blower.
3. Set the power switch of the blower to “ON” to inflate. After use, turn the power to “OFF”.
4. To disconnect the plug, have an adult grip it tightly and pull it from the wall outlet.


⚠ WARNING:

1. Adult installation and supervision required.
2. This blower is for residential use only. It is not intended to be used in commercial or industrial settings.
3. Never insert fingers, pencils, or any other object through the grill at ANY time.
4. Do not operate blower with a damaged cord or plug.
5. Do not operate in the presence of explosive and /or flammable fumes.
6. Never connect the blower to any solid – state speed control device.
7. **WARNING -** Electrocutation hazard do not use extension cord with this product.
8. Always unplug the blower before servicing.

INSTRUCTIONS FOR BLOWER CLEANING AND STORAGE


Do not immerse the blower in water. Unplug the blower before cleaning. To clean: wipe with a damp cloth. The blower does not require any lubrication and has no user serviceable parts. Do not attempt to service the blower. When not in use, store the blower indoors in a dry place. Store the blower upright on a stable surface. Loosely coil the cord and place it beside the blower.

INFLATING THE BOUNCE HOUSE




Check the ground that you are going to erect your bounce house for any sharp objects that could damage the base of the bounce house.

Unzip the carrying case and remove the Bounce house and all the accessories.




Unfold the bounce house and position where you want to inflate.




Extend the long air tube on the rear of the bounce house.

Place the blower near the end of the air tube with the air outlet on the blower facing the end of the air tube.




Slide the end of the air tube over the air outlet on the blower.

“Double tie” the drawstring on the air tube tight to fasten it onto the blower.




INFLATING THE BOUNCE HOUSE



Straighten the blower and air tube to ensure the air will flow easily into the bounce house.

Fasten the blower to the ground by pushing the two blower stakes through the holes in the base of the blower.

Wearing your eye protection, hammer the stakes into the ground.




Plug the blower into a correctly grounded mains socket.

Turn the blower on by pressing the ON/OFF switch.

The bounce house will now inflate.

IMPORTANT: The blower **MUST** be left on when the bounce house is being used.




Once the bounce house is fully inflated, ensure the air tube is straight then fasten the four anchoring straps on the corners of the bounce house base to the ground using the four bounce house stakes.

Slot the four stakes through the D-rings and hammer into the ground.

The Bounce house is now ready for use.


STORING THE BOUNCE HOUSE AWAY



Ensure nobody is using the bounce house.


Press the ON/OFF switch on the blower to turn it off.

Turn the blower off at the mains socket and remove the plug.



Undo the drawstring on the air tube and pull the tube off the blower.

Now remove the stake anchoring the blower to the ground.



Once the bounce house has completely deflated, remove the four stakes from the anchor straps on the corners of the bounce house.

Make sure the bounce house is completely dry then fold it up and put it back into the carrying bag along with the six stakes.

Store the blower and the carrying bag in a dry place away from children.

Cover the blower to protect it from dust.

IMPORTANT: Never leave the blower outside overnight or in wet or damp conditions.

CARE & MAINTENANCE



- Clean the outer surface of the bounce house with clean water, use a hose or a soft cloth for cleaning.
- Do NOT machine wash the bounce house.
- Do not use a pressure washer to clean the bounce house.
- Always ensure the bounce house is completely dry before storing it.
- Always deflate the bounce house after use and store in a dry indoors location.
- Conduct regular inspections on your Bounce House for signs of wear and tear. If the product is damaged do not use it.
- Never attempt to modify the product in any way.
- As an outdoor product the inflatable is subject to wear and deterioration. Inspect for signs of fabric failure; weak or torn surfaces must be repaired promptly.
- Blower must be unplugged before servicing.
- Do not immerse the blower in water. To clean, wipe with a damp cloth.
- Regularly inspect the intake and output openings and keep free of dirt, leaves, etc.
- Store the blower upright on a stable surface.
- **WARNING!** Keep away from fire.

REPAIR KIT INSTRUCTIONS



Warning: Not a toy. Adult use only.
Repair kit. Keep away from children.






1. Deflate the item, clean the damaged area and allow it to dry thoroughly.
2. Cut a portion of the patch allowing to the size needed and round the corners. (See Fig. 1 & 2).
3. Apply the glue on the patch material, position the patch over the damaged area and smooth out any bubbles.
4. Allow to sit for 30 minutes before re-inflating.



SPARE PARTS

Ordering replacement parts visit our web site or call our Customer Hot Line 1-877-927-8777. To help us assist you, please provide the following information when calling:

- The MODEL of the inflatable Bounce house.
- The NAME of the product.
- The KEY LISTING and DESCRIPTION of the part (see parts list).
- The quantity needed.
- The desired method of shipping.

Key listing	A	B	C	D	E
Picture					
Description	Bounce House	Blower	Plug and cable	Blower Stakes (Short)	Anchor Stakes (Long)
Quantity	1	1	1	2	4

**For a full range of accessories and replacement parts
call 1-877-927-8777**