





# Installation & Assembly

Version:1.0




**EN\_IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.**


## USING CAM LOCK AND QUICKFIT




**EN\_QUICKFIT:** Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.













**EN\_CAM LOCK:** When fitting cam lock, ensure starting position is correct before you insert connecting quickfit.













**EN\_Quickfit** head should be in the centre of the cam lock when the two panels are joined.  
Cam lock should be inserted before quickfit.



























**EN\_Turn** cam lock clockwise to tighten.





NO.	PARTS	QTY	SPARE
①		x1	
②		x1	
③		x1	
④		x1	
⑤		x2	
⑥		x2	
⑦		x2	
⑧		x2	
⑨		x8	
⑩		x8	

NO.	PARTS	QTY	SPARE
⑪		x8	
⑫		x8	
⑬		x8	
⑭		x1	
⑮		x2	
⑯		x1	
⑰		x2	
⑱		x4	
⑲		x4	
⑳		x1	






 <b>A</b> x54 Ø6x35mm +3(spare)	 <b>B</b> x54 Ø15x10mm +3(spare)	 <b>C</b> x54 Ø6x30mm +3(spare)	 <b>D</b> x41 Ø4x35mm +4(spare)	 <b>E</b> x112 Ø3.5x12mm +3(spare)	 <b>F</b> x18 +2(spare)
 <b>G-1</b>	 <b>G-2</b>	 <b>H</b> x22 +2(spare)	 <b>I</b> x8	 <b>J-1</b>	 <b>J-2</b>
 <b>K-1</b>	 <b>K-2</b>	 <b>L</b> x12 Ø15mm	 <b>M-1</b>	 <b>M-2</b>	 <b>N</b> x1
 <b>O</b> x4	 <b>CL</b> x8 L350mm	 <b>CR</b> x8 L350mm	 <b>DL</b> x8 L350mm	 <b>DR</b> x8 L350mm	

 <b>A</b> x40	 <b>B</b> x40	 <b>C</b> x32	 <b>D</b> x40
--	--	--	--

**01**






**x8**

E x48

DL x8


DR x8





x8

E x16

I x8





x8



C x10


H x20



H x2



N x1

O x4





E x12

CL x4



E x12






CR x4



E x24



CL x4

CR x4





! Second hole

F x4





F x2





F x2

D x1




F x4







C x6

F x6




The backplate slots are rearward




180°


F x4




17



A x6






18



B x6

C x6



G x12




L x12



Ø15mm





G-1

G-2







The drawer is different,  
please install it strictly  
according to the number  
shown.




First fix the anti-rewind screw in the reserved hole of the product.




Then, put the expansion bolt into the hole




then, use a ruler to measure the approximate height of the product on the wall, and then mark it with a pen.



Finally, pass the matching screws through the "anti-rewind" and tighten them to fix them on the wall.



Then use a tape drill to make holes in the wall that are suitable for the product screws.



If the ground is uneven, you can use foot padw to level it off.