


ASSEMBLY INSTRUCTION

ITEM#: MSS-10057



PRODUCT CONTAINS 3 BOXES:

MSS-10057-A

MSS-10057-B

MSS-10057-C

Arrive in 3 separate boxes and may not be part of the same shipment; please install the product after receiving all the packages.

Requires three or four people and takes 7-10 hours for installation.

Quick & Easy Assembly

Ridge Reinforced Walls

Available in Various Sizes

WARNING: READ INSTRUCTION MANUAL BEFORE ATTEMPTING TO ASSEMBLE OR OPERATE THIS PRODUCT.

About installation

About usage

About product

About return

Others

Customer Service Email: customercare@lava-star.com

If you have any questions, please do not hesitate to contact us. We will ensure to provide you with a response within 24 hours.

CONTENTS

1.Contents.....	2
2.Precautions for installation.....	3-4
3.Product explosion diagram	4-6
4.Part list.....	7-13
5.Hardware.....	14
6.Base installation steps.....	15-16
7.Frame installation steps.....	17-24
8.Triangular panel installation steps.....	25-35
9.Top frame installation steps.....	36-37
10.Top panels installation steps.....	38-46
11.Door installation steps	47-53
12.Trim strip installation step.....	54-55

BEFORE YOU START

Owner's Manual

Prior to installation, it is important that you contact your local government authority to determine if building approval is required.

Please read carefully and make sure you understand this owner's manual as it includes important information and helpful tips which will make the installation easier and more enjoyable.

Assembly instructions

Instructions are included in this manual and contain all relevant information for your model building. Review all instructions before you begin. During assembly, follow the step sequence carefully to ensure proper installation. Please be aware: **this unit takes three or four people about one full day to complete.**


Parts

Check to be sure that you have all the necessary parts for the installation.


Separate contents of the carton by the part number while reviewing parts list.

Familiarize yourself with the hardware and fasteners for easier use during construction. These are packaged within the carton. Note that extra fasteners have been supplied for your convenience.

TOOLS REQUIRED




Hammer




Screwdriver



Ladder




Electric screw driver



Wrench




This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.




Square Assembly

Check that assembly is square before tightening bolts.




Use Level

Check that set or assembly is properly level before proceeding.



Measure Distance




Gloves

IMPORTANT

How many people needed for the installation work?

Requires three or four people and takes 7-10 hours for installation.



PLAN AHEAD

Site Selection

Avoid overhanging trees as much as possible as leaves will make regular cleaning necessary and broken branches are a potential hazard.

Small trees, bushes or fences nearby can be helpful, acting as a wind break.

Site Preparation

The site must be prepared so that the base of the shed is level all round and checking with a spirit level is required.

The base can be constructed by treated timber or concrete, in order to stop the moisture getting into the shed.

The shed is not designed to be built on the lawn directly. Also the ground will get muddy during rainy days. If a concrete pad is made, it is important that this slopes towards the edges to prevent water ingress.

Time must be allowed for any concrete or cement to dry before building the shed on top.

Bases can also be constructed from bricks, blocks, or mounted on a concrete pad.

The bricks or blocks should be cemented onto firm and level concrete footings and the greenhouse frame drilled and screwed to the base.

IMPORTANT NOTES:

Find someone to help you: it is much easier with someone to hold parts, pass tools ect. Also some steps require two people to lift structures together. This is not very heavy work so would suit most able-bodied people.

Allow plenty of time: rushing often causes errors and the re-doing of incorrect assemblies. If you have never built a shed before, it can take most of a day to carefully complete the construction.

Have the right tools in hand.

Safety clothing as recommended in the 'Tools' section.

Ideally let out the parts and check that all are present before commencing construction. Lay on cloths or plastic sheets if there is any risk of scratching the parts.

Tighten all nuts carefully, being sure not to miss any. Check the frame is square and using a spirit level to check that it is upright.

For your safety concern, please do not stand under the metal shed in heavy wind or snow days.

For safety, please use expansion screws to reinforce the posts to the ground.

Please clear the snow off the roof in time if there is a heavy snowfall.

Make sure all screws are tightened before use. Repeat to confirm all screws, buckles and straps are tightened every 90 days.

Please keep all screws loose during the assembly process and tighten them after completing the installation.

Do not use or store objects in the Metal Shed with open flames or flammable chemicals.

Please note that some parts have sharp edges and should be handled with gloves.

If any parts are missing, broken, damaged or worn, discontinue use of the product until repairs are made or factory replacement parts are installed.


Failure to install the product according to the manufacturer's instructions may void the warranty policy for this product.

PARTS

Before installation, please place the parts in the position as shown in the figure below.


Shed top panels

No.	Qty.
G1	4
G2	2
M1	2
M2	2
M3	2
M4	4
Q1	16
Q2	2
N1	1
N2	2



Shed top frame

No.	Qty.
G3	4
B1	2
B2	2
B3	2
B4	2
K1	2
K2	2
L1	4
L2	4



PARTS


Before installation, please place the parts in the position as shown in the figure below.

Shed Side Frames & Panels

No.	Qty.
C1	4
C2	2
C3	2
C4	2
C	2
F1	1
F2	1
F3	2
F4	2
F5	2
F6	2
F7	2
F8	2
S1	1
S2	2
S4	1
S5	1
E1	5
E2	16
E3	4
E4	2
E5	2
Y1	2
Y2	6
Y3	2
Y4	1
S6	4

Shed base


No.	Qty.
A1	2
A2	2
A3	1
A4	1
A5	1
A6	1
A7	1
J1	4



PARTS










Before installation, please place the parts in the position as shown in the figure below.




Door	
No.	Qty.
D1	2
D2	1
D3	1
D4	4
D5	4
D6	2
R1	4
R2	1
R3	1
R4	2














Parts list






Box1-MSS-10057-A















NO.	Qty	Part Image
E1	5	
E2	16	
E3	4	
E4	2	
E5	2	
N1	1	
N2	2	
D2	1	
D3	1	

















NO.	Qty	Part Image
D1	2	
S4	1	
S5	1	






NO.	Qty	Part Image
Q1	16	
Q2	2	
K1	2	
K2	2	
G3	4	
G1	4	
G2	2	
R2	1	

NO.	Qty	Part Image
R3	1	
R4	2	
R1	4	
Instruction Manual		
Hardware		













NO.	Qty	Part Image
M3	2	
M4	4	
S1	1	
S2	2	
D6	2	

NO.	Qty	Part Image
A1	2	
A2	2	
A3	1	
A4	1	
A5	1	
A6	1	
A7	1	
B1	2	
B2	2	
B3	2	
B4	2	
C1	4	
C2	2	
C3	2	

NO.	Qty	Part Image
C	2	
C4	2	
D4	4	
D5	4	
F1	1	
F2	1	
F3	2	
F4	2	
F5	2	
F6	2	
F7	2	
F8	2	
L1	4	
L2	4	
M1	2	
M2	2	

NO.	Qty	Part Image
Y1	2	
Y2	6	
Y3	2	
Y4	1	
S6	4	


HARDWARE

Part	Description	Qty	Extra	Part Image
H1	M4*10mm bolt	684	70	
H2	M4*15mm bolt	50	10	
H3	M4 nut	50	10	
H4	M4.8*16mm bolt	16	2	
H5	M5*12mm bolt	16	2	
H6	M5 nut	21	3	
H7	M5*10mm bolt	5	1	
T1	Washer	684	27	
T2	Screw Cover	684	30	
J1	Corner Base	4	0	
J2	Stake	9	0	
J3	Expansion Bolt	4	0	

Base Exploded View




Before installation, please place the parts in the position as shown in the figure below.

Shed base	
No.	Qty.
A1	2
A2	2
A3	1
A4	1
A5	1
A6	1
A7	1



Step.1

	A1*2
	A2*2
	A3*1
	A4*1
	A5*1
	A6*1
	A7*1




Note: Find the corresponding numbered parts and install them as shown in the picture. The shed base must be BOTH square AND level or the holes will not align. Make sure d1 equal to d2, when diagonal measurements are equal, the frame is square. (This is for avoiding misalignment of the doors or holes during the installation).

Frame Exploded View

Before installation, please place the parts in the position as shown in the figure below.





Shed Side Frames & Panels	
No.	Qty.
C1	4
C2	2
C3	2
C4	2
C	2
F1	1
F2	1
F3	2
F4	2
F5	2
F6	2
F7	2
F8	2
S1	1
S2	2
S4	1
S5	1
S6	4
E1	5
E2	16
E3	4
E4	2



Note: The wood side should be facing out.




Note: E2 and E4 could be assembled interchangeably.



Step.2






Install E3 on the base A1 and A2.

Step.3



	E2*1
	E5*2
	E1*3





Step.3-1









Step.3-2

	F1*1
	F2*1





Step.4



	F3*2
	F4*2
	F5*1
	F6*1



Step.5




	F7*2
	F8*2

	
H1 *14	T1 *14



a*2


Step.6










Triangular Panel Exploded View




Before installation, please place the parts in the position as shown in the figure below.



Shed top triangular panel	
No.	Qty.
G3	4
B1	2
B2	2
B3	2
B4	2
K1	2
K2	2








Step.7

	K2*2
	K1*2
	B1*2
	B2*2
	B3*2
	B4*2
	G3*4










Step.8




Step.9

	S4*1
	S5*1





a







b

- a: attach S4 ,E1 to F1.
- b: attach S5, E1 to F2.
- c: attach S4, E1 to A7.
- d: attach S5, E1 to A7.


Step.9-2





Step.10







OUT



INSIDE







Step.11



	C*2
	C1*4
	C2*2
	C3*2
	C4*2
	E4*2

H1	T1	H2	H3
*16	*16	*4	*4




Note: The wood color side should be facing out.


Step.12



Note: E2 and E4 could be assembled interchangeably.




&





Top Frame Exploded View



Before installation, please place the parts in the position as shown in the figure below.



Shed top frame	
No.	Qty.
L1	4
L2	4




Step.13

	L1*4
	L2*4

	
H2	H3
*12	*12






a*2




b*1

Note: Do NOT tighten the bolts at this step.


Step.14







a*2



b*2



Step.15




Note: Tighten the bolts from step 13 to step 15.

Top panels Exploded View




Before installation, please place the parts in the position as shown in the figure below.

Shed top panels	
No.	Qty.
G1	4
G2	2
M1	2
M2	2
M3	2
M4	4
Q1	16
Q2	2
N1	1
N2	2





Note: The black color side should be facing out.


Step.16





- a: attach Q1/Q2 to F8.
- b: attach Q1/Q2 to L1.
- c: attach Q1/Q2 to L1.
- d: attach Q1 to F7.
- e: attach Q1 to L2.
- f: attach Q1 to L2.

Step.17



	N2*1
	N1*1



attach N2, N1 to Q1 and L1/L2





Step.18





- a: attach Q1 to F8/F7.
- b: attach Q1 to L1/L2.
- c: attach Q1 to L1/L2.
- d: attach Q1 to F7/F8.
- e: attach Q1 to L2/L1.
- f: attach Q1 to L2/L1.

Make sure Q1 between N1/N2 and L1/L2.




Step.19



attach N2, N1 to Q1 and L2/L1.














Step.20



- a: attach Q1 to F7.
- b: attach Q1 to L2.
- c: attach Q1 to L2.
- d: attach Q1/Q2 to F8.
- e: attach Q1/Q2 to L1.
- f: attach Q1/Q2 to L1.

Step.21


	M1*2
	M2*2
	M4*4
	M3*2
	G2*2
	G1*4







The Door Exploded View



Before installation, please place the parts in the position as shown in the figure below.

Door	
No.	Qty.
D1	2
D2	1
D3	1
D4	4
D5	4
D6	2
R1	4
R2	1
R3	1
R4	2






Step.22

	D1*2
	D2*1
	D3*1
	D4*4








Note: DO NOT tighten the bolts at this step.

Step.23









Step.24


	D5*4
	D6*2
	R4*2

	
H1	T1
*34	*34

inside of door



outside of door







outside of door: attach
D4 to D1/D2/D3 by using
eight H1 and T1.



f: attach D1,D2 and D6.
attach D1,D3 and D6.

Note: Tighten the bolts
from step 22 to step 24.


Step.25







Step.26





*4








Step.27



	Y1*2
	Y2*6
	Y3*2
	Y4*1



Step.28

	J3*4
	J2*9
	J1*4

	
H1	T1
*16	*16



Made in China