

84"–104" Double Shelf Double Hang with Cubby and Sep. 32" Long Hang


INSTALLATION GUIDE

page 1

The instructions below will make installation & assembly as simple as possible. We recommend reading these instructions BEFORE beginning installation. Becoming familiar with all the components will also make your installation quick & easy.

WARNING:

It is important that RAILS be installed properly per the instructions below. If the system is incorrectly installed or assembled it could become unstable or collapse, possibly causing damage or injury.



TOOLS:

Impact Drill for driving screws
into studs (optional)
Drill with 3/16" bit & APEX #2
Phillips Screwdriver Bit
2 3/4" long or longer
7/64" Drill Bit for pre-drilling studs
(not needed if you have impact drill)
Rubber Mallet or hammer with wood block
Tape Measure
Level

CONTENTS:


- A) RAIL w/ End Caps (2 Long & 1 Short)
- B) Brackets (7)
 - C-1) Cubby Wall (Left)
 - C-2) Cubby Wall (Right)
 - C-3) Cubby Bottom
 - C-4) Cubby Shelf (2)
 - C-5) Cubby Screw Pack
 - Wall Connector Bolt (4)
 - Bottom Shelf Connector Bolt (4)
 - Figure "8" Clip (4)
 - 5/16" Dia. X 1 1/2" Standoff (4)
 - #8-32 x 2 3/8" Flathead Bolt (4)
 - 5mm x 1" Shelf Support Pins (8)
 - C-6) "U" Shaped Cubby Bracket
- D) Hangbar End Caps (6)
- E) Hangbars (E-1, E-2 & E-3)
- F) Top Shelf (2 Long & 1 Short)
- G) #8x3/4" Phillips Panhead Screw (18)
- H) #10x2" Phillips Panhead Screw
 - 49"–56" RAILS (22)
 - 57"–72" RAILS (26)
 - 73"–74" RAILS (30)

RAIL HEIGHT

When installing second shelf unit above first, top RAIL should be 40" above bottom RAIL

Top of hangbar will fall approx. $\frac{3}{4}$ " below top of RAIL when installed


Small gap between cubby bottom and shelf requires short screwdriver to lock cubby bottom in place



STEP 1

MOUNT RAIL INTO WOOD STUDS


The RAIL must be mounted into the solid wood of wall studs. Standard stud spacing is 16" from center to center. RAIL can shift left or right as desired so long as it is supported by all available studs. It is unsafe to mount the RAIL in any other manner. If you are unsure how to install the RAIL, please consult a qualified carpenter or handyperson.




- Measure for RAIL height & desired position (see diagram on page 2)
- Locate studs. **Do not use drywall anchors.** Mark stud centers on RAIL upper and middle screw guide grooves. Drill holes in the RAIL only using the 3/16" drill bit.
- If using an impact drill skip this step. Pre-drill wood studs using a 7/64" drill bit.
- Anchor the RAIL to the wall using the #10 x 2" wood screws (H) provided. Do not over tighten as RAIL can bend. Secure the top center screw first. **IMPORTANT – Make sure the RAIL is level before drilling mounting holes. If the RAIL is not level the system will not function properly.** Then attach the remaining screws.

STEP 2

SIDE WALLS: CAMLOCK BOLTS



Screw camlock bolts into pre-drilled holes in side walls (C-1 & C-2). (2) camlock bolts per wall




STEP 4
CONNECT WALLS TO
CUBBY BRACKET

Position Bracket (C-6) and right cubby wall (C-2) as shown.


Insert wall connector bolts into holes in the tops of the wall panels. Fronts of walls will be flush with fronts of bracket.

Use #2 Phillips Head screwdriver to tighten camlock (1/2 turn clockwise)




STEP 4 (continued)


Connect left cubby wall
(C-1) in the same manner



STEP 5 CUBBY BOTTOM

Position cubby bottom (C-3) between walls as shown. Drop shelf to bottom of walls (bottoms of walls and shelf should be flush). Turn camlock clockwise to lock shelf in place.







STEP 6 CUBBY TOP SHELF SUPPORTS

Stand cubby upright on floor

Pass flathead bolt through small end of figure "8" clip and standoff. Tighten bolt with large portion of figure "8" clips accessible from inside shelf unit walls.



STEP 7 HANG CUBBY ON RAIL


Tip assembled cubby and guide pucks into RAIL (A) at either right or left end of RAIL.

NOTE:

Cubby needs to be placed at end of RAIL. Can be either left or right end.

STEP 8 PLACE RAIL BRACKETS

Insert brackets (B) from front of RAIL at an angle and pull down. Position 3" from each end






STEP 9 ATTACH TOP SHELF

Begin with cubby wall closest to the end of the top shelf.

Fasten figure "8" clips on walls with #8 self tapping screws (G) from underside using Apex bit. No need to pre-drill

Before attaching shelf to second wall, measure inside cubby to ensure that distance between walls is same on top as on bottom

Attach shelf to second wall (same as with first wall)




Lastly, Fasten shelf to brackets with #8 self tapping screws (G) from underside using Apex bit. No need to pre-drill





STEP 10 PLACE RAIL BRACKETS

Insert brackets (B) from front of RAIL at an angle and pull down. Position 3" from each end with equal spaces between.



STEP 11 ATTACH TOP SHELF


Fasten shelf to brackets with #8 self tapping screws (G) from underside using Apex bit. No need to pre-drill



STEP 12

INSTALL BRACKETS FOR LONG HANG


Insert from the face at an angle and pull down. Make sure to position them 3" from each end.



STEP 13

ATTACH TOP SHELF FOR LONG HANG


Fasten shelf to brackets with #8 self tapping screws from underside using Apex bit. No need to pre-drill



STEP 14

INSERT HANGBAR ENDS


Insert Ends into Hangbar. Use rubber mallet or hammer with wood block to protect finish



STEP 15

PLACE HANGBARS

Drop hangbars into brackets



STEP 16 ADJUSTABLE SHELVES

Use shelf pins to support adjustable shelves (C-4) as desired inside completed cubby unit.

Cutouts on bottom of shelves fit over shelf pins to hold shelves

