



# Assembly Instructions




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. A Phillips head screwdriver is required for the assembly of this product .



- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




## VI HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS


- 1.Screw the Cam Bolt into the pre-drilled hole on the panel. Make sure Cam Bolt goes into the pre-drilled hole on the end of panel for Cam Lock.
- 2.Insert the Cam Lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of Cam Lock points towards Cam Bolt.
- 3.Take a Phillips screwdriver and rotate the Cam Lock clockwise to lock the Cam Bolt.
- 4.Use the sticker to conceal the Cam.



















- VII. Power tools should not be used to assemble this product .




Parts List













# Hardware List


A		Ø8x30mm	Dowel	13 pcs
B		Ø6x35mm	Cam bolt	6 pcs
C		Ø15x11mm	Cam lock	6 pcs
D		Ø30mm	Cam cover	9 pcs
E			Glue	1 pc
F		Ø5x16mm	Shelf support pin	12 pcs
G		Ø4x25mm	Knob bolt	2 pcs
H			Knob	2 pcs
J			Door Pin Hinge	2 pcs
K			Door Pin Hinge	2 pcs
L			Plastic pivot	4 pcs
M		Ø3x12mm	Screw	10 pcs
N			Connector	8 pcs
P		Ø6x13mm	Bolt	16 pcs
Q		M 4	Allen Wrench	1 pc
R		Ø6x50mm	Screw	3 pcs



Philips head screwdriver required for assembly  
(not included)


# Hardware List

S		Ø6x20mm	Bolt	2 pcs
T			Magnetic Catch	1 pc
U		Ø3x15mm	Screw	2 pcs
V			Metal piece	2 pcs
W		Ø6x55mm	Bolt	7 pcs
X		Ø3.5x12mm	Screw	16 pcs
Y			L-shaped Bracket	4 pcs
Z		Ø5x14mm	Screw	4 pcs
AA			Angle Bracket	1 pc
BB			Tipping Restraint Hardware	2 sets




Philips head screwdriver required for assembly  
(not included)


## Step 1




## Step 2




## Step 3





## Step 4



## Step 5





## Step 6








## Step 7



## Step 8




## Step 9




## Step 10


Note: Do not over tighten the bolts




## Step 11




## Step 12





## Step 13




## Step 14




## Step 15




## Step 16




## Step 17



## Step 18




## Step 19






## Step 20






## Step 21



# Step 22

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Final Assembly