



ASSEMBLY INSTRUCTION




Notice:


1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
2. Place the item on a flat ground to adjust and make sure it remains stable.
3. Tighten up all screws with tools gradually.
4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
6. Note : If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.




x2




PART LIST




Ax1




Bx1




Cx1




Dx1




Ex4




Fx1




Gx1




Hx1




Ix1




Jx1




Kx1




Lx1




Mx2




Nx2




Ox4




Px2




Qx1




Rx2




Sx2




Tx1




Ux2



Vx1




Wx2



Xx5

PART LIST




Yx2


PART LIST




1- Washer : 104 pcs
Extra : 2 pcs



2-Bolt 6x30 : 84 pcs
Extra : 2 pcs




3-Bolt 6x50 : 10 pcs
Extra : 1 pcs




4-Nut : 10 pcs
Extra : 1 pcs



5- Allen key : 2 pcs




5- Key : 1 pcs




6- Conecter : 4 pcs


CARTON CONTENT :




Ax1




Bx1




Cx1




Dx1




Ex3



Ux1




Xx2




Yx1


CARTON CONTENT :




Mx2




Nx2




Ox4




Px2




Wx2




Hardware




Fx1




Gx1




Hx1




Ix1




Ex1




Ux1




Xx2




Yx1




Jx1




Kx1




Lx1




Qx1




Rx2




Sx2



Tx1




Vx1




Xx1

Step 1





Ax1 Bx1 ①x2 ②x2

Step 2





Cx1 ①x8 ③x4 ④x4



Step 3





Step 4




Step 5




Step 6



Step 7






H



Hx1 ①x8 ③x4 ④x4



Step 8



I



Ix1 ①x4 ②x4

Step 9





Ex1 ①x6 ②x6

Step 10





Ux1 Xx2

Step 11




J x1 K x1 ① x4 ③ x2 ④ x2

Step 12





E x1 ① x4 ② x4

Step 13




E





Ex1 ①x4 ②x4

Step 14





L




Lx1 ①x6 ②x6

Step 15




V x1 Xx1

Step 16




x2




Mx1 Px1 ①x1 ②x1

Step 17




Ox2 ①x8 ②x8

Step 18




Nx1 ①x6 ②x6

Step 19





x2




Wx1

Step 20




Qx1 Sx1 ①x2 ②x2

Step 21



Sx1 ①x2 ②x2



Step 22



Rx1 ①x6 ②x6

Step 23



R



Rx1 ①x6 ②x6


Step 24

T




Tx1

Step 25



6x4

Step 26



Yx2

Finish