


## TIME AND CHIME SETTING:

**CONGRATULATIONS** – You have purchased a quality clock which plays the Westminster chime melody on the hour, tolls the hour and has an automatic shut-off (clock does not chime between 10:00 p.m. and 6:00 a.m.). To ensure your clock functions correctly, please follow the time and chime setting instructions precisely. The clock will chime during the day and will automatically turn off at night.

1. Pull upwards the back panel of the top unit .
2. BEFORE inserting batteries set the clock at 6:05 AM with knob A.
3. Insert 1xAA alkaline battery into the clock battery chamber, according to the positive (+) and negative (-) symbols.
4. Insert 2xAA alkaline batteries into the chime battery chamber, according to the positive (+) and negative (-) symbols. Make sure batteries are secure in the holder. The clock will chime automatically and toll 6 times.
5. Now turn hands(Using knob A) slowly to the present hour (in a clockwise direction).Remember that the clock started at 6:05 in the morning. if setting at night,lets say, to 9:20 PM, then hands will be turned thus -- 7,8,9,10,11, 12,1,2,3,4,5,6,7,8,9, then 9:20.  
N.B.: When moving hands to the present time, the clock will begin chiming. Do not be concerned about this. the last strike you hear after setting the clock at appointed time will be the correct one.
6. When replacing batteries, remember that all the above must be repeated from point No 1 above. The clock must be started again at 6:05 a.m.
7. To eliminate chimes, remove the two batteries from the Chime Battery Chamber.
8. Never turn clock hands counter clockwise as it will interrupt the chime sequence and damage the clock.

**N.B.: WHEN BATTERIES ARE LOW, CHIMES WILL NOT REMAIN CO-ORDINATED WITH THE TIME ON THE CLOCK. WHEN THIS HAPPENS, REPLACE WITH NEW ALKALINE BATTERIES AND RESET CLOCK AS ABOVE.**




CLOCK BATTERY CHAMBER

CHIME BATTERY CHAMBER

## PENDULUM SETTING:

1. Insert 2xC Alkaline batteries into the pendulum battery chamber according to the positive (+) and negative (-) symbols.
2. For transport security, the small black plastic pendulum (B) may be attached to the case (C) to prevent it from swinging.
3. At (D) use thumb pressure to gently push towards the right to loosen the pendulum and allow it to swing freely.

Battery-operated. Requires batteries. Do not mix old and new batteries. Do not mix alkaline, standard batteries (carbon-zinc) or rechargeable (nickel-cadmium) batteries.



PENDULUM BATTERY CHAMBER