Product structure decomposition



Product structure decomposition



Product structure decomposition	
 1 x 1	 2 x 1
 3 x 1	 4 x 2
 5 x 1	 6 x 3
 7 x 1	 8 x 2
 9 x 2	

Accessories list

A		Two In One Screw(6x28mm)	20pcs
B		Two In One Nut(10x12mm)	20pcs
C		Foot rubber pad (36X36)	6pcs
D		Rebound device & Screw(3x16mm)	1pcs-4pcs
D		hinge	2pcs-2pcs
D		Iron sheet	2-4-4pcs
E		gasket & Screw (3x16mm)	16-16pcs
F		Iron sheet & Screw (3.5x12mm)	2-2pcs
G		Lock	1pcs
H		expanded rubber tube	2pcs
H		Iron gasket & Screw (4X45mm)	4-2pcs
H		Anti Fall Hardware & Screw (3.5x14mm)	2-2pcs
J		power (3A)	1pcs
K		Wire harness clip	2pcs

 1pcs



Double-head screwdriver, use as required

Locking Operation



Turn the key clockwise →
The lock core extends →
Lock the door.

Unlocking Operation:



Turn the key counterclockwise →
The lock core retracts to its original position →
Open the door

Use parts ① and ②



Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign

Step 1



code	Diagram	count
A		6

Step 2

code	Diagram	count
A		4



Step 3

code	Diagram	count
B		2



△ Note: The bottom one is Board No. 2.

Step 4

code	Diagram	count
B		6



Step 5

code	Diagram	count
B		6



Step 6

code	Diagram	count
C		6



Step 7

code	Diagram	count
A		4



Step 8

code	Diagram	count
B		4



Step 9



Step 10

code	Diagram	count
A		4



Step 11

code	Diagram	count
D		1
D	 3×16mm	4



Step 12



Step 13

code	Diagram	count
B		4



Step 14

First, completely unscrewthe screws on the parts



Then take out the black rubberpad from the inside of the part,and the white sponge remainsunchanged inside the part.



code	Diagram	count
D		1
D		1
D		1
G		1



Place the black gasket on the side where the screws are installed

Pay attention to the direction of the door hinge,
rotate the screws to compress the black gasket,
and do not place it in the opposite direction

Step 15

code	Diagram	count
D		1
D		1
D		1

First, completely unscrewthe screws on the parts



Then take out the black rubberpad from the inside of the part,and the white sponge remainsunchanged inside the part.



Place the black gasket on the side where the screws are installed

Pay attention to the direction of the door hinge,
rotate the screws to compress the black gasket,
and do not place it in the opposite direction

Step 16

Pull the wires through from inside the panel cabinet.



Step 17

code	Diagram	count
D		4
D		1
D		1



Step 18



Step 19



Step 20

Open the glass door



Close the glass door





Step 21

code	Diagram	count
E		16
E	 3X16mm	16
F		2
F	 3.5X12mm	2



Step 22

Connect the lamp wires.

code	Diagram	count
K		2



Step 23

code	Diagram	count
H		2
H		2
H		2



Step 24



Mark hole locations with a marker pen

Step 25

code	Diagram	count
H		2

Drill a hole in the wall with an impact drill.





Hammer drive in an expansion plug.

Step 26

code	Diagram	count
H	4x45mm	2
H		2



Step 27

code	Diagram	count
J		1

Hammer drive in an expansion plug.



User's Guide

Thank you for purchasing this product.

To use this product, please connect it to a power source.

Please use if the product works normally after connecting to power.

If bubbles appear on the panel, remove the protective film.

Introduction

The box is an intelligent controller.

It has 1 USB output port 1 Type-c port, with 2 touch buttons ,

it can and turn ON/OFF the induction function,

turn ON/OFF the light,adjust the light luminance, and change light colors.

The lights can be controlled through both the touch buttons and a dedicated app.

Operation

This touch button is used to turn the light on/off, adjust brightness, and switch the color of the lights.

i. Single Click: Turn the light on/off.

ii. Quick Double-Click: Switch between 7 static RGB colors.

iii. Long Press (2+ seconds): Adjust the light luminance.

This touch button is used to switch dynamic phantom colors and turn ON/OFF the induction function.

i. Single Click:Switch to Phantom Mode, with 5 magical color transformations available.

ii. Human Body Sensing Control:Long Press (3+ seconds): Turn on The key press indicator light is on.)

Long Press (3+ seconds): Turn off (The key press indicator light is off.)

By default, the human body sensing is enabled upon initial power-on, and the indicator light is on.



⚠ ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.

2. If you have any questions when installing, please feel free to contact us. Thank you.



Select English Language

Select the corresponding device to download.
Note: If the download fails,
please turn off the "Enhanced Protection"
in the Pure Mode settings of the device.



1



2

It turns blue after clicking

3



4

5 Unplug the smart box

6