


PLASTIC GARDEN SHED 8x8FT


Instructions for Assembly





WARNING

Please read the instruction manual carefully before assembly.
Please assembly strictly in accordance with the instruction.
Please double-check to ensure that all parts of the package contents intact.
To avoid injury, work gloves are recommended during assembly.


Level the ground surface | Nivelez la surface du sol | Nivela la superficie del suelo | Ebnen Sie die Bodenoberfläche | Maak de bodem vlak | Livellare la superficie del terreno | Nivela a superfície do solo



Recommendation: Construct a wooden or concrete base as a foundation | Recommandation: fabriquez une base en bois ou en béton en guise de fondation | Recomendación: construya una base de madera o de cemento a modo de cimiento | Empfehlung: Bauen Sie als Fundament eine Grundfläche aus Holz oder Beton | Aanbeveling: maak een houten of betonnen ondergrond als fundering | Raccomandazione: Costruire una base di legno o di cemento come fondamenta | Recomendação: Construa uma base de madeira ou de cimento como fundação



External floor measurements are: | Les mesures externes de la étage sont: | Las medidas del suelo externo son: | Die Außen-Bodenmaße betragen: | De afmetingen van de externe vloer zijn: | Le dimensioni esterne del pavimento sono: | As medidas externas do chão são:



BEFORE STARTING ASSEMBLY | AVANT DE COMMENCER LE MONTAGE | ANTES DE EMPEZAR EL ARMADO | VOR MONTAGEBEGINN | VOORDAT U BEGINT TE MONTEREN | PRIMA DI INIZIARE L'ASSEMBLAGGIO | ANTES DE INICIAR A MONTAGEM

Read the care and safety guidelines at the end of this manual | Check to ensure that there are no missing or damaged parts BEFORE starting or arranging assembly | Remove all parts from the package(s) and spread them out on a clean work surface | Review all assembly instructions | Assemble all the parts according to the directions in this manual. Do not skip any steps.

Lisez les instructions de précaution et de sécurité à la fin de ce manuel | Assurez-vous qu'il n'y a pas de pièces manquantes ou endommagées AVANT de commencer ou d'organiser l'assemblage | Retirez toutes les pièces du/des paquet(s) et étalez-les sur une surface de travail propre | Lisez toutes les instructions de montage | Assemblez toutes les pièces selon les instructions de ce manuel. Ne sautez aucune étape.

Lea las intrucciones de precauciones y seguridad que están al final de este manual | Asegúrese de que no faltan piezas ni están dañadas ANTES de comenzar o disponer el montaje | Saque todas las piezas del paquete o paquetes y póngalas sobre una superficie de trabajo limpia | Revise todas las instrucciones de montaje | Monte todas las piezas según las instrucciones de este manual. No se saltee ningún paso.


Lesen Sie die Sicherheitsrichtlinien am Ende des Benutzerhandbuchs durch | Prüfen Sie bitte VOR dem Zusammenbau, dass keine Teile beschädigt sind oder fehlen | Nehmen Sie alle Teile aus der Verpackung und breiten Sie sie auf einer sauberen Arbeitsfläche aus | Gehen Sie noch einmal die komplette Aufbauanleitung durch | Bauen Sie alle Teile entsprechend der Anleitung in diesem Handbuch zusammen. Lassen Sie dabei keinen Arbeitsschritt aus.

Lees de richtlijnen voor zorg en veiligheid achterin deze handleiding | Controleer dat er geen onderdelen mankeren, of beschadigd zijn, VOORDAT u met de montage begint | Haal alle onderdelen uit het pakket (of uit de pakketten) en leg ze open schoon werkoppervlak | Bekijk alle montagehandleidingen | Monteer alle onderdelen volgens de aanwijzingen van deze handleiding. Sla geen stappen over.

Leggere le linee guida di assistenza e sicurezza alla fine di questo manuale | Assicurarsi che non ci siano parti mancanti o danneggiate PRIMA di iniziare l'assemblaggio | Estrarre tutti i componenti dall'imballo e posizzarli su una superficie di lavoro pulita | Consultare tutte le istruzioni di montaggio | Assemblare tutti i componenti secondo le istruzioni contenute nel manuale. Non saltare nessuna fase.


Leia as diretrizes de cuidados e segurança que constam da parte final deste manual | Verifique para se assegurar de que não há peças em falta ou danificadas ANTES de começar a preparar a montagem | Retire todas as peças da embalagem e espalhe-as numa superfície de trabalho limpa | Reveja todas as instruções de montagem | Monte todas as peças de acordo com as instruções do manual. Não salte quaisquer passos.

REQUIRED TOOLS | OUTILS EXIGÉS | HERRAMIENTAS NECESARIAS | BENÖTIGTE WERKZEUGE | BENODIGD GEREEDSCHAP | ATTREZZATURA OCCORRENTE | FERRAMENTAS NECESSÁRIAS




SPATULA | SPATULE | ESPÁTULA | SPACHTEL | SPATEL | SPATOLA | ESPÁTULA

- Use spatula (part "SG8") for easier insertion of panel into profile.
- Utilisez la spatule (partie "SG8") pour une meilleure insertion du panneau dans le profil.
- Utilice una espátula (pieza "SG8") para una mejor inserción del panel en el perfil.
- Benutzen Sie den Spachtel (Bezeichnung "SG8"), um die Platten leichter in die Nut einführen zu können.
- Gebruik spatel (onderdeel SG8) voor het gemakkelijk invoeren van het paneel in het profiel.
- Utilizzare la spatola (parte SG8) per inserire il pannello più facilmente nel profilo.
- Utilize uma espátula (peça "SG8") para facilitar a inserção do painel no perfil.



























































SG8 x2































ASSEMBLY REQUIRES TWO PEOPLE | LE MONTAGE DOIT ÊTRE EFFECTUÉ PAR DEUX PERSONNES | SE NECESITAN DOS PERSONAS PARA ARMARLO | ZWEI PERSONEN ZUR MONTAGE NOTWENDIG | MONTAGE VEREIST TWEE PERSONEN | L'ASSEMBLAGGIO RICHIEDE DUE PERSONE | A MONTAGEM EXIGE DUAS PESSOAS


PARTS LIST

NO.	PART.	Qty.
QF1-2		4
QF1-1		12
QP6		4
QP1		2
QP3		2
DP4		1
QP8		6
SG19		3
SG6		4
SG7-1		1
SG7-2		1
QW1-2		2
QW1-3		2
QW1-1		20
QW2-2		2
QW2-1		4
QW3-1		4
QW3-2		2
QT1-1		1
QT1-2		1
QT1-3		1
QT1-4		1
QT1-5		1
QT1-6		1
QT1-7		1
QT1-8		1
QT1-9		1
QT1-10		1



NO.	PART.	Qty.
DP5		4
PS1		6
PPA1		6
QAP1		2
PPA2		1
QAP3		2
QA3		1
DA1L		1
DA1R		1
SS4		1
SS3		1
SS6		1
PS5		2
QS2		1
BY		2
SG27		2
SG14		4
SG10		2
SG101		2
SG102		2
QR1-2		8
QR1-1		8
QP7		4
QP4		4
QAP2		6
CS2-2		6
CS4-1		3
8-1		2

NO.	PART.	Qty.
8-2		2
SG1		2
SG2		4
DD1-1		1
DD1-2		1
DD1-3		1
DD1-4		1
DD1-5		1
DD1-6		1
DA4		2
DS1		2
DA1		1
DA2		1
DA2R		1
DA2L		1
SG9		5
SG8		2
M01		4
M03-6L		1
M03-7		1
M04		1
Dri II		1
DC		2
Z410		203
Z420		182
ZW413		102
Z425		4
RF7		4
SG20		2




- Use spatula  (part "SG8") for easier insertion of panel into profile.
- Please ensure the panels are all installed on position before screwing.
- Please be mindful of the screw size used during installation; using screws that are too long may damage the shed.




FLOOR ASSEMBLY





● Fully fit the panel inside the profile



● The crease line of the floor must be underneath





When installing the floor, when the textured face up to have the floor installed in a flat state.



Step 1


1-1



SG8




QF1-1





3 PC

QF1-2



1 PC

1-2



● Fully fit the panel inside the profile

QP3



2 PC


SG6



2 PC

Step 2

2-1



SG8



QP6




1 PC

QP8




2 PC


2-2




● Fully fit the panel inside the profile



2-3




● Fully fit the panel inside the profile




Step 3

Pay attention to the direction of the board



3-1




3-2




3-3




● Fully fit the panel inside the profile



● Fully fit the panel inside the profile




QF1-1



3 PC

QF1-2



1 PC

QP8




2 PC

QP6




1 PC

SG8





3-4




Spin around

3-5


$ab=cd$



The panel texture should be aligned.




Step 4



Screw along the marked lines in profile



SG19



1 PC

Z410




12 PC

Z420




16 PC



4-1




4-2




Step 5





● Fully fit the panel inside the profile



● Fully fit the panel inside the profile



5-1




QP6



1 PC

SG19



1 PC

Z420




2 PC

QF1-1




3 PC

QF1-2








1 PC

5-1




Pay attention to the direction of the board


Step 6

QP6  1 PC	QF1-2  1 PC	QF1-1  3 PC	QP8  2 PC	SG8 
---	---	---	--	---


6-1




6-2




6-3







6-4




6-5



The panel texture should be aligned




● Fully fit the panel inside the profile




● Fully fit the panel inside the profile


Step 7



Screw along the marked lines in profile



SG19



1 PC

Z410





12 PC

Z420



10 PC



Step 8

SG8




SG7-2



1 PC

DP4




1 PC

SG7-1



1 PC

QP1





2 PC



SG6



2 PC




● Fully fit the panel inside the profile




Step 9


9-1




9-2









9-3





WALL ASSEMBLY




Step 10

DP5  2 PC	PPA2  1 PC	PPA1  1 PC	QW2-2  2 PC	QW2-1  4 PC	QW1-1  6 PC
---	--	--	--	---	---

10-1



● Fully fit the panel inside the profile




● Fully fit the panel inside the profile


SG8




10-2











10-3





10-4



10-5















Step 11




● Fully fit the panel inside the profile

● Fully fit the panel inside the profile

PPA1  5 PC	QW1-2  2 PC	QW1-3  2 PC	QW1-1  8 PC
			SG8 



Step 12



● Fully fit the panel inside the profile

SG8



QPA1




2 PC

DP5




2 PC

QW1-1




6 PC



12-1





12-2






● Fully fit the panel inside the profile



12-3





Step 13





Step 14




14-1






14-2

Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.




- SS6**

1 PC
- ZW413**

4 PC
- Z410**

14 PC

14-3





Step 15

15-1




QT1-8 1 PC	QT1-7 1 PC
QT1-10 1 PC	B Y 1 PC
QT1-9 1 PC	Z410 2 PC
QT1-6 1 PC	

15-2




15-3



Step 16

16-1



SG8



Z410



14 PC

QW3-2




2 PC

QW3-1



4 PC

DA1L



1 PC

DA1R




1 PC

QAP3




2 PC




16-2



16-3








16-4




Step 17


17-1




17-2



17-3



QT1-3



1 PC

Z410




2 PC

BY




1 PC

QT1-2




1 PC

QT1-4



1 PC

QA3




1 PC

QT1-1



1 PC

QT1-5



1 PC


ZW413






4 PC


Step 18

18-1




Z420	ZW413	SG27
		
10 PC	8 PC	2 PC


AB=CD





Please keep both sides QAP3 on a line



18-2




18-2



Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



Step 19

19-1





19-2

Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.








19-3





Step 20

20-1




Pay attention to the placement of QS2








Z410		7 PC
ZW413		8 PC
PS5		2 PC
QS2		1 PC
SS4		1 PC
SS3		1 PC





20-2



Pay attention to the placement of SS4






Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



Step 21

21-1




8-1



2 PC

RF7








4 PC

Z410




4 PC




21-2




ROOF PARTS





Fully fit the panel inside the profile






The stripes should be upwards



Step 22








The stripes should be upwards



Step 23

QAP2




x2

Step 24


Z410



24 PC











Make sure the sheet and profiles are in place before nailing




x2

Step 25

QP7  4 PC	Z410  8 PC
QP4  4 PC	SG20  2 PC
SG2  4 PC	SG8 
Z420  8 PC	 Fully fit the panel inside the profile



25-1

Flip the panel.




x2

25-2




Please note the installation location



x2




25-3

A=B
C=D



x2

25-4



x2


Step 26

Z420



26-1


Flip the panel.








x2

26-2

x2



26-3



Fully fit the panel inside the profile


Step 27

Fully fit the panels inside the profiles of roof



SG8



27-1








outside



27-2


QAP2 and PPA1 should be aligned once the roof is installed.



Z420





20 PC





Step 30

30-1



Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.




30-2






Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



ZW413		6 PC
8-2		2 PC
Z410		4 PC
SG1		2 PC
Z425		4 PC



30-3




Step 31




PS1

6 PC
ZW413

24 PC







Attention to the location of the screws: they need to be locked on the iron pipe that corresponds to the inside of the plastic profile.



Step 32






SG14

4 PC
Z420

4 PC




x4

Step 33

Window section




SG10



2 PC

SG101



2 PC

SG102




2 PC

Z410




32 PC

A-1




A-2




- Remove the film before fixing SG101



- Two persons are needed for this step, to press SG10 from outside and inside.




A-3






DOOR SECTION



Door mount this is above



SG8




The stripes should be outside



The boards must be straight

Step 34




34-1




DD1-3 1 PC	DD1-2 1 PC
DD1-5 1 PC	DD1-6 1 PC
DD1-1 1 PC	
DD1-4 1 PC	
SG9 5 PC	



34-2




Step 35



Step 36


LEFT DOOR





Step 37


RIGHT DOOR

37-1




DA4

1 PC
DS1

1 PC


37-2




37-3



Step 38




Step 39




Step 40


40-1



40-2




M03-6L



1 PC

M03-7




1 PC

Z410




12 PC

MO1






4 PC






M03-6L + M03-7

40-2



Don't fasten the screws in this step to adjust the positions of doors

Step 41



Nail the door after place adjustment and fasten all the screws.

Step 42

