

# ASSEMBLY INSTRUCTIONS

---

## TOOLS REQUIRED


Allen Wrench

(Included)



Philips  
Screwdriver

(Not Included)



2 - Persons  
Recommended

## ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



## CHECK BEFORE STARTING

### Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

### Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

### Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

### Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



## Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



## Suitable Location

Assembling near the area of the intended location is highly recommended.




## Sufficient Space

Make sure you have enough space to move around during the assembly.



## Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



## Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


# ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY  
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly  
and insert screws or bolts into  
their respective holes.




Turn clockwise to tighten and  
only tighten when step is  
completed or when instructed  
to do so.



Use the appropriate hand tools  
or power tools for assembly.  
Select steps, such as tightening  
screws and/or bolts, may require  
hand tools to avoid causing  
damage during assembly.




Save the instructions and store  
any supplied tools for later  
maintenance.




After two weeks, check and  
tighten any loose hardware and  
repeat again every six months  
thereafter.

**IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.**



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




## PARTS

DESCRIPTION OF COMPONENT						
ITEM NO	WORK PIECE DESCRIPTION	MEASUREMENT	QTY	COLOUR	SHAPE	PACK IN BOX
(1)	LOWER SIDE BOARD (L)	2224*651*15	1	PINK		1/5
(2)	LOWER SIDE BOARD (R)	2224*651*15	1	PINK		1/5
(3)	U-SHAPED IRON	1910*15*15	3	SILVER		1/5
(4)	LOWER BACK BOARD	1000*465*15	1	PINK		2/5
(5)	UPPER FRONT PANEL	1000*400*15	1	PINK		2/5
(6)	UPPER BACK BOARD	1000*330*15	1	PINK		2/5
(7)	LOWER FRONT PANEL	1000*380*15	1	PINK		2/5
(8)	UPPER SIDE BOARD (L)	1033*714*15	2	PINK		3/5
(9)	LADDAR (L)	380*212*15	2	PINK		3/5
(10)	HARDWARE	203*159*32	1	-		3/5
(11)	LADDAR (R)	380*212*15	2	PINK		3/5
(12)	LARGE CURTAIN	1650*1000*1	1	PINK		3/5
(13)	SMALL SURTAIN	890*305*1	1	PINK		3/5
(14)	UPPER SIDE BOARD (R)	1033*714*15	2	PINK		3/5
(15)	IRON FRAME	1030*215*25	2	WHITE		4/5
(16)	STEP BOARD	377*160*25	2	PINK		4/5
(17)	DECORATE PIECE	120*120*15	2	PINK		4/5
(18)	SQUARE PIPE	1000*25*25	5	WHITE		4/5
(19)	ROUND PIPE	970*12.7	4	WHITE		4/5
(20)	PLYWOOD SLAT	995*62*12	13	WHITE		4/5
(21)	SMALL ROUND PIPE	540*12.7	4	WHITE		4/5
(22)	WHEEL COVER	550*550*15	4	PINK		5/5

MODEL : CM7630 (1000\*1920)

## HARDWARE

A	B	C	D	E	F	G
M6*50 QTY:42	M6*55 QTY:32	M6*55 QTY:4	M6*25 QTY:16	M6*12 QTY:8	M6*12 QTY:12	4*10 QTY:8
H	I	K	N	□	J	
M6*30 QTY:8	D22 QTY:4	QTY:5	QTY:26	QTY:8	QTY:50	



# ASSEMBLY INSTRUCTIONS


Align panel (#7) to side boards (#1,2), then secure by using bolts (#A) with washers (#J) to barrel nuts (#B) with barrel nut caps (#B).

1

B   QTY:4

A  M6\*50  
QTY:4

J  QTY:4



Tip: Place parts on the flat level surface to ease alignment and assemble.


2

B   QTY:4

A  M6\*50  
QTY:4

J  QTY:4

Align panel (#4) to side boards (#1,2), then secure by using bolts (#A) with washers (#J) to barrel nuts (#B) with barrel nut caps (#B).



# ASSEMBLY INSTRUCTIONS


3

B   QTY:4

A  M6\*50  
QTY:4

J  QTY:4

Align back upper board (#6) to side boards (#1,2), then secure by using bolts (#A) with washers (#J) to barrel nuts (#B) with barrel nut caps (#B).




4

A  M6\*50  
QTY:10

J  QTY:10

Align square pipes (#18) to the holes of the side panels, then secure by using bolts (#A) with washers (#J).



# ASSEMBLY INSTRUCTIONS


5

D



M6\*25  
QTY:1

Align wheels (#22) to back of the side panels, then secure by using bolts (#D).




6

D



M6\*25  
QTY:1

Align wheels (#22) to back of the side panels, then secure by using bolts (#D).



# ASSEMBLY INSTRUCTIONS


7

D



M6\*25  
QTY:1

Align wheels (#22) to front of the side panels, then secure by using bolts (#D).




8

D



M6\*25  
QTY:1

Align wheels (#22) to front of the side panels, then secure by using bolts (#D).



# ASSEMBLY INSTRUCTIONS

9

Align iron frame (#15) to wheel and side panels, then secure by using bolts (#F) and bolts (#C) with washers and caps (#I).

C



M6\*55  
QTY:2

I




M22  
QTY:2

F



M6\*12  
QTY:2



10

Align iron frame (#15) to wheel and side panels, then secure by using bolts (#F) and bolts (#C) with washers and caps (#I).

C



M6\*55  
QTY:2

I




M22  
QTY:2

10

F



M6\*12  
QTY:2



# ASSEMBLY INSTRUCTIONS

## 11


B  QTY:8

A  M6\*50  
QTY:8

J  QTY:8


11

Align side ladder panels (#9,11) to the step board (#16), then secure by using bolts (#A) with washers (#J) to barrel nuts (#B). Cover barrel nuts (#B) with barrel nut caps (#B).




## 12

B  QTY:8

A  M6\*50  
QTY:8


Align ladder steps to the side panels, then secure by using bolts (#A) to barrel nuts (#B). Cover barrel nuts (#B) with barrel nut caps (#B).



# ASSEMBLY INSTRUCTIONS

13

Align U-shaped iron (#3) to the middle of the bed.




14

K



QTY:5


Secure U-shaped iron to bed by using brackets (#K).



# ASSEMBLY INSTRUCTIONS

Align U-shaped irons (#3) to the inner side of the bed.


15



16

N  QTY:26

Attach end caps (#N) to the slats (#20).




13X

# ASSEMBLY INSTRUCTIONS

17

Attach slats to U-Shaped irons on the sides.




13X

18

Align upper front panel (#5) to the side panels, then secure by using bolts (#A) with washers (#J) to barrel nuts (#B). Cover barrel nuts (#B) with barrel nut caps (#B).

- B  QTY:4
- A  M6\*50  
QTY:4
- J  QTY:4




# ASSEMBLY INSTRUCTIONS




## 19

- E  QTY:4
- H  M6\*30  
QTY:4
- J  QTY:4


Align upper side boards (#8,14) to the side panel, then secure by using bolts (#H) with washers (#J) to nuts (#E).



## 20

- E  QTY:4
- H  M6\*30  
QTY:4
- J  QTY:4

Align upper side boards (#8,14) to the side panel, then secure by using bolts (#H) with washers (#J) to nuts (#E).



# ASSEMBLY INSTRUCTIONS


Align decorate piece (#17) to upper side boards, then secure by using bolts (#D).

## 21

D



M6\*25  
QTY:4



## 22

F




M6\*12  
QTY:4

Align L brackets (#O) to round pipes (#21), then secure by using bolts (#F).

O




QTY:4



# ASSEMBLY INSTRUCTIONS

23

Insert small curtains (#13) to the round pipes (#21).



24

F




M6\*12  
QTY:4

O



QTY:4

Align L brackets (#O) to round pipes (#21), then secure by using bolts (#F).



# ASSEMBLY INSTRUCTIONS


## 25

G



4\*#10  
QTY:4

Align L bracket of curtains to upper side boards, then secure by using screws (#G).




## 26

G



4\*#10  
QTY:4

Align L bracket of curtains to upper side boards, then secure by using screws (#G).




# ASSEMBLY INSTRUCTIONS

27

D  M6\*25  
QTY:4


J  QTY:4

Align round pipes (#19) to upper side boards, then secure by using bolts (#D) with washers (#J).



28


Align round pipes (#19) to the large curtain (#12).



# ASSEMBLY INSTRUCTIONS

29


Put large curtain onto the top of the bed.



30

Secure round pips (#19) on the large curtain by using bolts (#D) with washers (#J).

-   M6\*25  
QTY:4
-   QTY:4



## ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

# More Information

---

- User Age: 36 Months Or Above.
- Standard Of Paint:

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

- Information regarding maintenance  
Use dry, clean & soft cloth rub on the surface regularly; must not use any wet cloth, hardware or any hard material (such as keys, knife, sand-paper) rub on the surface. Keep away from water and any chemical substances.
- Conditions for use of the product domestic
- Installation only to be carried out by a competent person
- Article consists swallowable small parts, children  $\leq 3$  years should not be without parental guidance (surveillance or monitoring)
- Screw lock must be inserted before joining
- For the safety reason all of the hardware must be screwed tidely.
- This Product must be assembled by adult
- To avoid surface damage, tight all serew must not use over 5Nm power.
- Use only mattress which is 74"-75" long, 37.5"-38.5" wide and 4"-6" height.