

AWF605-SY




Please thoroughly review the installation instructions prior to commencing the installation process. Ensure that all tools are utilized appropriately and with due care. Should you encounter any questions regarding the product or the installation procedure, do not hesitate to contact us. We will make every effort to assist you in resolving any issues.



boniture@outlook.com

We aim to provide you with a distinctive experience.

Before You Start





- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware of to slow down and stop when screw is tight. Failure to do so may result in stripping the screw. (Assembly speed can be increased by using electric screwdriver)

Helpful Hints


PEOPLE NEEDED FOR ASSEMBLY: 1-2

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with an **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- If there is a back panel in the package, please install it to make sure your unit is complete and sturdy.
- Please fix all the screws provided for the back panel which can enhance product stability. If it is difficult to fix it when tightening, it can be fixed with the help of a hammer and then tightened.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.




Board Identification


Not actual size




①
LEFT FOOT
Qty:1




②
RIGHT FOOT
Qty:1




③
LEFT RAIL
Qty:1




④
RIGHT RAIL
Qty:1



⑤
MIDDLE RAIL
Qty:1
















⑥
LEFT PANEL
Qty:1




⑦
RIGHT PANEL
Qty:1

Part List

 Ø15X9.5mm (A) X14	 Ø6.5X35mm (B) X8	 Ø8X30mm (C) X4	 Ø3.5X14mm (D) X13	 Ø4X35mm (E) X12
CAM LOCK spare:1	CAM BOLT spare:1	WOODEN DOWEL spare:1	SCREW spare:1	SCREW spare:1
 6X25mm (F) X12	 (G) X1	 (H) X1	 (I) X1	 (J) X1
BOLT spare:1	LIGHT STRIP	ADAPTER	U-SHAPED PLASTIC CLIP	KEY
 (K) X6	 (L) X5	 Ø6.5X48mm (M) X3		
CONNECTING BUCKLE	FOAM PAD	CAM BOLT		


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.














Board Identification


Not actual size



STEP 1






Insert the cam bolt into the hole first, then insert the cam lock and lock it.







Proper orientation of CAM LOCK



STEP 2








STEP 3



With cam bolt M centered and horizontal, tighten both cam lock A simultaneously.









STEP4



Before installation, please remove the adhesive tape protective film on the back of the sponge mat and then stick it to the board.






STEP 5




 G

Before installation, please remove the adhesive tape protective film on the back of the light strip and then stick it to the board.

STEP 6



1. drill twelve Ø6 holes on the wall



2. put twelve anchors in the holes

STEP 7

