




























Kitchen Cart



PART LIST


A 	B 	C 	D 	E 
Top Panel 1 PC	Drop Leaf 1 PC	Left Frame 1 PC	Right Frame 1 PC	Bottom Panel 1 PC
F 	G 	H 	I 	J 
Partition Panel 1 PC	Adjustable Shelf 2 PCS	Back Panel 2 PCS	Left Door 1 PC	Right Door 1 PC
K 	L 	M 	N 	O 
Drawer Front Panel 2 PCS	Drawer Left Panel 2 PCS	Drawer Right Panel 2 PCS	Drawer Back Panel 2 PCS	Drawer Bottom Panel 2 PCS
P 	Q 	R 	S 	T 
Back Rail 1 PC	Hanging Bar 1 PC	Front Rail 1 PC	Back Slat 1 PC	Support Rail 2 PCS

HARDWARE LIST

#1  Ø3*15mm	#2  Ø3.5*15mm	#3  Ø3*30mm	#4  Ø5/32**22mm	#5  Ø1/4**1-1/2"
Round Head Screw 4 PCS	Short Screw 38 PCS (Extra 1)	Screw 8 PCS (Extra 1)	Round Head Bolt 8 PCS (Extra 1)	Bolt 2 PCS
#6  Ø1/4**3"	#7  Ø1/4"	#8  Ø8*30mm	#9 	#10 
Long Bolt 4 PCS	Barrel Nut 4 PCS	Wood Dowel 10 PCS (Extra 1)	Shelf Holder 8 PCS (Extra 1)	Door Magnet 2 PCS
#11  149*28*10mm	#12 	#13 	#14 	#15 
Handle 4 PCS	Hinge 4 PCS	Top Hinge 3 PCS	Towel Bar 1 PC	Locking Caster 2 PCS
#16 	#17  4mm	#18 		
Caster 2 PCS	Allen Wrench 1 PC	Wrench 1 PC		

ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.


Please do not use tools to assemble this unit unless specifically indicated.




Reference the image above any time the instructions state "lock the hardware" or "insert hardware and pull down to lock".



Be sure to check all hardware is locked when complete.

Step 1. Attach handle (part #11) to drawer front panel (part K) using round head bolts (part #4) and phillips head screwdriver. Insert drawer left panel (part L) and drawer right panel (part M) into drawer front panel (part K) pull down to lock. Slide drawer bottom panel (part O) into grooves of assembled unit (parts K, L & M). Attach drawer back panel (part N) to assembled unit (parts L, M & O) using screws (part #3) and phillips head screwdriver. Repeat for remaining drawer.







Step 2. Attach door magnets (part #10) to front rail (part R) using round head screws (part #1) and phillips head screwdriver.




- #1  x 4
- #10  x 2



Step 3. Attach towel bar (part #14) to left frame (part C) using bolts (part #5) and allen wrench (part #17).




- #5  x 2
- #14  x 1
- #17  x 1



Step 4. Attach top hinges (part #13) to top panel (part A) and drop leaf (part B) using short screws (part #2) and phillips head screwdriver.




#2  x 18
 #13  x 3



Step 5. Attach hinges (part #12) to left door (part I) using short screws (part #2) and phillips head screwdriver.




#2  x 6
 #12  x 2





Step 6. Attach hinges (part #12) to right door (part J) using short screws (part #2) and phillips head screwdriver.




- | | | |
|-----|---|-----|
| #2 |  | x 6 |
| #12 |  | x 2 |

Step 7. Attach right frame (part D) to bottom panel (part E) using wood dowels (part #8), long bolts (part #6), barrel nuts (part #7), allen wrench (part #17) and phillips head screwdriver.




- | | | |
|-----|---|-----|
| #6 |  | x 2 |
| #7 |  | x 2 |
| #8 |  | x 2 |
| #17 |  | x 1 |


Step 8. Attach front rail (part R) to right frame (part D) and lock the hardware.




Step 9. Insert partition panel (part F) to assembled unit (parts E & R) and lock the hardware.




Step 10. Attach back slat (part S) to bottom panel (part E) using wood dowel (part #8).




#8  x 1


Step 11. Slide back panels (part H) into grooves of assembled unit (parts D, E & S).




Step 12. Attach back rail (part P) to assembled unit (parts D & S) using wood dowels (part #8) and lock the hardware.




Step 13. Attach left frame (part C) to assembled unit (parts E, P & R) using wood dowels (part #8), long bolts (part #6), barrel nuts (part #7), allen wrench (part #17), phillips head screwdriver and lock the hardware.




Step 14. Attach locking casters (part #15) and casters (part #16) to frames (parts C & D) using wrench (part #18).




Step 15. Carefully turn unit upright. Insert support rails (part T) into notch of back rail (part P). Attach assembled unit (parts A & B) to assembled unit (parts C, D, F & T), using wood dowels (part #8) and lock the hardware.



Step 16. Slide assembled drawers into place. Put hanging bar (part Q) into notch of right frame (part D).







Step 17. Place shelf holders (part #9) into desired position and then slide adjustable shelves (part G) into place.



#9  x 8

Step 18. Attach doors (parts I & J) to frames (parts C & D) using short screws (part #2) and phillips head screwdriver. Attach handles (part #11) to doors (parts I & J) using round head bolts (part #4) and phillips head screwdriver.



- | | | |
|-----|---|-----|
| #2 |  | x 8 |
| #4 |  | x 4 |
| #11 |  | x 2 |