















OWNER'S MANUAL

**POWER
RECLINER SOFA**


PARTS LIST

<p>A</p>  <p>Right Backrest x1</p>	<p>B</p>  <p>Middle Backrest x1</p>	<p>C</p>  <p>Left Backrest x1</p>	<p>D</p>  <p>Seat Base x3</p>	<p>E</p>  <p>Left Armrest x1</p>	<p>F</p>  <p>Right Armrest x1</p>
<p>D</p>  <p>Massage Remote x2</p>	<p>E</p>  <p>Seat Iron Sheet x4</p>	<p>F</p>  <p>Wrench x1</p>	<p>G</p>  <p>Screw & Washer x16 x16 x8</p>	<p>H</p>  <p>Power Adapter x2</p>	<p>I</p>  <p>Base Feet x4</p>

STEP 1

Install 4 x Part E on two seat base (B), one seat base (B) need 2 x Part E.



NOTE: The Part E needs to be installed on the iron frame, not under the iron frame.



E X 4PCS
G X 8PCS

STEP 2


Fix the two bases with seat iron sheet.




Finished

STEP 3

Make sure that the armrest is fully aligned with the groove when inserting it, and then press down firmly until you hear a "click" sound to complete.




ATTENTION



Ensure the two connections on each armrest are both inserted onto the base tightly.

STEP 4



Make sure that the backrest is fully aligned with the grooves on the left and right sides when inserting, and then press down firmly until you hear a "click" sound.



STEP 5

1. No. ① and No. ② wires from the backrest and seat base with same color connect together.
2. No. ③ wire from the back connects to the wire at the bottom of the seat.
3. No. ④ wire from the back connects to the massage remote.
4. The USB socket in the bottom of the recliner armrest.

NOTE: The connections on the left and right sides are the same.



STEP 6

1. Make sure both metal brackets on each armrest are mounted on the base.

(There are two metal brackets on each side of the base, it looks like assembly finished when you insert armrest into only one bracket instead of two, however all pressure will apply to one bracket, that is one likely reason that the armrest fall apart from the seat.)

2. Make sure the backrest inserts are locked to the base.


(Pull up the backrest to check if it is locked in place.)

3. Make sure all wires are connected tightly.

4. Make sure all wires not placed the bottom of the rack and will not be pressed by frame.

(If the wire is pressed by the frame, the wire will be broken by the frame and the sofa will stop working.)


5. Make sure all the screws are tightened.




REMOTE OPERATION INSTRUCTION

How to recline?


Press and hold the button near the arm rest, and then the footrest starts to release. When reaching a certain height, the backrest starts to lie down until the maximum angle.



How to get footrest latch down?



HOW TO USE THE MASSAGE REMOTE?



1. POWER: Turn on/off remote control.

2. HEAT: Turn on/off the heating function for the backrest.
(Heating function works with vibration separately.)

3. MODE: Set different massage modes.

4. TIMER: The timer can be set in fixed time 10/20/30 minutes.

5. POINTS: Control massage points (back, lumbar, thigh, and leg) individually.

6. INTENSITY: Select the strength of the massage function (low, medium, high).

TROUBLESHOOTING

The following troubleshooting FAQs should summarize what you need to know about your recliner sofa. If at any time you do not feel comfortable performing the troubleshooting steps listed in this manual, please contact MCombo Customer Support for service.

Questions	Answers
<p>What if my power recliner sofa does not operate at all?</p>	<ul style="list-style-type: none"> • Make sure all the connections are secured; refer to the Assembly Instructions. • Check all the electrical cords are not crimped or pinched. • Check if the light of the RED button at the back of the base is on. • Make sure the light of the control buttons on the armrest and goes on.
<p>What if the reclining function doesn't work?</p>	<ul style="list-style-type: none"> • Make sure all the wires of the sofa are intact and connected properly. • Check if the RED light on the switch is on. • Make sure the lights of the control buttons are on. • Connect the power adapter and armrest separately to the good side to test whether they work properly.
<p>What if the massage and heat do not work?</p>	<ul style="list-style-type: none"> • Make sure all the wires of the sofa are intact and connected properly. • Check if the RED light on the switch is on. • Make sure the lights of the massage remote are on. • Connect the power adapter, and massage remote, and backrest separately to the good side to test whether they work properly.
<p>What if the USB charge ports do not work?</p>	<ul style="list-style-type: none"> • Make sure the massage and reclining functions are both effective. • Make sure the USB cable coming out of the armrest is properly connected. • Check if the GREEN light on the USB charge port goes on.
<p>What if the armrest falls apart from base?</p>	<ul style="list-style-type: none"> • Ensure the two connections on each armrest are all inserted onto the base tightly. • Check the brackets of armrest and base to ensure there is no defects.
<p>What if my recliner sofa makes a clicking noise?</p>	<ul style="list-style-type: none"> • Check to make sure the frame, motor and wiring are intact. • Make sure the weight capacity of 320 lbs has not been exceeded.
<p>What if my recliner tilted to one side?</p>	<ul style="list-style-type: none"> • Make sure the rack of recliner sofa is in a good condition without any distortion.

IMPORTANT: If the product still does not operate properly, please contact the MCombo Customer Support for help and never attempt to make any repairs or adjustments yourself.

PRODUCT CARE

Dust regularly with a soft, dry cloth to prevent soil build-up. Keep away from heat to avoid glazing, melting or scorching. Use a professional cleaning service to clean the fabric.

WARRANTY

Electronic Parts	1 Year
Reclining Mechanism	1 Year
Metal/ Wood Chair Frame	1 Year

All the products come with a 30-day return/replacement policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged products, by providing pre-paid return labels or pick-up service for customer convenience

Note: Please disassemble the product before you return it otherwise there will be a huge cost as oversized.

WARNING

- Proper assembly of this item requires 2 people.
- This product is not intended for institutional or commercial use.
- Read all instructions before assembling this product.
- FALL HAZARD – To prevent death or serious injury, always keep child within arm's reach.
- Avoid placing this item in direct sunlight to prevent fading.
- Check this product for damaged hardware, loose joints, missing parts or sharp edges before and after assembly and frequently during use.
- To avoid tipping over, do not put your weight against the back or get up before returning the product to the seated position.

RETURN/REPLACEMENT POLICY

MCOMBO®

All of product come with a 30-day return/replace policy. During this time, we will cover the shipping cost of return and replacement for defective and damaged product, through providing pre-paid return label or pick-up service for customer convenience.

NOTE:

- (1) Please keep the original packaging in case the product needs to be returned. If the original packaging is not available, the newly found packaging needs to meet the following size standard:
UPS/FedEx packaging size standard: (width+ height) * 2+ length< 128 inch.
- (2) Please disassemble the chair before you return it, otherwise there will be a huge cost as oversized and it could even exceed your order amount.
- (3) Please do not purchase return label for a damaged/defective chair by yourself.
- (4) If you have any problem to return the chair, please contact us immediately, we will do our best to help you with a reasonable solution.

Why don't we recommend returning the item by yourself?

- Huge cost
- Need you to take the box to FedEx facility

MCombo®



Mcombo.com



Amazon.com/mcombo

Newacme LLC, 2808 Vail Ave, Commerce, CA, 90040

sales@mcombo.com

1-323-597-1109 (8:00 a.m. - 4:00 p.m. (Monday - Friday) TIME ZONE: PST)