


# SHOE CABINET

## Assembly Instruction




# General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: hex key, footpads and bolts.
- V. Power tools should not be used to assemble this product.




## Cam Lock Fastening System
























Insert the cam bolt into the hole first, then insert the cam lock and lock it.




# Parts List




# Hardware List

A		M6x35mm	Screw	20 pcs
B			Screw	16 pcs
C		M4x35mm	Bolt	6 pcs
D		M3.5x12mm	Bolt	28 pcs
E		M5x40mm	Bolt	4 pcs
F		M4	Hex Key	1 pc
G			Cork	6 pcs
H		M4x20mm	Bolt	4 pcs
I			Door handle	4 pcs
J		M4x14mm	Bolt	2 pcs
K			Iron sheet	2 pcs
M			Bolt	2 pcs
N		M3x16mm	Bolt	12 pcs
O			Plastic parts	8 pcs
P		M4x10mm	Bolt	2 pcs
Q			Iron sheet	2 pcs
S			Bolt	8 pcs
T			Door shaft	4 pcs
U			Iron sheet	4 pcs
V			Magnet	2 pcs
W			Iron sheet	4 pcs
X		M3x12mm	Bolt	4 pcs
Y			Screw	4 pcs


# Step 1





A	X12
	
M6x35mm	

# Step 2

Please pay attention to the directions of arrow sign on slide during installation.




D	X3
	
M3.5x12mm	




Q	X1
	

### Step 3

Please pay attention to the directions of arrow sign on slide during installation.




### Step 4




V	X1	N	X2	G	X1	B	X6
		 M3x16mm					


# Step 5





# Step 6




# Step 7





K	X2
	


J	X2
	
M4x14mm	

A	X4
	
M6x35mm	


# Step 8




G	X2
	


B	X4
	


# Step 9




# Step 10




V	X1
	

N	X2
	
M3x16mm	


# Step 11




# Step 12




# Step 13



# Step 14




# Step 15




# Step 16


Adjust the layer board freely according to the height of the shoes.




# Step 17




# Step 18




# Step 19










C	X4
	
M4x35mm	

# Step 20





# Step 19





A	X4	Y	X4	I	X2	H	X2
							
M6x35mm						M4x20mm	


# Step 20



D	X2
	
M3.5x12mm	

# Step 21



P	x2
	
M4x10mm	