












Description	QTY	Illustration	Description	QTY	Illustration
Trailer frame body	1		M14*40*15 Hexagon bolts	6	
Connecting bracket left	1		φ12*25 Flat washers	10	
Connecting bracket right	1		φ12 Lock washers	6	
M12 Hexagon nuts	4		φ14*30 Flat washers	6	
M12*35 Hexagon bolts	6		φ14 Lock washers	6	

Tools Required

Torque Wrench, Ratchet, 22mm Socket, 6" Extension, Wire Pipe Brush



Before Installation

REMOVE CONTENTS FROM BOX AND VERIFY ALL PARTS ARE PRESENT. FAILURE TO IDENTIFY DAMAGE BEFORE INSTALLATION COULD LEAD TO A REJECTION OF ANY CLAIM. IF ANY DAMAGE FOUND, PLEASE TAKE A PICTURE FOR THE CLAIM PURPOSE. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

Warning



THE HITCH WILL HAVE A VISIBLE TOW RATING LABEL AFFIXED DIRECTLY ON THE PRODUCT. USER SHOULD NEVER EXCEED THE VEHICLE MANUFACTURER'S MAXIMUM TOW AND WEIGHT RATING REGARDLESS OF THE CAPACITY OF THE HITCH. TO PROTECT YOUR INVESTMENT, WAX THIS PRODUCT AFTER INSTALLING. REGULAR WAXING IS RECOMMENDED TO ADD A PROTECTIVE LAYER OVER THE FINISH. DO NOT USE ANY TYPE OF POLISH OR WAX THAT MAY CONTAIN ABRASIVES THAT COULD DAMAGE THE FINISH.

STEP 1

Lower spare tire from inside of vehicle.(Fig 1)

STEP 2

Weld nut cleaning may be required. Raise hitch into position and secure with the 14-1.5mm x 40mm Hex Bolts, 14mm Lock Washers and 14x28x2.5mm Flat Washer provided. Torque all 14mm bolts to 87-88 lb-ft.(Fig 2)



STEP 3

Raise spare tire back into place following step 1.(Fig 3)

