


Assembling Instruction



ATTENTION

If there is any missing, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions.


We will send replacement to you asap. We are concerned about each customer's experience, if there is any loss or damage, please contact us at any time, we will provide effective solutions.

Please attach your Oder ID so that we can assist you better.




General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are : wood dowels , screws and bolts.
- VI . A Phillips head screwdriver is required for the assembly of this product .



- VII . Power tools should not be used to assemble this product .






















Parts List



x2

HARDWARE PACK CONTENT



A  M6x35mm 40+4PCS	B  Ø15x9mm 40+4PCS	C  M4x40mm 30+4PCS	D  Ø6x30mm 58+6PCS	E  M3x12mm 12+2PCS
F  M4x16mm 8+1PCS	G  96mm 4PCS	H  6PCS	I  6PCS	J  M3x14mm 12+2PCS
K  Ø20mm 32+4PCS	L  15mm 8PCS	M  M4x12mm 4+1PCS	N  2PCS	O  Ø6x30mm 2PCS
P  M4x12mm 8+1PCS	Q  4PCS	R  M3x12mm 32+4PCS		




Philips head screwdriver required for assembly
(not included)

*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




x2



A x 8PCS

Step 2


Note:The holes on #11 should be upwards




B x 8PCS



D x 4PCS



Step 3





C x 2PCS



D x 2PCS

Step 4





C x 4PCS



D x 4PCS

Step 5






C x 4PCS




D x 4PCS

Step 6



A x 8PCS


Step 7






B x 4PCS



D x 4PCS



Step 8




P x 8PCS



Q x 4PCS


Step 9





B x 4PCS





D x 4PCS



Step 10




180°





C x 2PCS

Step 11



Magnet outward.






I x 2PCS



J x 4PCS


Step 12



A x 8PCS

Step 13


Note: The holes on #2 should be upwards





B x 8PCS





D x 4PCS







Step 14






	C x 2PCS
	D x 2PCS

Step 15




	C x 4PCS
	D x 4PCS


Step 16



Magnet outward.



A x 4PCS




I x 2PCS



J x 4PCS


Step 17





B x 4PCS




D x 4PCS



Step 18






C x 4PCS





D x 4PCS

Step 19




A x 4PCS

Step 20



x2




A x 4PCS

Step 21

Note:


Side with bolts A on #7 should be positioned lower





B x 4PCS





D x 4PCS






Step 22




	C x 2PCS
	D x 2PCS



Step 23



	B x 4PCS
	D x 4PCS



Step 24






C x 4PCS





D x 4PCS


Step 25




! Magnet outward.



A x 4PCS




I x 2PCS



J x 4PCS


Step 26




B x 4PCS









D x 4PCS




Step 27








	E x 12PCS
	F x 8PCS
	G x 4PCS
	H x 6PCS
	L x 8PCS
	R x 16PCS

Step 28



NOTE: The left door is #19 and the right door is #20. the suction iron piece is located above the door




	M x 4PCS
	N x 2PCS
	R x 16PCS

Step 29

Drill 2 holes on the wall at the required position for anti-falling device installation.


WALL







O x 2PCS

Step 30

WALL



Note:According to the distance between the cabinet and the wall,adjust the #N fitting to the appropriate position .and then tighten all the screw on the #N fitting.



C x 2PCS



K x 32PCS



WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- **ALWAYS** install Anti-tip device provided.
- **NEVER** put a TV on this product.
- **NEVER** allow children to stand, climb or hang on drawers, doors, or shelves.
- **NEVER** open more than one drawer at a time.
- Place heaviest items in the lowest drawers.