




# Multifunctional storage

## Assembly Instructions


we recommend using the included manual installation tool for assembly.  
If you choose to use a power drill, please set it to the lowest torque setting  
to prevent over-tightening, which may damage the wooden panels.




# Parts List




X1



X1




X2




X2

# Hardware




A x 74sets




Ø15X9.5MM

B x 74sets




Ø8 x 30MM

C x 25pcs




Ø6 x 30MM

D x 14pcs




3.5 x 12MM

E x 50pcs




3.5 x 35MM

F x34pcs




G x 1sets




300MM

H x 6sets



















3.5 x 12MM

I x34pcs









J x 1sets

## ASSEMBLY MATERIAL




Item no.	Reference Image	Oty.	Item no.	Reference Image	Oty.
①		X1	②		X1
③		X1	④		X1
⑤		X1	⑥		X6
⑦		X6	⑧		X6
⑨		X6	⑩		X6
⑪		X1	⑫		X1
⑬		X2	⑭		X2
⑮		X1	⑯		X1

# ASSEMBLY MATERIAL


Item no.	Reference Image	Qty.
<b>17</b>		X2
<b>19</b>		X1
<b>21</b>		X1

Item no.	Reference Image	Qty.
<b>18</b>		X1
<b>20</b>		X2
<b>22</b>		X1




# Step 1




Install first rail on the left side of board.




# Step 2






Install first rail on the right side of board.



# Step 3


**E**   
3.5 x 12MM  
E x 12


**H**   
HX3





**NOTICE:** To ensure the stability of the structure, please pay attention to the hole position when locking screws. CL slide should lock on the first hole position near the pulley, CR slide lock on the second hole position near the pulley.



# Step 4

**(A)**  AX 4






**(B)**  BX 4

**(C)**  Ø8\*30mm  
CX 5






**(F)**  3.5 x 35MM  
Fx 1








# Step 5








# Step 6








# Step 7







# Step 8




# Step 9








# Step 10







Firstly, use F to secure the No.18 piece and then secure the back plate No.21 and No.22. As shown in the figure:






# Step 11



## Step:1








# Step 12




X 1


# Step 13




## Step:1




X 1






## Step:2



## Step:3








# Step 14







X 1




# Step 15



## Step:1





# Step 16




X 4

# Step 17



# Step 18



WALL

