





STOP!

Before beginning the assembly process, ensure all boxes and parts have been delivered.


ATTENTION: BEFORE START ASSEMBLING TAKE A PICTURE OF THE LABELS ON THE PACKAGES, THIS WILL BE REQUIRED IN CASE THE PRODUCT HAS ANY ASSISTANCE DEMAND.



FOR BEST RESULTS:

- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.





TOOLS REQUIRED








Rear view


Prepare the room before starting the assembly, leaving it completely clean and the area in good condition to start the work.
Use the cardboard of the packaging to separate and support the parts removed from the boxes.



x02

Recommended tools (not included)














N°	Description	Qty.	Box
01	Base	01	01
02	Lower bar	02	02
03	Left side panel	01	02
04	Right side panel	01	02
05	Top panel	01	01
06	Front of the drawer	02	02
07	Left side panel of the drawer	02	01
08	Right side panel of the drawer	02	01
09	Rear panel of the drawer	02	02
10	Base of the drawer	02	01
11	Shelf of drawers	01	02
12	Adjustable shelf	02	01
13	Upper bar	01	02
14	Back panel	02	02
15	Union plastic profile	01	02
16	Left support of slides	01	01
17	Right support of slides	01	01
18	Lower back panel	03	02
19	Left slides	02	01
20	Right slides	02	01





Hardware

A 08x


B 44x

C 44x

D 08x

E 08x

F 08x

G 08x

H 04x

I 22x

J 04x

K 08x


L 08x

M 52x

N 02x

O 02x

P 02x

Q 02x


HOW TO IDENTIFY THE SLIDES?



*plastic wheel always pointed to the ground.







*plastic wheel always pointed to the ground.

WICH HOLES USE TO ATTACH THE SCREWS?



Attention, all the assemblage must be done on the cardboard box or the Styrofoam boards to avoid damage to the parts.


Step 01





ATTENTION!

It is mandatory to apply an additional screw (C) at the position informed, please observe there is no pre hole in the 16 and 17 parts.


Step 02




Using the hardware (G) connect the part (16) onto the part (03) and the part (17) onto the part (04).



Step 03



D = 08x




H = 04x




C = 08x

Connect the hardware (H) onto the part (03) and the part (04) with hardware (C).
Connect the part (16) and part (17) with hardware (D).



Step 04




B = 04x

Connect the part (01) onto the parts (02) with the hardware (B).




M = 04x

Apply the hardware (M) onto the hardware (B).



Step 05




B = 12x

Connect the parts (03) and (04) onto the parts (01) and (02) with the hardware (B).




M = 12x

Apply the hardware (M) onto the hardware (B).



Step 06




B = 04x

Connect the part (18) onto the parts (03) and (04) with the hardware (B).




M = 04x

Apply the hardware (M) onto the hardware (B).



Step 07




B = 04x

Connect the part (18) onto the parts (03) and (04) with the hardware (B).




M = 04x

Apply the hardware (M) onto the hardware (B).



Step 08




B = 04x

Connect the part (11) onto the parts (03) and (04) with the hardware (B).




M = 04x

Apply the hardware (M) onto the hardware (B).



Step 09




B = 04x

Connect the part (18) onto the parts (03) and (04) with the hardware (B).




M = 04x


Apply the hardware (M) onto the hardware (B).



Step 10





A = 04x




J = 02x


Connect the part (13) onto the part (05) with the hardware (A + J).



Step 11




B = 04x




M = 04x

Connect the part (05) onto the parts (03) and (04) with the hardware (B).

Apply the hardware (M) onto the hardware (B).





Step 12




I = 22x


Connect the parts (14) joining the part (15) using the hardware (I).



Step 13





A = 04x



J = 02x

Connect the part (13) onto the part (03) and (04) with the hardware (A + J).




Assembling the drawers

Step 14



E = 08x

Apply the hardware (E) into the part 06.



Step 15







F = 08x



M = 08x



Connect the parts 07, 08 onto the part 06 with the hardware F.




Apply the hardware (G) onto the hardware (E).

Step 16

Apply the part 10 in the groove of the parts 07, 08 until the groove of the part 06.



Step 17




B = 08x


Connect the part 09 onto the parts 07, 08 with the hardware (B).



M = 08x

Apply the hardware (M) onto the hardware (B).






Step 18

L = 04x



C = 04x

Apply the hardware (L + C) into the groove of the part 06 as shown on detail.



**Step 19**

L = 04x





C = 04x

Apply the hardware (L + C) into the groove of the part 09 as shown on detail.




Step 20



You must apply the screws
on the holes
indicated by the arrows.




*plastic wheel always pointed
to the rear panel of the drawer
part 09.



Step 21



Apply the hardware (N) into the parts (03) and (04) to support the part (12)




Step 22




K = 08x

Apply the hardware (K) into the parts (03) and (04) to support the part (12)



Step 23




Install the drawers fitting it into the slides (19) and (20).

Attention! Tipover system.

Step 24


First, approach the furniture as close as possible to the wall.




Attention! Tipover system.

Step 25

You will need a pencil to mark where you should drill the wall with a 3/8" drill bit to put in the hardware (P).





Use the 3/8" drill bit to drill the wall.




Attention! Tipover system.

Step 26

Press the wings of the hardware (P) and put it in to the hole that you drilled on the wall.




Connect the hardware (Q) on the wall, using the hardware (O).





Attention! Tipover system.

Step 27



C = 04x

Connect the hardware (Q), onto the part 05 with the hardware (C).



WARRANTY POLICY

All furniture products are warranted, to the original purchaser at the time of purchase and for a period of 30 days thereafter.

Our warranty is limited to new products purchased in factory sealed cartons.

In order to provide you with timely assistance, please thoroughly inspect your furniture for missing or defective parts immediately after opening the carton.

Manhattan Comfort offers a 30-day parts replacement warranty on all items.

Our furniture products are not intended for outdoor use.

THE WARRANTY DOES NOT COVER:

- Defects/damages by improper assembly or disassembly.
- Defects/damages caused by shipping. Claims for damage during transit should be placed immediately to the transportation company.
- Defects/damages caused by inappropriate use of the furniture.