

Mass: 122.2 kg


SHIRE
BUILT AROUND OUR REPUTATION



Follow and Tag Us: @shiregardenbuildings

© Gazebo 2020

Batch No: 6147



Mass: 122.2 kg

These instructions are for your safety. Please read through them thoroughly before use.
PLEASE KEEP THIS LEAFLET FOR FUTURE REFERENCE

PT

GAZE0706DSL-1AA

5060437982213

Let's get started...

Important information...



| | |
|-------------------------------|----|
| Safety | 03 |
| Preparation of base | 04 |
| Warranty | 04 |
| Care, maintenance & Recycling | 05 |

In more detail...



| | |
|----------------------------|-------|
| Parts List | 06 |
| Fascia & Nail List | 07 |
| Detailed Technical Drawing | 08-09 |
| Hardware Chart | 10 |
| Before you start | 11 |
| Assembly instructions | 12-23 |

Like us, Follow us, Recommend us & Tag us



Shire Garden Buildings



@shiregardenbuildings



Shire Garden Buildings



customerservice@shiregb.co.uk



Brigstock Road Wisbech Cambridgeshire PE13 3JJ
Tel 01945 465 295

Safety

Check that you have noted all the following instructions:



- We advise the use of non slip protective gloves throughout the assembly process.
- We advise the use of steel capped protective footwear throughout the assembly process.
- We advise that you use a helper to hold the glass in position whilst you nail the beading in place.
- We advise the use of protective headwear and safety goggles throughout the assembly process.
- Where a ladder is in use another person must hold the ladder.
- Do not attempt to work in windy conditions.
- We advise the use of a scaffold tower when fitting the roof, for felting or if you cannot reach from the ground.
- Do not allow children near the tools and work area.
- Follow any safety precautions quoted by the manufacturer for any equipment you use.
- Check all parts before assembly.
- Only use child and animal safe wood preservative.
- Do not use creosote.
- Allow the wood preservative to fully dry before use.
- Regularly check the building for wear and tear.



Important!



EVERY PRECAUTION IS TAKEN TO ENSURE THAT YOUR BUILDING HAS NO ELEMENT INCORRECTLY PLACED OR POSSIBLY HAZARDOUS, HOWEVER PRIOR TO USE PLEASE CHECK ALL SURFACES FOR THE FOLLOWING:

- (1) RAISED GRAIN, SPLINTERS: Sand down timber to smooth finish.
- (2) NAIL/SCREW/PIN HEADS PROUD: Tap home to be flush with surface of timber.
- (3) DAMAGED SCREW HEADS RESULTING IN SHARP SPLINTERS OF METAL: Replace.
- (4) SHARP ENDS OF NAILS/ SCREWS/ PINS PROTRUDING THROUGH THE PANEL: Remove and reposition.
- (5) ENSURE ALL PARTS ARE SECURED AGAINST REASONABLE FORCE: Remove and refi.
- (6) ENSURE THERE ARE NO LOOSE PARTS: Remove and refit/discard.



IMPORTANT ! For your safety please read carefully the safety warnings

Preparation of base...

We recommend that the base onto which your building will stand should be at least 75mm larger in each direction than the total floor size of the building.

- **Actual floor area of the building:** 2156mm x 1867mm
- **Total height clearance:** 2680mm
- **Roof size:** 2410mm wide x2080mm long

The chosen position in your garden for your building should be excavated to a depth of 75mm to allow a base of sand, on to which paving slabs can be evenly laid. You may also use an adjustable timber base or a concrete base. Whatever base you decide upon IT MUST BE LEVEL AND FIRM.

Warranty...

10 Year anti rot warranty subject to the following:

- The building must be raised so it is not in contact with any water retaining base surface (for example grass)
- This can be achieved using a timber, concrete or slab base
- When using a concrete or slab base use damp proofing strips under the bearers
- The building must have been completely treated and sealed immediately prior to or after assembly
- The building must have been re-treated and re-sealed annually

NOTE: Wood is a natural product and therefore the following are excluded from the warranty:

- Colour change
- Warping
- Splitting.

The following are also excluded:

- Damage resulting from poor assembly
- Poor treatment application
- Poor care and maintenance
- Changes to the design
- Misuse
- General wear and tear.

Care, Maintenance and Recycling

The 5 golden rules of care:

- (1) Ensure your base is level and firm.
- (2) Ensure the building is not sitting directly on the ground using damp proof membrane or the optional timber base.
- (3) Ensure every piece of timber and surface, especially that is hidden upon assembly is treated with a top quality wood preservative at least twice (before assembly). Turn the panels upside down whilst painting so the treatment runs into the seams.
- (4) Garden buildings are not waterproof, therefore you must seal between all the panels with a silicone based sealant.
- (5) Regularly check your roofing felt for weather damage and leaks.

The 6 golden rules of maintenance:

- (1) Visually check for weather damage.
- (2) Check and replace if necessary any Silicone sealant if used on your building.
- (3) Check the roofing material for wear.
- (4) The doors and windows may require periodical adjustment.
- (5) Ensure your building is well ventilated especially during hot weather.
- (6) During extremely hot periods humidify your building to prevent the timber from drying out.

Recycling and disposal:



packaging

1. Pallet and timber widely recycled
2. Cardboard widely recycled
3. Plastic strapping subject to local regulations
4. Plastic sheeting subject to local regulations.




Building


1. Timber widely recycled
2. Metal fixings widely recycled
3. Glass widely recycled
4. **Roofing felt not currently recycled.**

Stacked Parts List


FLOOR HALF
(A3956)x02




PLAIN PANEL
(A5633)x03




ROOF
(A4080)x06




RAIL
(A3963)x02




CORNER POST
(A4069)x06



FELT STRIP 8m
(A4081)x01




FINIAL & SCREW SET
(A0111)x01




Fascia Bag Parts List


ROOF TRIM
(A4082)x06




CAP 990
(A5660)x02



TOP BRACE
(A3964)x03



BLOCK 34X34
(A5658)x06



In more detail.....

FINIAL
A0111


DOUBLE ENDED SCREW
A4029


FELT STRIP 8M
A4081

CORNER POST 44X88
A4069

CAP 990mm
A5660

FLOOR PANEL
A3956






In more detail.....

Hardware Chart Scale 1:1


13mm Felt Nail
(A0023) x350




40mm Round head nail
(A0025) x30




50mm Posi-drive screw
(A0557) x30



60mm Posi-drive screw
(A0035) x49




80mm Posi-drive screw
(A0036) x06



Before you start...


Things to check before you start:

- ✓ Ensure your base is ready – See page 4
- ✓ Check all parts as listed in the parts lists
- ✓ Read the instructions fully before starting work
- ✓ Follow all the health and safety guidelines.


















6mm

When you see the drill icon
 Only ever drill through the first piece of framework which will be a pilot hole for the screw to attach the second piece of framework
The required drill bit size is shown with the icon.



You will need:

- | | |
|--|---|
|  <ul style="list-style-type: none"> • Hammer |  <ul style="list-style-type: none"> • Gloves |
|  <ul style="list-style-type: none"> • Spirit level |  <ul style="list-style-type: none"> • Saw |
|  <ul style="list-style-type: none"> • Ladder |  <ul style="list-style-type: none"> • Pencil |
|  <ul style="list-style-type: none"> • 3mm 5mm drill bit |  <ul style="list-style-type: none"> • Goggles |
|  <ul style="list-style-type: none"> • Drill |  <ul style="list-style-type: none"> • A helper for some tasks |
|  <ul style="list-style-type: none"> • Tape measure & Ruler |  <ul style="list-style-type: none"> • Screwdriver |
|  <ul style="list-style-type: none"> • Sand paper |  <ul style="list-style-type: none"> • Sharp knife |
| |  <ul style="list-style-type: none"> • Pliers |



Assembly instructions:

These instructions are for your safety. Please read through them thoroughly before use.
Treat all the parts before assembly – see page 5!


GB-IE

The “Panel layout” is showing you how to position the panels.




01



Floor Half
(A3957)x02



60mm Screws
(A0035)x04



GB-IE




Drill one of the **Floor Halves (A3956)**.

Secure both panels together using 4x **60mm Screws (A0035)** as above.
Carefully turn over the floor and position onto your chosen **base**.


12

Drill two **Plain Panels (A5633)** as below. Place the panels into the back corner of the floor, with one **Corner Post 44x88 (A4069)** between them, positioned as below. Make sure the cladding on the panels overlap the floor. Secure the posts with 3x **60mm Screws (A0035)** in each side. Then secure another corner post either side of plain panels as below.


02





Plain Panel (A5633)x02





Corner Post 44x88 (A4069)x03



60mm Screws (A0035)x12



DO NOT FIX WALLS TO FLOOR UNTIL ASKED






Drill the last **Plain Panel (A5633)** as below.


Place onto your building as below and secure to the previous post using 3x **60mm Screws (A0035)**.

Then secure another **Corner Post 44x88 (A4069)** next to the plain panel using another 3x **60mm Screws (A0035)**.


03





Plain Panel (A5633)x01





Corner Post 44x88 (A4069)x01



60mm Screws (A0035)x06



DO NOT FIX WALLS TO FLOOR UNTIL ASKED



GB-IE

Pre drill both of the **Rails (A3963)**.

Drill two holes in each side and two at the bottom.


Align the bottom of rail framework flush with the floor edge.

The shaped part of the rail must protrude **7mm** in front of the post.


Using the holes drilled previously fix the rail to the post with 2x **60mm Screws (A0035)**.

Repeat with the other rail.






04



Rail
(A3963)x02




60mm Screws
(A0035)x04




GB-IE Orientate the last two **Corner Posts (A4069)** the same as before to each rail, having the **7mm** protrusion.
Fix through the rail with the holes drilled previously.
Use **60mm Screws (A0035)**.

GB-IE




05



Corner Post 44x88 (A4069)x02




60mm Screws (A0035)x04




GB-IE

Pre drill 3x **Top Brace (A3964)** at each end.
Fix 2x **Block (A5658)**, 1 at each end flush top and bottom and with the end.
Use 2x **50mm Screws (A0557)** in each end.


06





Top Brace (A3964)x03



Block 34x34 (A5658)x06



50mmScrew (A0557)x12




16


GB-IE

Position the top brace assembly between the posts so the top is at the same height as the walls.
The front face is flush with the post face.
Drill (not too high) and fix to the posts.
Repeat with the assembly over the other rail and then the entrance.






07



Step 06 x03




60mm Screws
(A0035)x12




Roll out the **Felt 8m (A4081)** on a clean, flat surface, back side up. Place one of the six triangular **Roof Panels (A4080)** onto this as in the picture (framework upwards). Allow for a **50mm** overhang of felt along the bottom edge, the shortest side of the panel. Cut out felt to triangles not forgetting the overhang. Repeat this step for all panels, alternating orientation. Then fold the felt over the roof panels. Pull the felt tight and secure with **13mm Felt Nails (A0023)**, equally spaced along the edges as below. Lay out the remaining **Felt 8m (A4081)**. Use a straight piece of wood or something similar to mark out 6 strips, measuring **1450mm x 333mm (LxW)** as below. Cut these strips out and place them aside.


08





Roof Panel (A4080)x06





Felt Strip 8m (A4081)x01



13mm Felt Nails (A0023)x150




X6







GB-IE

At least two people should lift the roof assembly into position.
The framework should sit in the middle of each post.
Ensure everything is square and true.
Drill a hole at an angle through the top of the post only and secure with an **80mm screw (A0036)**.
Repeat at all the posts.

10




80mm Screw
(A0036)x06




Fix the 1450mm x 333mm strips over the joins of the triangular roof pieces using **13 felt nails (A0023)** down each side. The top of the strip can be folded onto adjacent roof panels. The end of the strip that overhangs the roof needs to be folded under the overhang and secured there using 3 x felt nails.

GB-IE





11



Felt Roll 8m
(A4081)x01




13mm Felt Nails
(A0023)x200






GB-IE Fix the walls to the floor with 2x **60mm Screw (A0035)** per panel.

12




60mm Screws
(A0035)x07




GB-IE

Take the finial and screw the double ended screw directly in the centre of it.
Fix the finial to the top of the roof by screwing the exposed half of the double ended screw into the point where the roof panels meet.



13



Finial
(A0111)x01





Double end screw
(A4029)x01




GB-IE

Fix shaped coverstrips over the joins on the roof using 4 x 40mm Nails (A0025).



14



Roof Trim
(A4082) x06




40mm Nails
(A0025) x24




22

Position the rail cap centrally on top of the rail.
Position the nails so they go into the framework below.

15



Rail cap
(A5660)x02



40mm Nails
(A0025)x06



Building Photographs

It will be greatly appreciated if you could forward images of your completed building to -
sales@shiregb.co.uk.