




















Thank you for purchasing the **CABINET!**

Before you start, here are some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step-by-step instructions.
2. Owing to the size and weight of the Cabinet, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approximate assembly time: 60 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or instructions until you have checked all the components and hardware and the furniture is fully assembled.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save the tools that have been provided.
6. Please keep all pieces out of reach of children.



Hardware :


A)  Cam bolt/Metal Ø 6 x 35 mm x 15	B)  Cam Lock /Metal Ø 15 mm x 15	C)  Dowel Big/Wood Ø 8 x 30 mm x 48	D)  Screw/Metal M 7 x 50 mm x 7	E)  Screw/Metal M 12 x 35 mm x 4
F)  Pin Sliding Top/Plastic Ø 8 x 19 mm x 6	G)  Pin Sliding Bottom/Plastic Ø 8 x 16 mm x 6	H)  Wedge/Plastic 9 x 14 x 10 mm x 18	I)  Screw/Metal M 3.5 x 15.5 mm x 18	J)  Key/Metal L 4 x 1
K)  Buffer/Rubber Ø 8 mm x 6	L)  Screw Cup/Plastic Ø 15 mm(Short) x 3	M)  Screw Cup/Plastic Ø 15 mm(Long) x 4	N)  Anti-tipping strap/Polyester ± 150 mm x 2	O)  Ring/Metal Ø 20 mm x 2
P)  Screw/Metal M 6 x 16 mm x 2	Q)  Foam Pad/Spon 25 x 25 x 2 mm x 4	R)  Screwdriver (Not Include) x1		




Components:



1	Top Board	x1	2	Bottom Board	x1	3	Side Board Left	x1	4	Side Board Right	x1
5	Center Board	x3	6	Fixed Shelf 1	x1	7	Support Board 1	x2	8	Support Board 2	x2
9	Support Board 3	x2	10	Back Board 1	x1	11	Fixed Shelf 2	x1	12	Slide Door 1	x2
13	Slide Door 2	x1	14	Back Board 2	x2						


STEP 1:




		
Cx12	Ax5	Rx1


Hardware required.
Screwdriver not included




STEP 2:




Cx8


STEP 3 :





		
Cx8	Ax4	Rx1

Hardware required.
Screwdriver not included


STEP 4:






	
Dx1	Jx1

Hardware required. Screwdriver not included


STEP 5:





		
Bx1	Ax1	Rx1

Hardware required.
Screwdriver not included


STEP 6:





	
Dx1	Jx1

Hardware required. Screwdriver not included


STEP 7:





	
Bx2	Rx1

Hardware required. Screwdriver not included


STEP 8:






	
Bx2	Rx1

Hardware required. Screwdriver not included


STEP 9:





		
Bx1	Ax1	Rx1

Hardware required.
Screwdriver not included


STEP 10:






	
Dx5	Jx1

Hardware required. Screwdriver not included


STEP 11:




		
Cx16	Ax4	Rx1




Hardware required.
Screwdriver not included

STEP 12:




STEP 13:




		
Bx4	Qx4	Rx1


Hardware required.
Screwdriver not included



STEP 14:




Cx4


STEP 15:







	
Ex4	Rx1

Hardware required. Screwdriver not included


STEP 16:




			
Bx5	Lx3	Mx4	Rx1

Hardware required.
Screwdriver not included



STEP 17:






STEP 18:






STEP 19:







		
Hx18	lx18	Qx1

Hardware required.
Screwdriver not included


STEP 20:



			
Nx2	Ox2	Px2	Rx1

Hardware required.
Screwdriver not included

STEP 21:



Assembly is complete. The Cabinet is ready to enjoy now!