


Sideboard


Assembly Instructions




Please scan the code and view the
YouTube installation video.

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The two main types of hardware used to assemble this product are screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.


















- VI. Power tools should not be used to assemble this product.






Parts List



Hardware List

1		Ø6x40	Cam bolt	12 pcs
2		Ø8x40mm	Wooden dowel	8 pcs
3		Ø15x11mm	Cam lock	12 pcs
4			Corner Brace	4 pcs
5			Door Hinge	4 pcs
6		Ø3.5x13mm	Screw	16 pcs
7		Ø6x16mm	Bolt	12 pcs
8			Gasket	12 pcs
9		S 4	Hex Key	1 pcs
10		Ø5x40mm	Screw	4 pcs
11		Ø5x20mm	Shelf holder	4 pcs
12			Corner Brace	4 pcs
13		Ø4x12mm	Screw	16 pcs
14		Ø4x20mm	Screw	4 pcs
15		Ø3.5x13mm	Screw	8 pcs

16			Corner Brace	4 pcs
17		Ø4x18mm	Screw	4 pcs
18			Ball Bolt	4 pcs
19		Ø6x52mm	Screw	4 pcs
20		Ø8mm	Plastic Expansion Bolt	4 pcs
21			Wire	2 pcs




**Philips head screwdriver required for assembly
(not included)**

The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.


Step 1

Install the cam bolt of the base plate and panel with the grooved side up on the floor, then press the wooden dowel into the hole directly.




Step 2

Place the holes in the side panel and front bezel with the cam bolt on the top plate, then from the side install the cam lock, the arrow of the cam lock is in the opposite direction to the screw hole.




Step 3

Gently insert the back panel along the groove of the side panel, align the slots on the bottom plate and push them all the way in. Then locate the marked holes in the side panels and install right angle connection buckle.



Step 4


Align the holes of the panel with the side panels and the cam bolt of the front bezel.



Step 5

Locate the bottom plate on both sides four holes, mounting reinforcement screws, after completing the installation of the screws.


Make sure the L-shape feet are placed in the proper metal holes with screws.



Step 6


Turn the cabinet over to make the top side is facing up.

Press the small corner code of the back panel into the gap, and align the holes of the corner brace, then fix it on the bottom plate and the panel with screws.



Step 7

Push the round end of the shelf holder into the hole at the same level as the side plate and insert it into the shelf plate.




Step 8

For installation of the door hinge, pay special attention to the order of installation hole positions:

1. Install the A1 screw hole first, adjust the height of the cabinet door until it is flush with the cabinet itself, and then tighten the A1 screw hole;
2. If the height of the cabinet door cannot be adjusted to be flush with the cabinet itself after installing the A1 screw hole; Please remove screw A1 and install screw B1;
3. Finally, install the four fixing screws C1, C2, C3, and C4;

In addition, the other three "door hinges" can also be installed one by one using the same method.

Tips: If there is a large gap between the door panel and the cabinet, Please adjust the D1 button. If there is a large gap between two doors, please adjust the D2 button.



Step 9

1. The ball nut is screwed on one end of the WIA rope through the fixing baseplate, and then the fixing baseplate is installed in the marked hole of the side panel.
2. The other end of the WIA rope passes through the fixed bottom plate and screws on the ball nut. According to the hole spacing of the fixed base plate, open it in advance on the wall 8 mm hole, drive in the expansion pellet, and use screws to mount the fixed bottom plate on the wall.

