






















Suggestion

- It is recommended to install it near a power source, as later steps will require the power to be turned on.
- This product requires installation by at least two people.

ASSEMBLY INSTRUCTION




ASSEMBLY INSTRUCTION

<p>① 1PC</p> 	<p>② 1PC</p> 	<p>③ 2PCS</p> 	<p>④ 2PCS</p> 
<p>⑤ 2PCS</p> 	<p>⑥ 1PC</p> 	<p>⑦ 1PC</p> 	<p>⑧ 2PCS</p> 
<p>⑨ 1PC</p> 	<p>⑩ 1PC</p> 	<p>⑪ 2PCS</p> 	<p>⑫ 2PCS</p> 
<p>⑬ 1PC</p> 	<p>⑭ 1PC</p> 	<p>⑮ 1PC</p> 	<p>⑯ 1PC</p> 
<p>⑰ 1PC</p> 	<p>⑱ 1PC</p> 	<p>⑲ 1PC</p> 	<p>⑳ 1PC</p> 

ASSEMBLY INSTRUCTION


21

1PC




22

1PC




23

1PC




24

1PC




25

1PC




26

1PC




27

1PC




28

1PC




29

1PC




30

1PC




31

1PC




32

1PC




33

1PC




34

1PC



35

1PC




36

1PC




37

1PC




38

1PC




39

1PC























40






1PC







ASSEMBLY INSTRUCTION

<p>④1 1PC</p> 	<p>④2 1PC</p> 	<p>④3 2PCS</p> 	<p>④4 1PC</p> 
<p>④5 1PC</p> 	<p>④6 1PC</p> 	<p>④7 1PC</p> 	<p>④8 2PCS</p> 
<p>④9 1PC</p> 	<p>⑤0 1PC</p> 	<p>⑤1 1PC</p> 	<p>⑤2 1PC</p> 
<p>⑤3 1PC</p> 	<p>⑤4 2PCS</p> 	<p>⑤5 1PC</p> 	<p>⑤6 1PC</p> 
<p>⑤7 1PC</p> 	<p>⑤8 1PC</p> 	<p>⑤9 1PC</p> 	<p>⑥0 1PC</p> 
































ASSEMBLY INSTRUCTION

<p>⑥1 1PC</p> 	<p>⑥2 2PCS</p> 	<p>⑥3 1PC</p> 	<p>⑥4 1PC</p> 
<p>⑥5 2PCS</p> 			

"A" Hardware installation example

<p>I</p>  <p>This part cannot be separated, please install in strict accordance with the assembly requirements</p>	<p>II</p> 
<p>III</p> 	<p>IV</p> 

ASSEMBLY INSTRUCTION
















<p>A 12PCS</p>  <p>M6*30</p>	<p>B 10PCS</p>  <p>M6*10</p>	<p>C 1PC</p>  <p>M4</p>	<p>D 4PCS</p>  <p>M6*10</p>
<p>E 4PCS</p>  <p>14"</p>	<p>F 2PCS</p>  <p>M8</p>	<p>G 1PC</p> 	<p>H 4PCS</p> 
<p>I 1PC</p> 	<p>J</p>  <p>4PCS</p>  <p>8PCS</p>	<p>K 121PCS</p>  <p>M6*40</p>	<p>L 121PCS</p>  <p>Ø15*9.5</p>
<p>M 80PCS</p>  <p>Ø3.5*14</p>	<p>N 8PCS</p>  <p>Ø3.5*40</p>	<p>O 12PCS</p>  <p>Ø5*15</p>	<p>P 8PCS</p> 
<p>Q 3sets</p>  <p>96#</p>  <p>Ø3.5*12</p> 	<p>R 16PCS</p> 	<p>S 1PC</p>  <p>Ø50</p>	<p>T 1PC</p> 
<p>U 4PCS</p>  <p>Ø8*40</p>	<p>V 121PCS</p> 	<p>W 16PCS</p>  <p>M6*16</p>	<p>X 2PCS</p>  <p>Ø3.5*25</p>
<p>Y 2PCS</p>  <p>M8*16</p>	 <p>M4</p>  <p>M5</p> 		

Step 1

K 109PCS



M6*40






ASSEMBLY INSTRUCTION

Step 2

K 12PCS



M6*40





Step 3

L 3PC



Ø15*9.5




Step 4

L 2PCS





Ø15*9.5




ASSEMBLY INSTRUCTION


Step 5

L 1PC

Ø15*9.5





Step 6


L 5PCS

Ø15*9.5




Step 7

L 2PCS

Ø15*9.5





L 10PCS

Ø15*9.5




ASSEMBLY INSTRUCTION


Step 9


L 6PCS

Ø15*9.5




Step 10


G 1PC


M 2PCS

Ø3.5*14






Step 11

L 11PCS

Ø15*9.5





Step 12



M 4PCS

Ø3.5*14





Step 13





Step 14



Step 15




Step 16




ASSEMBLY INSTRUCTION

Step 17



Step 18


M 8PCS
Ø3.5*14



Please press here to open the door panel.


Step 19

L 3PCS
Ø15*9.5




Step 20


L 3PCS
Ø15*9.5




ASSEMBLY INSTRUCTION


Step 21

L 6PCS

Ø15*9.5





Step 22

L 4PCS

Ø15*9.5





Step 23

L 4PCS

Ø15*9.5




Step 24

L 7PCS

Ø15*9.5




ASSEMBLY INSTRUCTION



Step 25



Ex4




Step 26




ASSEMBLY INSTRUCTION

Step 27





Lx2



Lx2

L 4PCS
Ø15*9.5


Step 28



Lx6

L 10PCS
Ø15*9.5

Step 29





Lx12

Requires two or more people to install.


L 12PCS
Ø15*9.5


Step 30

L 14PCS

Ø15*9.5




Step 31

M 4PCS

Ø3.5*14




Make sure the accessory nuts face outward during installation.




Step 32

A 4PCS
M6*30






Step 33

R 10PCS






ASSEMBLY INSTRUCTION

Step 34




E2	2PCS	L	4PCS
14"		Ø15*9.5	
Q	1set	M	4PCS
96#	Ø3.5*12	Ø3.5*14	
N	4PCS	Ø3.5*40	

Step 35





E2	2PCS	L	4PCS
14"		Ø15*9.5	
Q	1set	M	4PCS
96#	Ø3.5*12	Ø3.5*14	
N	4PCS	Ø3.5*40	

Step 36




Step 37



0 8PCS

Ø5*15





Step 38





Step 39

M	8PCS
	
	Ø3.5*14
P	4PCS
	





Step 40

M 16PCS

Ø3.5*14




Step 41

L 6PCS

Ø15*9.5






Step 42

Attention, please! Lift accessory 1 and accessory 2 up by hand to the same level to facilitate the installation of accessory 5 in step 43.




Step 43

B	4PCS
	
	M6*10
C	1PC
	
	M4



Note that the "gourd-shaped hole" here on the front crossbeam is close to the left cabinet





First install the inner screw, then install the outer screw.

ASSEMBLY INSTRUCTION


Step 44

Attention, please! Install accessory 5, which is the crossbeam, and press the legs on both sides to the lowest position.


 If it is not pushed all the way to the bottom, it may cause the product to have uneven legs, which can result in an uneven tabletop.



Step 45




Step 48



C	1PC
M4	
F	2PCS
M8	
I	1PC

Note: If the transmission rod doesn't fit smoothly into the hole of rod coupler, fine-tune fit with the wrench.

Step 49




Step1: Connect the controller of the lifting frame, namely accessory 6, to the plugs of the other two accessories 10 and 13, and then turn on the power.


Step2: Press the downward button on the controller for 5 seconds- the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.


Step3: Press and hold the "Rise" button, raise the lifting frame to a certain height, then turn off the power and proceed to the next installation step.

Step 50




Step 51

B 4PCS

M6*10




Step 52

A 4PCS
M6*30



Step 53


D 4PCS
M6*10



Step 54

The tabletop is too heavy. It is recommended to move the two boards here to the tabletop and then join them together.



U 4PCS
Ø8*40






Step 55





W 16PCS
M6*16

Attention, please! At this step, screw W cannot be locked yet. All 16 screws need to be locked before tightening screw W uniformly.






Step 56


S	1PC	M	2PCS
			
Ø50		Ø3.5*14	
		X	2PCS
			
		Ø3.5*25	




Step 57


H	4PCS
	
M	4PCS
	
Ø3.5*14	
T	1PC
	

To prevent the power adapter from being damaged and from loosening, please use a pull strap to secure the cable.




Step 58

Y 2PCS

M8*16



Step 59



OK

Instruction Manual for JCB35M51C Controller (Version 1.0-English)


System Function Description:

1. Lifting and Lowering Function of the Height-Adjustable Desk:

Hold down the upward button, and the column will rise; hold down the downward button, and the column will lower. Release the button, and the movement will stop.

2. Memory Position Function:

Long press the "①/②" button for 3 seconds until the digital tube display flashes. After the number flashes 3 times and stops, the current height will be successfully stored in the corresponding memory position. Short press the "①/②" button and release it, and the tabletop will automatically move to the height of the memory position. During operation, pressing any button can stop the movement.



3. Reset Function:

(1) Function Description:

The system needs to be reset under specific circumstances.

These circumstances include:

- ① When used for the first time, the system will enter the reset state after being powered on.
- ② Active reset will put the system into the reset state.
- ③ A system abnormality will cause the system to enter the reset state.

(2) Operation Method:

Bottom Reset: Hold down the downward button until it reaches the bottom. Then release the button, and press the downward button again for 5 seconds— the hand controller will display "RST". Release the button, then hold down the downward button again until the digital tube shows a number.

