## INSTRUCTION MANUAL

Thank you for shopping with us, we really appreciate your business. Our goal is to provide an excellent customer service before, during and after delivery. We've included a guide on how to install this light, should you require additional assistance please feel free to email us and one of our customer service reps will reach out to assist you.

## Before you get started:

When working with electrical wiring, follow these safety instructions to prevent injury or damage:

- 1. Turn off the power: Before starting any work, turn off the power to the area you will be working in.
- 2. Use appropriate tools: Only use tools designed for electrical work and in good condition.
- 3. Wear protective gear: Wear safety glasses, gloves, and other protective gear as necessary.
- 4. Test for power: Use a non-contact voltage tester to check for electrical current before touching any wires.
- 5. Avoid wet conditions: Do not work with electrical wiring in wet or damp conditions.
- 6. Keep a safe distance: Stay away from exposed wires or electrical components.
- 7. Seek professional help: Consult a qualified electrician if you are unsure about any aspect of electrical wiring or encounter any problems.

## WARNING!

- 1. Do not use the power supply beyond the specified range (100-240V,50Hz).
- 2. Avoid scratching the surface and wires of the lamp during installation.
- 3. Do not install the lamp outdoors.
- 4. The lamp should not be close to corrosive chemical objects or gases. It should not be washed with water. It can only be wiped with a clean soft cloth.

## **Installation Instructions**







This device is optimized for use with shoes in the weight range of 450-550 grams. To achieve this specific weight range, glass marbles can be added to the shoe. The spring balance is calibrated to accurately measure weights within the 450-550-gram range. It's important to note that the device may not function correctly if the shoe exceeds 550 grams in weight.

Follow these steps for proper usage:

1	Use a spring balance to weigh your shoe. If the shoe weighs less than 450 grams, proceed to the next step. Add glass marbles one by one into the shoe until the spring balance panel shows a weight within the range of 450-550 grams. Alternatively, you can weigh the shoe using a scale to achieve the desired weight range.
2	Place the stand on a flat surface. Connect the cable to the DC port and plug the adapter into a 100-240VAC outlet.
3	Insert the magnet into the shoe, ensuring that the small end of the magnet (marked 'TOP') securely attaches to your shoe.
4	Hold the shoe and magnet firmly with both hands. Slowly move them upwards, raising them by approximately 0.2-0.4 inches. Once you sense the magnetic force locking the shoe in place, gently release your hands.

The switch is used to turn the LED lights ON/OFF.