OFFICE CHAIR

ASSEMBLY INSTRUCTION



FIGURE

M6*20

Q'TY

4PCS

Assembly Instruction

ASSEMBLY TIPS:

- Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior start of assembly.
 Please follow attached instructions in the same sequence as numbered to assure fast &

easy assembly.

Warning! 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishment.

ASSEMBLY TIME PER UNIT: 10MINUTES

PAPTS IDENTIFICATION:

Z HARDWAREPACKAGE

DESCRIPTION

CROSS HEAD BOLT

(A) SEAT



1PC

NO.

1

(B) BACK



1PC

(C) BACK SUPPORT



1PC

2	2	SHORT BOLT	∯∭∭ M6*16	5PCS
	3	ALLEN BOLT	∭∭ M6*20	4PCS
	4	SMALL ALLEN WRENCH	M4	1PC
	5	LARGE ALLEN WRENCH	M6	1PC

(D) METAL PLATE



1PC

(E) GAS LIFT



1PC

(F) BASE



1PC

(G) CASTER



5PCS

