


DOOR SIDEBOARD



ASSEMBLY INSTRUCTION - Please Keep For Future Reference



Safety and Care Advice

IMPORTANT - Please Read This Instruction Carefully Before Assembly.






- Check you have all the components and tools listed on page 3.
- Remove all settings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before assembly.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its intended position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit.
- Parts of the assembly will be easier with 2 people.
- Do not use power drill/drivers for assembly, or the unit may be damaged.
- Dispose of all packaging carefully and responsibly.



CARE and MAINTENANCE

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal center.



General Hints & Tips















Components and Tools

IMPORTANT - Please Check If You Have All The Components and Tools.

Note: The quantities below are the correct amount to complete the assembly. In some cases more pieces may be supplied than are required.




<p>A=16</p>  <p>Peg M6*34mm</p>	<p>B=16</p>  <p>Lock M15*12mm</p>	<p>C=16</p>  <p>Dowel M8*30mm</p>	<p>D=28</p>  <p>Screw M3.5*14mm</p>	<p>E=12</p>  <p>M4X30MM SCREW</p>	<p>F=4</p>  <p>Screw M6*30</p>
<p>G=18</p>  <p>Pin</p>	<p>H=4</p>  <p>Screw M4*18</p>	<p>I=2</p>  <p>Stopper</p>	<p>J=2</p>  <p>Handles L96mm</p>	<p>K=1</p>  <p>Spanner M4mm</p>	<p>L=4</p>  <p>Insert Door Hinge</p>

Assembly Instruction

Step 1

A=8 I=2




Peg

D=12 L2=4




Screw



Step 2

A=8 C=16




Peg

Dowel

D=8 L1=4



Screw




Assembly Instruction

Step 3

B=16



Lock
M15*12




Step 4

G=18



Pin



Assembly Instruction

Step 5



E=4

M=1



Screw M4*30

Spanner M3mm



Step 6

E=8

F=4



Screw M4*30

Screw M6*30


K=1

M=1



Spanner M4mm

Spanner M3mm




Assembly Instruction

Step 7



H=4

J=2




Screw
M4*18

Handles
L96mm



Step 8



OK





STEP 9



Customer Attention:

To align doors and control gap in between doors.
Product doors may need adjusting during
and after assembly.





This can be done by adjusting appropriate screws.
See below illustration.



Vertical door adjustment:




Loosen both screws on all hinges and lift the
door to the desired height.

This allows an even space at the top and
bottom between the door and frame



Lateral Door Adjustment:

If door is hinge bound, (rubbing on frame as you
close or open door) loosening screw shown and
move the door in appropriate direction. (In or out)



D  8PCS

Horizontal Door Adjustment:

Rotate Screw clock wise or anti clockwise. This
will produce an even gap between doors and frame.

after adjusting, you find the doors are in alignment,
you can fasten that hinge with 2 screws