




# Product Installation Instructions







**Ax1**




**Bx1**




**Cx2**




**Dx2**




**Ex1**




**Fx5**




**Gx1**




**Hx1**




**Ix1**




**Jx1**




**Kx2**



**Lx1**
















**Mx1**




**1**

# Accessories list

①		Two in one screw (6x28mm)	39pcs +4pcs
②		Two in one nut (10x12mm)	39pcs +4pcs
③		Wood chipping (6x30mm)	16pcs +4pcs
④		Handle & screw (4x18mm)	4pcs +2pcs 2pcs
⑤		Non-slip pads	6pcs +2pcs
⑥		Backboard card strip	2pcs
⑦		Fixing clip & screw (3x16mm)	10pcs +4pcs
⑧		Foot nail	4pcs
⑨		Laminate Support Nail	8pcs +2pcs
⑩		Hinge & Screw (4x10mm)	8pcs +2pcs 4pcs
⑪		Screw (3.5x12mm)	16pcs +4pcs
		AC/DC Adapter (12V=3.0A)	1pcs




1pcs












Double-head screwdriver, use as required

2

# Product structure decomposition




①		39pcs	③		16pcs	⑥		2pcs
②		39pcs	⑤		6pcs	⑦		10pcs
⑧		4pcs	⑨		8pcs			




# Use parts ① and ②




Step1



Step2




Step3



Use a screwdriver to lock in the direction of the "+" sign

Disassemble along the direction of "-" sign



Step 1




- ① x10
- ③ x6

5

Step 2



Step 3




Step 4

2



x6





Step 5



2





x4



Step 6



Step 7




Step 8


2




x10




Step 9

5  x6


Tear off release paper and stick the black foot pad on the board





 x6 5

Step 10

Fx2  
⑥ x1




Step 11






Step 12



Clip in the two backboards



Step 13




Step 14



Step 15




Pay attention to the hole position




Step 16

2  x1






Step 17

2  x7





Step 18




Step 19



2  x4




 x4 2

Step 20


7  x10




Step 21



Use a hammer to drive the nail into the gap of the wooden board and fix the back board




Step 22





Step 23

9  x8



9  x4







Adjust the height according to the actual situation


9  x4



Step 24








4	 2pcs	 4pcs	11	 16pcs	16pcs
10	 4pcs	 8pcs		 1pcs	1pcs



Step 25



Be careful not to scratch your hand




- 10  x2
-  x4




**Step 26**


Be careful not to scratch your hand




- 10  x2
-  x4



Step 27

11  x16


 x16 11




First lock the elliptical hole  
then lock the fixed hole

Step 28


4  
x2      x4



Step 29




Turning this screw can effectively adjust the size of the door gap.




Turn this screw to adjust the door panel to be flat with the side panel.

Step 30



x1




## User's Guide

Thank you for purchasing this product. To use this product, please plug it into a 12V DC power supply. Please use if the product works normally after connecting to power.

## Introduction

The box is an intelligent controller with 2 touch buttons. It can turn ON/OFF the light, change light colors, and adjust the light luminance.

## Product Show



### ATTENTION PLEASE

1. If there is no touch response suddenly, Re-plug the power to reset the touch static electricity.
2. If bubbles appear on the panel, remove the protective film.

## Operation



This touch button is used to turn on/off, change colors, and adjust brightness.

A. Short touch -> lighting on -> short touch -> change light color -> short touch -> change light color -> short touch -> lighting off. B. Long touch -> adjust the luminance



This touch button is used to turn on/off the induction function.

A. Short touch to turn on the induction function. It can auto-turn on the light when people are close to the controller in 4 meters. It can auto power off the light when the body is far away from the controller after 30 seconds.

B. Long touch to turn off the induction function.

C. Note: When you touch the light button to change the light modes, the induction function will automatically turn off. It is best to turn on this function after selecting the light color and adjusting the brightness you want.