


Workman Apex



1. Base

1.a Lay the pieces of the floor down in the desired position. Push them together to make a completed floor. You don't need to worry about securing them with nails as the weight of the completed building will hold them in place.


1.b Check that the floor is level using a spirit level before proceeding.

1.c Each floor joist should be as near as possible supported along its full length to prevent the floor from dipping in the middle.

1.d Ensure heavy duty nails are driven through the side and gable panel base rails, through the floor boards in a position where they will finally penetrate the floor joist.


Important:

- The floor panel must be laid on a firm level base.
- The underside of this floor must be treated with a quality wood preserver.
- Before starting assembly, you may have to remove transport blocks from the bottom of some panels.



65mm Nails

2. Gable & Sides



38mm Nails


80mm Coach Screws x8

2.d Once the gables and rear side panels are in place, you can start fitting the front door and window panels. Windows to the sides and the door panel in the middle.


2.e Use the same method to join the panels as the rear ones, by screwing through the framing using the 80mm screws.

2.f Again, you will be provided cover strips to cover the joins. Fix these in place using the 38mm nails (fig.3).

2.g Using the coach screws provided, secure the gables to the sides through the pre-drilled holes in the gable from the outside.



2. Gables & Sides



38mm Nails

80mm Screws

2.a Position one end gable panel on to one end of the floor panel.


2.b Offer up a back side wall panel and secure this to the gable by using the 38mm nails through the sides in to the gables.

2.c Then secure the 2nd back side wall panel in place by screwing through the internal frame work (fig.1). You will be provided a cover strip to cover the external join.

fig.1


Gables align with the side panels.

4. Roof Boards



65mm Nails

38mm Nails




4.a Place the roof panels in position and secure these internally to each other with the 65mm nails provided. You may need someone to help you pull the two panels together before you can nail them.

4.b Nail the roof to the gables and side frame with 38mm and 65mm nails provided.

Troubleshoot: If at this point the roof panels do not align correctly, the door does not open/close properly or the building looks twisted at all then it would suggest that the base is not correctly level. Therefore, one or more corners of the building may need adjusting so the base is square. If you are having trouble with this and need extra advice please refer to our Online Help Guide.

5. Roof Felt




5.a Roll out meter wide strips across the lower lengths of the roof on both sides, making sure there is enough overhang to fold down on to the roof framing. Ensure the felt is tight and use the clout nails to tack the top edge of the felt in to place.

5.b Roll out the next strip along the roof. Make sure that it overlaps the lower piece of felt enough to prevent leaks. Secure in place with the clout nails.

5.c Then take the last piece of felt and position this on the roof so that it folds down over the apex and overlaps the felt already on the roof. Once all of the felt is secure, trim off any excess and secure the bargeboards in place.

Note: On some sheds you will have 3 pieces and a half piece. Once you have felted the lower edges, position the half piece so that it overlaps enough to prevent leaks. Then you can take the final full piece of felt and position it so that it folds down over the apex. Secure in place.

6. Windows



6.a Glaze windows by securing glass / perspex with the panel pins supplied.


Important:

All windows must be sealed inside and out with silicone, putty or any other water-tight solution (not supplied). Please do not confuse your corner strips as window beading. We do not provide window beading as standard with our buildings.

7. Finishing Pieces


7.a Fit the bargeboards to the roof panels, trapping the overhanging end of the felt in between to provide a weather seal.

7.b Secure the diamond finials over the top of the bargeboards.



38mm Nails

Please note the bargeboards may need cutting to size before installation.



Please Note: There are no bargeboards supplied for the lower edges of the roof.

7.c Secure the corner strips at each corner of the shed with the 38mm nails provided.

Important: Please do not confuse these corner strips as window beading. We do not provide window beading as standard with our buildings.

Also please be aware that these corner strips may need cutting to size.

Treat your building annually: Although it may come with a factory base coat you should treat your new garden building inside and out shortly after installation with a good quality water resistant treatment. This process should then be repeated annually with care taken to brush the treatment into all wooden components involved within the construction of the building, inside and out.

Ensure nothing is in contact with your building: Any overhanging tree or hedge growth poses a threat to your garden building and should be cut back at regular intervals. If a tree branch makes contact with your building it may pierce the roofing felt and encourage water ingress. You should also take care not to allow plants to grow too close to the walls of your building to prevent leaks.

Check and replace any damaged felt: If you do find any damage sustained to your roofing felt over time it is essential that you act upon this without delay. Should you discover a rip or tear in the felt it is recommended that this area be stripped from the roof and a new covering of high grade, heavy duty, mineral felt (which can be purchased online and/or at most retail DIY stores) be affixed immediately.

You should also ensure that your new building is covered on your household insurance policy, as we cannot be held responsible for damage caused by storms or vandalism.

For more help and advice on installing and maintaining your garden building please visit our comprehensive help centre at: www.tigersheds.com/helpcentre.asp

Check List

Note: Panels greater than 10ft may come in two pieces or more.

- x1 Floor (2 or more panels)
- x2 Gables (triangular)
- x3 Front Side Panels (rectangular)
- Rear Side Panels (2 or more Panels)
- Roof Panels
- Roofing Felt
- Glass / Perspex
- (Found In Polytube Pack)
- x4 Bargeboards
- Cover Lats (3 or 4 dependant on size)
- x2 Diamond Finials
- x4 Corner Strips
- Fixing Pack