


SKU:PHO_34V7PT9R
PHO_34V7WQGQ

Assembly Instruction



Trouble shooting:

Missing / Wrong / Broken parts and installation issues



Send email with your question ,order NO. and screenshot of order details to:
support@idealhouse.vip






Respond within 24 hours















Issue resolved




















Part Nr.	Qty	Part Nr.	Qty	Part Nr.	Qty
1	1pcs	2	1pcs	3	1pcs
4	1pcs	5	1pcs	6	1pcs
7	3pcs	8	1pcs	9	2pcs
10	6pcs	11	6pcs	12	2pcs
13	2pcs	14	4pcs	15	4pcs
16	4pcs				
T01	2pcs	T02	2pcs	T03	1pcs



HARDWARE LIST


<p>(A) x 40</p> 	<p>(B) x 40</p>  <p>Ø15X9.5mm</p>	<p>(C) x 34</p>  <p>D5X40mm</p>	<p>(D) x 8</p>  <p>M6x30mm</p>
<p>(E) x 6</p> 	<p>(F) x 68</p>  <p>Ø3.5X12mm</p>	<p>(G) x 2</p> 	<p>(H) x 16</p> 
<p>(J) x 6</p>  <p>CL x6 DL X6 CR X6 DR X6</p>			
<p>(K) x 1</p>  <p>3#</p>	<p>(L) x 1</p>  <p>4#</p>	<p>(M) x 1</p>  <p>4#</p>	

HARDWARE LIST


① x 1 	② x 1 	③ x 1 	④ x 1 
⑤ x 1 	⑥ x 1 	⑦ x 3 	⑧ x 1 
⑨ x 2 	⑩ x 6 	⑪ x 6 	⑫ x 2 
⑬ x 2 	⑭ x 4 	⑮ x 4 	⑯ x 4 
T01 x 2 	T02 x 1 	T03 x 2 	

1

D3.5X12MM



(A) x 5




(F) x 10

CL



(J) x 5




Noted the distance of glide to edge is 15mm

After assembly

After assembly



15mm



2


D3.5X12MM

(A) x 5 (F) x 10 CR (J) x 5



After assembly


15mm



Noted the distance of glide to edge is 15mm

3

D3.5X12MM



(F) x 4

CL




(J) x 1



CR



(J) x 1



Noted the distance of glide to edge is 15mm




After assembly

15mm

4



(A) x 6




5

D5X40MM



(C) x 2



6


Ø15X9.5MM



(B) x 5



(H) x 5



Noted the direction of backpanel holes is upward

7


Ø15X9.5MM



(B) x 5



(H) x 5



8


Ø15X9.5MM



(B) x 6



(H) x 6




9

D5X40MM




(C) x 4




10

D3.5X12MM



(F) x 20




11

M6X30MM



(D) x 2




12

D5X40MM


M6X30MM



(C) x 4




(D) x 6




13

D5X40MM




X 2

14





X 2

15




16

Ø15X9.5MM





17

D5X40MM
Ⓢ x 16




X 4

18



X 4

19




X 4

20

Ø15X9.5MM





(B) x 16



X 4



21

D3.5X12MM




22

D3.5X12MM



23



24




1. Drive the expansion screw into the appropriate position on the wall

2. Use long screws to install one of the plastic buckle seats in the appropriate position on the wall.




3. Use short screws to install the other plastic buckle in the appropriate position on the cabinet.

4. Push the cable tie through the two plastic buckle seats and pull tight. As shown in the figure.

WALL



BOARD



25

Finished assembly

