

PRODUCT MANUAL


Models OG6834-S OG03-PE7729E



PACK CONTENT							
NUMBER	PICTURE	QTY.	PART NUMBER	NUMBER	PICTURE	QTY.	PART NUMBER
	(30 in.)	3	OGRP-T-1	A	ຝີ	4	OGRP-C-A
(3)	(15 in.)	22	OGRP-T-3	\bigcirc	\checkmark	6	OGRP-C-D
				E	s S	20	OGRP-C-E
(4)	(11 in.)	14	OGRP-T-4	J	Sy PO	2	OGRP-C-J
5	(39.5 in.)	4	OGRP-T-5	Y		1	OGRC6834-S OGRC03-PE7729E
8	(26.5 in.)	15	OGRP-T-8	Z		6	OG-S-1322
Anchors		4	OGHWD-AK-4	Ropes		4	



ARRANGE PARTS INTO GROUPS AS LISTED IN YOUR PACK CONTENTS UNFOLD COVER AND PUT TO ONE SIDE



8xE 4x8 4x4 2xZ 8x3

This forms the next level. Once completed build the next level with parts listed in Step 3.

6xE 2xD 4xD 4x4 6x3 2xZ

This forms the next level. Once completed build the next level with parts listed in Step 4.

4xA 2xE 2x8 2x4 1x1 This forms the next level. Once completed build the next level with parts listed in Step 5.

4x5 2xJ 1x8

This forms the next level. Once completed, place the cover (Y) over the frame and attach.

STEP 6

STEP 2


STEP 3

STEP


4

STEP 5

In order to have the frame connected you will need to assemble the frame by pushing downward while connecting two rods at a time, giving it an extra force (when frame is complete repeat from all angles, as picture shown). This will result in a tighter and smaller frame enabling the greenhouse cover to slide on easily.



Anchor kit Assembly Instructions



Step 2

Connect the top end of the rope into the strap on the top of the greenhouse for all 4 sides as image shown.

Step 3

Take the other end of the rope and pass it through the bended side of anchor as shown in figure. Repeat the step for all 4 sides.

