







# STEP 11



# STEP 12



## Recommended Maximum Weight



\*Unit in Pound(lbs.)


**WARNING:**  
 >This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.  
 >DO NOT allow children to climb on unit.  
 > Put heavier items on lower shelves.

# Assembly Instruction


3-Drawer Dresser

01:30


Approx. 1.5 Hours




Recomm. 2 Persons




Tool Required




## EXPLODED VIEW



## PARTS LIST




## HARDWARE LIST




### USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, soft and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.




## STEP 9



## STEP 10





# STEP 7



TOOL REQUIRED







# STEP 8



TOOL REQUIRED








Please note, you will repeat this step for each of the 3 drawers.

# STEP 1





TOOL REQUIRED

# STEP 2





TOOL REQUIRED




### STEP 3








### STEP 4



### STEP 5



### STEP 6



**WARNING**  
Please make sure that the Back Panel is attached securely. All nails must be driven into the parts straight and centered. Failure to do so could cause instability, product collapse, and/or serious injury.