



# TV Stand


















If there are any questions during the assembly process, please contact us at [AssemblyMaster@hotmail.com](mailto:AssemblyMaster@hotmail.com)  
An video and description about the step you were stucked will help us to understand the problem quickly.

## Package Contents:Parts




## Package Contents:Hardware

A x 8	B x 8	C x 16	D x 20	E x 8	F x 2	G x 4
 6 x 35mm	 15 x 12mm	 6 x 30mm	 6 x 12mm	 7 x 48mm	 110 x 96mm	 4 x 8mm
H x 12	J x 12	K x 8	L x 4	M x 1	N x 1	P x 5
 3.5 x 14mm	 15 x 12mm	 15 x 12mm	 15 x 12mm	 4mm	 110 x 96mm	 19mm


**1****A x 8**

6 x 35mm

Twist Screws (A) into Board (1).

**2****B x 8****C x 8**

15 x 12mm





6 x 30mm


Insert (C) into the holes on Board (1), then connect Board (5)(6)(7)(8) with (1). Twist Screw (B) into the boards as displayed.

**3**

Insert Board (2)(3) into the grooves on Board (1).


4

F x 2	G x 4
	
110 x 96mm	4 x 8mm




Twist Screw (G) to connect the Handle (F) with (4).



5



Place (4) on the grooves on Board (1) as displayed.


6





C x 8	E x 8
	
6 x 30mm	7 x 48mm

Insert (C) into the holes on Board(5)(6)(7)(8), then connect Board(10) with (5)(6)(7)(8). Twist Screw (E) to secure it.


7





D x 20	P x 5
	
6 x 12mm	19mm


Twist Screw (D) to connect Leg (11) with Board (10), then twist (P) into Leg (11). (The adjustable foot P is designed to regulate the cabinet's height, ensuring stability on uneven surfaces.)

8



H x 12	J x 12
	
3.5 x 14mm	

Insert (J) into the back of the cabinet, then twist Screw (H) to secure it.



K x 8

L x 4



Insert (L) into the holes on Board (7)(8), then place Board (9) on it.  
Stick (K) onto the screws at (5)(6)(7)(8) as shown.