


# 12'×16' HARDTOP ALUMINUM POLYCARBONATE GAZEBO **ASSEMBLY MANUAL**



MODEL#: LGFP1583

Missing part? Damaged? Contact us via email at

[service@domioutdoorliving.com](mailto:service@domioutdoorliving.com)

[www.domioutdoorliving.com](http://www.domioutdoorliving.com)

## Pre-assembly



1. Two or more people are required for assembly.



2. You will need one or more stepladders.



3. Wearing protective gloves is recommended.



4. You may need a safety hat.



5. Please use a Phillips screw driver.



6. For ease of construction, you may need a drill.



7. You may need a safety goggle.



8. Do not fully tighten screws prior to complete assembly.

## Warning & Attention

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

▲ Use bolts to secure the frame to the ground to against the strong wind.



**A** 4x Pole



**C** 2x Beam




**C1** 2x Beam



**D** 2x Beam



**D1** 2x Beam



**D2** 2x Beam Connector



**E** 4x Corner Roof Bar



**E1** 4x Corner Roof Bar Connector



**E2** 6x Roof Bar



**E3** 2x Roof Bar



**F** 4x Corner Roof Solidifying Bar



**F1** 4x Corner Roof Solidifying Bar




**F2** 4x Corner Roof Solidifying Bar



**F3** 4x Corner Roof Solidifying Bar




**G** 4x Finishing Bar



**G1** 4x Finishing Bar



G2 2x Finishing Bar



H 2x Finishing Bar



H1 2x Finishing Bar



H2 2x Finishing Bar



J 4x Finishing Bar



J1 4x Finishing Bar



J2 2x Finishing Bar




K 4x Solidfying Bar




K1 4x Solidfying Bar




K2 4x Solidfying Bar




L 4x Roof Panel




L1 4x Roof Panel




L2 4x Roof Panel



M 4x Roof Panel




N 4x Roof Panel




N1 4x Roof Panel







**N2** 4x Roof Panel



**P** 2x Roof Panel




**P1** 2x Roof Panel



**P2** 2x Roof Panel



**Q** 4x Plastic Bar



**Q1** 2x Plastic Bar




**B** 4x Base



**B1** 8x Joint Cover



**B2** 8x Joint Cover



**C2** 2x Union Bar




**R** 4x Corner Solidifying Bar



**R1** 4x Corner Solidifying Bar



**S** 1x Inside Roof Connector




**S1** 1x Outside Roof Connector



**T** 3x J-Hook



**U** 4x Bracket



**U1** 8x Bracket



**U2** 16x Bracket



**V** 128x Hook




**W** 4x Bracket



**W1** 8x Bracket



**W2** 4x Bracket



**W3** 8x Joint Cover

















**X** 6x Joint Cover











**X1** 4x Corner Cover




**X2** 8x Spacer

 <p><b>Y</b> 18x Finishing End</p>	 <p><b>Y1</b> 12x Finishing End</p>	 <p><b>Z</b> 4x Solid Sidewall</p>	 <p><b>Z1</b> 4x Mosquito Sidewall</p>
 <p><b>Z2</b> 1x Mesh</p>	 <p><b>S6</b> <b>S4</b></p> <p><b>1</b> 1x</p>	 <p><b>ST4.2x12</b></p> <p><b>2</b> 8x</p>	 <p><b>ST5x16</b></p> <p><b>3</b> 20x</p>
 <p><b>M6x15</b></p> <p><b>4</b> 16x</p>	 <p><b>M6x15</b></p> <p><b>5</b> 16x</p>	 <p><b>M5x12</b></p> <p><b>6</b> 64x</p>	 <p><b>M6x12</b></p> <p><b>7</b> 12x</p>
 <p><b>M6x16</b></p> <p><b>8</b> 276x</p>	 <p><b>M5x32</b></p> <p><b>9</b> 8x</p>		





A 4x

B 4x

B1 8x

B2 8x
 S4
1 1x

M5x12
6 16x

M6x16
8 28x
5




(4) Repeat the above procedures to assemble the other three Part #A.


(5) Repeat the above procedures to assemble the other Part #C and Part #C1.




D 2x




D1 2x




D2 2x




X 4x



1 1x




ST5x16  
3 8x





M6x16  
8 16x

(1) Insert Part #X into Part #D;



(2) Insert one side of Part #D2 into Part #D and secure with 4 Bolts #8.



(3) Insert Part #X into Part #D1;  
insert the other side of  
Part #D2 into Part #D1  
and secure with 4 Bolts #8.

(4) Secure Part #X with 2 Bolts #3.

(5) Repeat the above procedures to assemble the other Part #D and Part #D1.



S6

1 1x



M6x15

4 16x



M6x15



5 16x



M6x16

8 16x


(1) Connect Part #C/C1 and #D/D1 to Part #A with 4 Bolts #8. (From Inside)




(2) Connect Part #C/C1 and #D/D1 to Part #A with 4 Bolts #4 and 4 Bolts #5. (From Outside)

(3) Repeat the above procedures to assemble the other three corners.

▲ Please don't tighten all the bolts.



(R) 4x



(R1) 4x



(X1) 4x



(X2) 8x



(1) 1x



ST4.2x12

(2) 8x



(3) 8x




M6x16



(8) 32x

9

(1) Affix Part #R and #R1 to the frame with 8 Bolts #8.









(2) Cover the corner with Part #X1 and secure with 2 Bolts #2.



(3) Put Part #X2 on the protruding place and secure with 2 Bolts #3. (From Inside)


(4) Repeat the above procedures to assemble the other three corners.  
**▲ Tighten all the bolts.**





## Assemble the 4 corner Roof Bar:


(1) Connect Part #E1 and Part #E with 2 Bolts #8 .



(2) Attach Part #U to Part #E with Bolts #8.

(3) Attach 2 Part #W1 to Part #E with 2 Bolts #8.

(4) Repeat the above procedures to assemble the other sides.



S 1x



S4

1 1x






M6x16


8 16x

- (1) Please have a freestanding ladder ready at the center of the gazebo.
- (2) Place 4 Part #E1 on 4 corners of part #S; secure with 8 Bolts #8 (from bottom to top)


**ATTENTION:** You can also finish this step on the ground and then lift 4 corner roof bar and inside roof connector to the top together. (Need 2 people and 2 ladder)



- (3) Place 4 Part #E on 4 Part #A; secure with 8 Bolts #8.



E2 2x



U1 2x




1 1x



M6x16


8 10x

(1) Place Part #E2 on part #S;  
secure with 2 Bolts #8 (from bottom to top).




(2) Connect Part #E2 and the Assembled Beam (C/C1)  
with part #U1; secure with 3 Bolts #8 .

(3) Repeat the above procedures to assemble another side.



(E3) 2x



(U1) 2x




(1) 1x



M6x16


(8) 10x

(1) Place Part #E3 on Part #S; secure with 2 Bolts #8 (from bottom to top).




(2) Connect Part #E3 and the Assembled Beam (D1/D2/D) with part #U1; secure with 3 Bolts #8.

(3) Repeat the above procedures to assemble another side.



E2 4x



U1 4x





1 1x



M6x16

8 20x

(1) Place 2 Part #E2 on Part #S; secure with 4 Bolts #8 (from bottom to top).



(2) Connect 2 Part #E2 and the Assembled Beam (D1/D2/D) with part #U1; secure with 6 Bolts #8.

(3) Repeat the above procedures to assemble another side.



F 4x



F1 4x



F2 4x



F3 4x



U2 16x




1 1x




M5x12

6 16x


15




X4



X4





X4



X4

(1) Attach Part #U2 to Part #F/F1/F2/F3 with Bolts #6.

(2) Repeat the above procedures to assemble the other 3 pieces.





✓ S4

(1) Insert Part #F2 and Part #F3 into Part #E;  
secure with 2 Bolts #6.

1 1x

M5x12


6 8x

M6x16

8 8x

Outside View

Inside View



(2) Connect Part #F2/F3 and the Assembled Beam  
with Part #U2; secure with Bolts #8.

(3) Repeat the above procedures to assemble  
the other three sides.






✓ S4

(1) Insert Part #F and Part #F1 into Part #E;  
secure with 2 Bolts #6.





Outside View

Inside View



(2) Connect Part #F/F1 and the Assembled Beam  
with Part #U2; secure with Bolts #8.



(3) Repeat the above procedures to assemble  
the other three sides.






### Inside View

(1) Attach Part #K/K1 to Part #F2/F3 with Bolts #9.

(2) Insert Part #W3 to K2 and secure with Bolts #8.



Inside View










(3) Attach Part #K/K1 and Part #K2 to Part #E2 with Part #W3 and 2 Bolts #8.


(4) Attach Part #K2 and Part #K2 to Part #E3 with Part #W3 and 2 Bolts #8.

(5) Repeat the above procedures to assemble another side.

(1) Insert Part #W3 to K2 and secure with Bolts #8.



Inside View



(2) Attach Part #K and Part #K1 to Part #E3 with Part #W3 and Bolts #8.

(3) Connect Part #K/K1 and Part #F2/F3 with Bolts #9.

(4) Repeat the above procedures to assemble another side.



W2 4x






1 1x



M6x16

8 12x




(1) Insert Part #W2 into Part #K1 and Part #K.

(2) Secure with 2 Bolts #8.




Inside View

(3) Secure them to Part #E with Bolts #8.




(4) Repeat the above procedures to assemble the other three sides.



(S1) 1x




(T) 3x



(Z2) 1x

Secure Part #T to Part #Z2, Part #S and Part #S1.



**ATTENTION:** The holes of Part #Z2, Part #S and Part #S1 need to be aligned, on the same vertical line.





**From bottom to top**









Insert Part #Q/Q1 into the hole that around the edge of Part #Z2 .









J2 2x




Y 2x




1 1x




7 4x




8 2x



(1) Attach Part #Q to Part #J2 with 2 Bolts and Nuts #7.





(2) Place Part #Y on Part #J2 and Part #E3, securing with Bolt #8.




(3) Repeat these procedures to assemble the other side.

Inside View





J 2x



J1 2x



Y 4x



1 1x





M6x16


8 4x

(1) Place Part #J1, Part #J2 and Part #Q into order on Part #E2; put on Part #Y and secure with Bolt #8.


**ATTENTION: The holes need to be aligned.**




(2) Place Part #J, Part #J2 and Part #Q into order on Part #E2; put on Part #Y and secure with Bolt #8.



(3) Repeat these procedures to assemble the another side.



(J) 2x



(J1) 2x



(Y) 2x




M6x16

(8) 2x



(1) 1x



Inside View

(1) Place Part #J , Part #J1 and Part #Q1 into order on Part #E2; put on part#Y and secure with Bolt #8.

**ATTENTION:** The holes need to be aligned.

(2) Repeat these procedures to assemble the another side.



Y1 4x



1 1x




M6x12

7 8x




M6x16


8 4x



(1) Attach Part #Q to Part #J with Bolt and Nut #7; attach Part #Q1 to Part #J1 with Bolt and Nut #7.




(2) Place Part #Y1 on Part #J/J1 and Part #E, securing with Bolt #8.




(3) Repeat these procedures to assemble the other three corners.

Inside View








(H) 2x



(H1) 2x



(P) 2x



(P1) 2x




(Y) 2x




M6x16


(8) 6x



(1) Insert Part #P and Part #P1 into the top roof.







(2) Place Part #H and Part #H1 on Part #E3; put on part#Y and secure with Bolt #8.



(3) Place Part #H/#H1 on Part #E2, securing with Bolt #8.

(4) Repeat these procedures to assemble the another side.



(1) Insert Part #P2 into the top roof.

(2) Place Part #H2 on Part #E2, securing with Bolt #8.

(3) Repeat these procedures to assemble the another side.






M6x16

8 4x



Y1 4x




### Outside View

- (1) Place Part #H/H1 and Part #H2 on Part #E; put on part #Y1 and secure with Bolt #8.
- (2) Repeat these procedures to assemble the other three corners.





G2 2x



M 4x



Y 2x






M6x16

8 2x


(1) Insert 2 Parts #M into the frame.

(2) Place Part #Y on Part #G2 and Part #E3, securing with Bolt #8.


(3) Repeat these procedures to assemble the another side.




(1) Insert Part #L, Part #L1 and Part #L2 into the frame.




G 2x



L 2x



L1 2x



L2 2x



Y 2x







M5x12

6 4X




M6x16

8 2x




(2) Attach Part #G to the frame,  
securing with Bolt #6.




(3) Place Part #G and Part #G2 on Part #E2;  
put on part#Y and secure with Bolt #8.

(4) Repeat these procedures to assemble the another side.


(1) Insert Part #N, Part #N1 and Part #N2 into the frame.




G1 2x



N 2x



N1 2x



N2 2x



Y 2x






M5x12

6 4X



M6x16

8 2x



(3) Place Part #G1 and Part #G2 on Part #E2;  
put on part#Y and secure with Bolt #8.

(2) Attach Part #G1 to the frame,  
securing with Bolt #6.

(4) Repeat these procedures to assemble the another side.




(1) Insert Part #L, Part #L1 and Part #L2 into the frame.




G 2x



L 2x



L1 2x






L2 2x




M5x12

6 4x




(2) Attach Part #G to the frame, securing with Bolt #6.




(3) Repeat these procedures to assemble the another side.


(1) Insert Part #N, Part #N1 and Part #N2 into the frame.




G1 2x



N 2x



N1 2x






N2 2x




M5x12

6 4x



(2) Attach Part #G1 to the frame, securing with Bolt #6.



(3) Repeat these procedures to assemble the another side.




Y 2x




M6x16

8 2x



(1) Place Part #G and Part #G1 on Part #E2; put on part #Y and secure with Bolt #8.



(2) Repeat these procedures to assemble the another side.




Y1 4x



M6x16

8 4x



(1) Place Part #G and Part #G1 on Part #E;  
put on part #Y1 and secure with Bolt #8.


**(2) Repeat these procedures to assemble the other three corners.**







- (1) Place 7 hooks on each slot of the Sidewall Track (C1&C).
- (2) Place 9 hooks on each slot of the Sidewall Track (D&D1&D2).





1 1x



W 2x





M6x16

8 4x

(1) Install Part #W at the joint of Part #C & C1 with Bolts #8;  
Install Part #W at the joint of Part #D2 with Bolts #8.


**(2) Repeat the above procedures to assemble another side.**






Z1 4x


Hang up mosquito sidewalls to inside track.



Z1




Z1



Z1

Z1




Z1


Z1

Z1

Z1








Z1



Ⓩ 4x

Hang up mosquito sidewalls to outside track.



# Thanks for your purchase.

At domi outdoor living, we believe in our products.

That's why we provide a 12-month warranty and friendly, easy-to-reach after-sales service. So if you have any questions about our product and assembly, please feel free to contact us. We will be here for you.

**Support:**



**After-sales contact email:**

[service@domioutdoorliving.com](mailto:service@domioutdoorliving.com)

Please tell us your order ID when contact.

Attach photos of damaged part for instant reply.