

Product parameters

Parameter			
Solar Panel	Poly crystalline silicon 5V/3W	Poly crystalline silicon 5V/4.5W	Poly crystalline silicon 5V/11W
Battery	18650# Lithium Battery 3.7V/2200mAh	18650# Lithium Battery 3.7V/4000mAh	18650# Lithium Battery 3.7V/6600mAh
LED Source	52*2pcs LED2835	88*2pcs LED2835	201*2pcs LED2835
Charging Time	5-6 Hours	5-6 Hours	5-6 Hours
Working Time	10-12 Hours	10-12 Hours	10-12 Hours
IP Grade	IP55	IP55	IP55
Function	Light control	Light control	Light control
Power	2W	3W	5W
Main Material	Aluminum Lamp Body+PPMA	Aluminum Lamp Body+PPMA	Aluminum Lamp Body+PPMA

Solar Pillar Light

Product Manual



Notice

1. When the lamp is not working or the working time is short, please place the lamp in a location where the sun is shining directly to charge for 2 days. Don't turn on the lamp during the process. If it still doesn't work or working time is short, please contact the factory.
2. The product has light sensor, please use it where there is no light.
3. Rainy weather will affect the charging of lamp, the working time will be reduced.
4. Don't install the lamp in a place that is easily immersed in water.
5. Don't install the lamp in eaves, tree bottoms and other environments where there is no direct sunlight.
6. The lamp has built-in battery, don't throw away directly.

Please charge in the sun for 4 hours before using for the first time.

Check Remarks before use

- 1.Place lamp under sunshine for 4-6h after you get goods and turn on, because it only reserve part energy in battery.
- 2.The less time to charge under sunshine, the less time to work at night,Working time depends on surrounding,geography latitude,seasons etc.
- 3.There is the difference of working time and brightness extent for different light, please note.
4. Please clean the panel and in case of poor charging effect if it happen to have obstacle in panel in using.

Product Manual




Press the switch

- 1.Press switch first,turn on in 100%
- 2.Press switch second, turn on in 50%
- 3.Press switch third, close
- 4.Press switch for 2-3 seconds, transfer CCT



It turns into the light at night.



switch circularly




During the day, it is charged by the sun.

Packing Included


- 1 x Solar Column Lamp
- 1 x Instruction Manual
- 4 x Expansion screw

Installment step




1

Unscrew the four screws on the side and remove the bottom hanging plate




2

Drill holes according to the hole distance of the hanging plate, insert expansion screws, and fix the hanging plate on the installation position



3

Align the lamp bottom with the hanging plate, tighten the side screws, finish the installation



4

Turn on the switch then start to work

Dimensions

