


# ASSEMBLY INSTRUCTIONS







## Shoe Bench







### NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Please never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

# PARTS LIST

<b>Top Panel</b> 1 PC  A1	<b>Side Panel</b> 2 PCS  A2 (L&R)	<b>Shelf</b> 1 PC  A3
<b>Bottom Panel</b> 1 PC  A4	<b>Divider</b> 1 PC  A5	<b>Back Panel</b> 1PC  A6

# HARDWARE LIST

<b>Camlock</b> 16 SETS  B1	<b>Wood Dowel</b> 16 PCS  B2	<b>Screw</b> 14 PCS  B3	<b>Glue</b> 1 PC  B4
--	--	---	--





## Note:

- Read these instructions carefully before assembling.
- Tools requirh area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packied : Phillips screwdriver, flat screwdriver.
- Find a clean, smootng material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.



## To use Dowels:


1. Add glue (about ¼ full ) in the hole(s) of each board to be joined.
1. Insert the Dowel(s) and join boards.
2. Wipe excess glue with a damp paper towel.


## To use Cam Locks:

<b>1. Insert Cam Pin until snug</b>  Do not over-tighten	<b>2. Set boards together</b> 	<b>3. Insert Cam Lock</b>  Note arrow direction	<b>4. Turn Cam Lock clockwise (half a turn)</b>  if it won't turn halfway, back out the Cam Pin ¼ turn and try Cam Lock again.
---	--	---	---



Step 1: Assemble Divider A5 to Shelf A3 using Camlocks B1 and Wood Dowels B2.


B1:   2SETS


B2:  2PCS




Step 2: Assemble Shelf A3 and Bottom Panel A4 to Side Panels A2 using Camlocks B1 and Wood Dowels B2.

B1:   8SETS

B2:  8PCS



Step 3: Assemble Top Panel A1 to Side Panels A2 and Divider A5 using Camlocks B1 and Wood Dowels B2.



Step 4: Assemble Back Panel A6 to this unit using Screws B3.

